

CARE INSTRUCTIONS



Safety Instructions

Please follow proper assembly instructions.

- Always turn off the electrical power before placing the shade, removing, or cleaning the lamp.
- Lamps are delicate. Do not drop, crush, bend or shake them.
 Vibration or impact may cause filament breakage and short lamp life.
- Do not alter the construction or design. Do not remove safety labels or devices.
- Do not use equipment for other than its intended purpose, as described in the equipment manual.
- · Intended for indoor use only.
- To prevent the risk of severe or fatal electrical shock, do not twist the wire and keep it away from the sharp objects.
- Extra care needs to be given while placing the glass shade on the lamp/Pendant.



LIGHTING

These products are crafted with great attention to the details and designed for decorative purpose only. Please follow the instructions carefully, before using and cleaning.

Lamp Shade

Fabric Shades:

- Turn off power supply before removing shade from lamp base.
- Gently remove the accumulated dirt and dust using a clean soft cloth, or vacuum cleaner (Select the vacuum brush size as per the requirement).
- If necessary you may use a white cloth dampened with a mild solution of soapy water to wash the shade gently and evenly. Rinse thoroughly with a white cloth dipped in clean water. The shade should be allowed to dry quickly, using home dry cleaning product.
- Avoid using glass cleaners, abrasive cleaning compounds, ammonia or bleach; they may damage the fabric.
- Make sure cleaning materials are free of grit or any kind of sharp edged objects in order to avoid snagging in the shade fabric.



Metal Shades

- Turn off power supply before removing shade from lamp base.
- Gently wipe down the surface with a damp cloth and wipe thoroughly with a dry cloth immediately.
- For stubborn stains, clean the surface using a clean soft white absorbent cloth dampened with a solution of mild soap and warm water. Then it should be allowed to dry quickly using a dry cloth or home dry cleaning products.
- Make sure cleaning materials are free of grit and other sharp edged objects in order to avoid chances having scratches.
- Do not use abrasive, acid, alcohol-based, or solvent-based cleaners; they may fade the finish.

Glass Shades

- Turn off power supply before removing shade from lamp base.
- Gently wipe down the surface with a damp cloth and wipe thoroughly with a dry cloth immediately.
- For stubborn stains, clean the surface using a clean soft white absorbent cloth dampened with a solution of mild soap and warm water. Then it should be allowed to dry quickly using a dry cloth or home dry cleaning products.
- Make sure cleaning materials are free of grit or any kind of sharp edged objects in order to avoid chances of having scratches.



Lamp Bases-Powder Coated Lamps

- Turn off power supply before cleaning shade or lamp base.
- Gently wipe down the surface with a damp cloth and wipe thoroughly with a dry cloth immediately.
- For stubborn stains, clean the surface using a clean soft white absorbent cloth dampened with a solution of mild soap and warm water. Then it should be allowed to dry quickly using a dry cloth or home dry cleaning products.
- Do not use abrasive, acid, alcohol-based, or solvent-based cleaners; they may fade the finish.

Lamp Bases-Metal Finished

- Turn off power supply before cleaning shade or lamp base.
- Gently wipe down the surface with a damp cloth and wipe thoroughly with a dry cloth immediately.
- For stubborn stains, clean the surface using a clean soft white absorbent cloth dampened with a solution of mild soap and warm water. Then it should be allowed to dry quickly using a dry cloth or home dry cleaning products.
- Do not use abrasive, acid, alcohol-based, or solvent-based cleaners; they may fade the finish.



Lamp Bases-Glass Lamps

- Turn off power supply before cleaning shade or lamp base.
- · Use a clean, soft cloth to gently clean the accumulated dirt.
- Gently wipe down the surface with a damp cloth and wipe thoroughly with a dry cloth immediately.
- For stubborn stains, clean the surface using a clean soft white absorbent cloth dampened with a solution of mild soap and warm water. Then it should be allowed to dry quickly using a dry cloth or home dry cleaning products.
- Do not use abrasive, acid, alcohol-based, or solvent-based cleaners; they may fade the finish.
- Make sure cleaning materials are free of grit and other sharp edged objects in order to avoid chances of having scratches.

Lamp Base-Wooden Lamps

- Turn off power supply before cleaning shade or lamp base.
- Dust with a slightly damp, soft, lint-free cloth.
- Wipe dry with a dry, soft cloth in the direction of the wood grain.
- Apply a good quality furniture polish twice a year to maintain the finish of the lamp.
- Do not use abrasive, acid, alcohol-based, or solvent-based cleaners; they may fade the finish.
- Do not use oil based polishes or abrasives or polishes containing waxes.



Pendant Lamps

- Turn off power supply before cleaning pendant or its shade.
- Use a clean, soft cloth to gently clean the accumulated dirt.
- Gently wipe down the surface with a damp cloth and wipe thoroughly with a dry cloth immediately.
- Do not use abrasive, acid, alcohol-based, or solvent-based cleaners; they may fade the finish.
- Make sure cleaning materials are free of grit and other sharp edged objects in order to avoid chances of having scratches.