IMPORTANT



Prior to installing Data Drive™, you must make sure to back up all your files so they can be transfered to your new hardrive. Data not backed up prior to new installation will be lost. Refer to http://manuals.playstation.net/document/en/ps4/settings/data usb.html for the info and procedure for backing up data.



DATA BANK

NYKO


USB Storage Device Setup for Hardware Update

REQUIRED:


- A USB storage drive (FAT 32) with 2 GB of space
- A computer with internet connection



Create a new folder on your computer and name it **PS4** (upper case letters).




Create a folder INSIDE the **PS4** folder and name it **UPDATE** (upper case letters).




Save the **PS4** folder (with update folder inside it) to the USB storage device.



Download the latest system update: www.playstation.com/en-us/support/system-updates/PS4/



Save the downloaded file in the update folder inside the PS4 folder that is on the USB storage device.



Once the downloaded file is placed in the update folder make sure every folder is properly labeled (upper case) and eject the USB storage device.




Register this product online: www.nyko.com

If you are experiencing difficulties, please contact us: **Email: customersupport@nyko.com**

Phone: +1-888-400-6956

Nyko Product Limited Warranty:

This Nyko product is warranted to the original purchaser for the product's normal intended use for a period of ninety (90) days from the date of purchase. If a defect covered under this warranty occurs, Nyko will replace or repair the product or its defective parts, at Nyko's option, at no charge. This warranty does not apply to defects resulting from misuse or modification of the product. The product should be returned with proof of purchase, a brief statement of the claimed defect, and the purchaser's contact information, to: Nyko Technologies, Inc., 1990 Westwood Blvd., 3rd Floor, Los Angeles, CA 90025, with freight charges prepaid. Please allow 3-4 weeks for processing.



Your USB storage device is ready to be used with your PS4 to update. Refer to initialize system software sheet © quickstart.

- Make sure to download the latest software version from www.playstation.com
- You will need to use the full software update version, not a partial file intended to update an existing system software to the latest version. For a new hard drive install you must to use the full update file. Check the playstation.com and make sure that the full install file is selected/downloaded and placed on the USB storage device.
- Make sure to label all files correctly (upper case letters)
- The USB storage device you select must be FAT 32 formatted and have sufficient space for a fresh install of the system software
- The USB storage device must be FAT32 format to work properly with the PS4 console.