TYPE PAD

Full QWERTY Keyboard Attachment



TYPE PAD is designed to be compatible with the original and new versions of the XBOX One wireless controller.



Those with new model XBOX One controllers (with standard headset input) will need to extend the pass-thru headset jack located under the rubber cover on the back of the Type Pad. Gently flip into extended position and replace the rubber cover to cover the storage area.




Attach the Type Pad by aligning the plugs and gently pressing into place.



Power on the controller and console.




Press and release the SYNC button on the Type Pad to initiate pairing. The LED indicator will blink rapidly to indicate sync discovery mode.



Insert the Wireless Adaptor into an available USB port on the side or back of the console.



Once properly paired, the LED indicator will glow SOLID blue for 2-3 seconds to indicate successful connection before turning OFF. Test the mini directional pad and buttons to confirm proper operation. Repeat procedure if necessary to establish sync.



Once properly installed, connect headset (style compatible with your controller) by directly connecting to the appropriate port on the Type Pad.

Register this product online:

Register this product online www.nyko.com

If you are experiencing difficulties, please contact us: **Email: customersupport@nyko.com**

maii: customersupport@nyko.co Phone: +1-888-400-6956

Nyko Product Limited Warranty:

This Nyko product is warranted to the original purchaser for the product's normal intended use for a period of ninety (90) days from the date of purchase. If a defect covered under this warranty occurs, Nyko will replace or repair the product or its defective parts, at Nyko's option, at no charge. This warranty does not apply to defects resulting from misuse or modification of the product. The product should be returned with proof of purchase, a brief statement of the claimed defect, and the purchaser's contact information, to: Nyko Technologies, Inc., 1990 Westwood Blvd., 3rd Floor, Los Angeles, CA 90025, with freight charges prepaid. Please allow 3-4 weeks for processing.

NOTE:

Please note that only headsets supported by your wireless controller can be used with the Type Pad. The standard headset output on the Type Pad cannot be used unless your controller supports standard headsets, and the rotating jack on the Type pad is properly connected to that port on the controller.