

CHARGE DOCK

Quick Setup Guide

1

Wii U
Wii

Connect to console (Wii U or Wii) or USB power adapter (not Included)

2

Insert battery pak

3

Charge
Charge

4

NYKO

Register this product online:
www.nyko.com

Nyko is trademarks of Nyko Technologies, Inc. Wii and Wii U are registered trademarks of Nintendo, and Wii Remote is a trademark of Nintendo. This is a Nyko product and is not endorsed, manufactured or distributed by Nintendo. ©2014 Nyko Technologies, Inc. All Rights Reserved

Item# 87171

TECHNICAL SUPPORT:

We appreciate your support of Nyko products, and endeavor to guarantee your satisfaction with this purchase. If you are experiencing difficulties, please contact us:

Online: www.nyko.com

Email: customersupport@nyko.com

Phone: +1-888-400-6956

Nyko Product Limited Warranty:

This Nyko product is warranted to the original purchaser for the product's normal intended use for a period of ninety (90) days from the date of purchase. If a defect covered under this warranty occurs, Nyko will replace or repair the product or its defective parts, at Nyko's option, at no charge. This warranty does not apply to defects resulting from misuse or modification of the product. The product should be returned with proof of purchase, a brief statement of the claimed defect, and the purchaser's contact information, to: Nyko Technologies, Inc., 1990 Westwood Blvd., 3rd Floor, Los Angeles, CA 90025, with freight charges prepaid. Please allow 3-4 weeks for processing.