

User Manual:



Instructions to reset and use:

Step 1

Each lock is provided with the starting combination "0 0 0"

Step 2


Ensure the "0 0 0" is facing you and push down button A to open the lock. Slide forward and hold button B at the back.

Step 3

Slide button B and holding it in place set your 3 number combination.

Step 4

After you have set your combination, release button B.



(Fig 1)