

2-4 Cam Heavy Duty WIRED DVR CAMER SYSTEM


DVR MANUAL

LOGIN

1, no need password by default, if you need User/admin login in with password, refer to setting details in maintain menu-user.

2, after input password, confirm by remote controller left/right/up/down button.

3, enter main menu with password



MAIN MENU FUNCTION

1, REC setting, 2, Playback, 3, System setting, 4, Maintenance



1.1, REC setting

Recording mode setting, auto recording & scheduled recording mode.

1.11, auto recording mode

Recording File size can be set as 5MIN、10MIN、15MIN、20MIN、30MIN、45MIN

Audio mode can be on/off

Recording channel setting; Set the channel's opening and closing status, resolution, bit rate, mirror image on/off.




1.12 Scheduled recording mode

Recording file size can be set as 5MIN、 10MIN、 15MIN、 20MIN、 30MIN、 45MIN

Audio mode can be on/off

Recording channel setting; Set the channel's opening and closing status, resolution, bit rate, mirror image on/off.

Set the recording time; Set recording for a certain period of time from Monday to Sunday




2.1 Playback

2.1.1 video search function

Channel selection settings; whether to query all channels or a channel

Start time setting; Set the start time of the query

End time setting; Set the end of the query time



3.1 Function setting menu

3.1.1 Language function settings; language can be set to Simplified Chinese, Traditional Chinese, English

Time function setting; set the current time

Preview time setting; can be set to open or close the time when the screen is displayed


Preview channel flag settings; can be set to channel flag on the screen display is turned on or off state




4.1 System maintenance function



4.11 Storage Management; View the current device capacity, available capacity, and whether to format all the data within the device



4.12 User Management; Set the user's account type, password and management status



4.13 Upgrade Settings; set whether the device is automatic maintained state

Export settings; Export the configuration parameters of this machine to other machines

Import settings; Import configuration parameters for other machines into this machine

Restore the default configuration; whether to restore the initial configuration of the machine, set the device to be auto restart

Software upgrade; software can be set up for online upgrade

System reboots; Set whether the system needs to restart automatically



4.14 log information settings; query some actions occurred at a time



4.15 System Information; check the current software version

4.16 vehicle information settings;


Company Settings; set the company name of the current device

License plate number; set the current equipment license plate number

Driver settings; set the current device driver name

Line settings; set the current device's route

Device ID; set current device ID



The image shows a screenshot of a 'Car Info' settings menu. The menu is titled 'Car Info' at the top. It contains five rows of settings, each with a label on the left and a value in a dropdown menu on the right. The values are: 'Name' for Company, 'B668Y' for Bus Num, 'DriverName' for Motor Man, '290' for Line Index, and '000001' for Device Num. At the bottom of the menu are two buttons: 'Ok' and 'Cancel'.

Label	Value
Company	Name
Bus Num	B668Y
Motor Man	DriverName
Line Index	290
Device Num	000001

Thanks for your purchase. Call Falcon at 972.600.1320 or you have any more questions

www.dashcam.co – 972.600.1320