


M-Base Instructions



The M-Base ships with a protective brown paper coating on each side. These can be peeled off.

There is a top and bottom side to the M-Base. The orientation shown in the socket map above is the "top" side of the base, and is the side most compatible products should be inserted in to.

The Mezco product compatible slots come in two varieties, a standard size that fits the majority of those products, and a variant size that fits some of the slightly larger variants. It is possible new variants will emerge in the future that may not be compatible with the M-Base.

Some of the stand arms that the M-Base is compatible with have longer base pegs than the base is thick. The sockets on the M-Base feature a slightly tapered design, so their grip will get stronger the deeper a stand arm's peg is inserted into it. Because of this, you will find that the M-Base will provide a firm grip before you would have to push some of the stand arms all the way in through.

It should also be noted that compatibility across the stand arms from the lines that the M-Base supports will not be completely universal. It will function with the majority of stand arms from those lines, but for some of them there exists some releases that deviate from the common dimensions you find with those stand arms.

The variant stand arms may not fit, and if forced they may cause damage to the base or the stand arm.

Due to the tapered slots, if you find a stand is too loose through the top side, flip the base over and try it through the bottom. It may provide a better grip.