

It's not rocket science,

but following these  
instructions will make

installing your seat covers  
a lot easier.

We promise

**PART NUMBER** 52123

**PRODUCT TYPE** BUCKET SET

**PIECES**

- (1) DRIVER BACK
- (1) DRIVER BOTTOM
- (1) PASSENGER BACK
- (1) PASSENGER BOTTOM
- (2) HEADREST COVERS
- (2) STRINGLOCKS



[ttcovers.com/52123video](https://ttcovers.com/52123video)

*Seat Backs & Bottoms have tags signifying Driver or Passenger.*

*Ensure airbag patch (same side as the TigerTough tag) goes on the outside edge of the seat.*



*Basically, you break it, we buy it.  
Seriously.*

**Your new seat covers are covered by a two-year, unconditional, no B.S. warranty.**

That means that if you manage to abuse them to a point that they can't perform like they're supposed to within two years of when you bought them, we'll make it right.

Depending on what is more practical, we'll either repair or replace the damaged cover.

### **General care instructions:**

1. In most cases dirt, debris, spills and pet hair can be removed by wiping with a damp cloth.
2. Seat covers can be removed and machine washed on low temperature setting using mild detergent. Drip dry or machine tumble dry on a no heat cycle. Straps should be coiled and secured with rubber bands for machine washing and drying.
3. Soil may be removed with spray cleaner or detergent and water.
4. Oil or grease stains should first be treated with a dry cleaning solvent followed by a spray cleaner or detergent and water.
5. Do not use bleach.

### **IMPORTANT: AIRBAG COMPATABILITY**

**YOUR SEAT HAS SEAT SIDE AIRBAGS.** For maximum safety in the event of a crash, these airbags **MUST NOT** be restricted.

Your cover has been engineered with a tearaway flap (stitched with white thread) that will allow the airbag to deploy. Ensure that this flap & the orange TigerTough tag are facing the door.

TigerTough is not responsible for any issues resulting from incorrectly installed seat covers.

# Install Seat Cover



Slide the seat forward and raising it to the highest position to give you the most amount of working room.

Remove headrest by pressing in the tab on the base of the headrest mount and lifting up



Unhook the flap behind seat that runs under bottom of the seat. You will need to unhook the plastic connector to release this flap.



Unhook elastic straps from seat bottom.

Pull down to detach from seat bottom.



Place the seat bottom cover over the seat bottom with long flaps towards the front. Check the tag to make sure you have the right side.





Push the flap between the seat back and seat bottom as shown.






Drop the string closest to the door between the plastic trim and the seat cushion to run it on the inside of the seat frame. Drop the string on the other side down to the floor.



Tuck the cover in along the edge of the plastic trim for a clean, finished look.

Next, secure the strings together below the seat with the StringLock (see next page)

# THE STRINGLOCK



1

Run one string through the channel on the end of the StringLock.

2

Pull the string tight, pulling the StringLock towards one edge of the seat. Press the string into the clamp, locking it in place.

3

Run the second string through the StringLock just like the other one.

4

Pull the loose end of the second string until everything is tight and lock it into place as well.



Run the flaps from the front to the back beneath the seat, making sure it runs above the adjustment bar and other seat mechanisms.



Pull the flaps tight at the back and secure them.



Turn the seat back partially inside out and slide it over the seat as shown.

Make sure the airbag tearaway is on the side closest to the door.





Pull down so the seams are snug at the top of the seat.

Press the cover down around the plastic headrest mounts for a clean, finished look.



Push the flaps between the seat back and bottom as shown.



Pull them out from behind the seat.

The carpet flap that was released earlier tucks up inside the seat back so it is inside the cover and out of the way.



Fasten the flaps at the back as shown.



The long flap goes down and secures under the seat bottom to finish everything off.



Put the headrest back into the headrest mounts.





Put cover on with the tail towards the front.

Secure the tail up inside the back of the headrest.

You're done! Mission accomplished.