INSTALLATION GUIDE



75700 Rear Bench RAM 1500-5500 (2011-2018)



BILL OF MATERIALS

ITEM	QUANTITY
Seat Back Cover	1
Seat Bottom Cover	1
Headrest Cover	3

Watch the install video here: www.ttcovers.com/75700video

General care instructions:

- 1. In most cases dirt, debris, spills and pet hair can be removed by wiping with a damp cloth.
- 2. Seat covers can be removed and machine washed on low temperature setting using mild detergent.

Drip dry or machine tumble dry on a no heat cycle.

Straps should be coiled and secured with rubber bands for machine washing and drying.

- 3. Soil may be removed with spray cleaner or detergent and water.
- 4. Oil or grease stains should first be treated with a dry cleaning solvent followed by a spray cleaner or detergent and water.
- 5. Do not use bleach.



1 - Preparation




□ 1.1 - Tip seat bottom up.

□ 1.2 - Remove headrests by pressing in tabs at base of headrest and pulling up



2 - Install Seat Back Cover



- □ 2.1 Push seat cover behind seatbelt.
- **2**.2 Push center flap behind seat back, between the brackets.
- □ 2.3 Push outside flaps down on outside of brackets.
- **2**.4 Reach up behind seat from bottom and pull flaps down.
- □ 2.5 Pull cover down over seat back.
- □ 2.6 Tip seat bottom 1/2 way down and push front flaps between seat back and botom.
- **2**.7 Tip seat bottom up. Pull front and back flaps tight and fasten together.
- **2**.8 Line holes in cover up with headrest holes and work holes around plastic trim.
- **2**.9 Push front flap between seat back and seat bottom.
- **2**.10 Pull front flap tight and fasten to Velcro on seat back.



3 - Install Seat Bottom Cover



- \Box 3.1 Tip seat bottom 1/2 way up.
- **3**.2 Pull cover over seat bottom. Pull tight, tucking cover behind plastic trim at rear of seat bottom.
- **I** 3.3 Ensure that the metal restraint loops go through the holes in the cover.
- □ 3.4 Push top flap between seat back and bottom.
- □ 3.5 Tip seat bottom up.
- □ 3.6 Pull top and bottom flaps tight and fasten together.



4 - Install Headrest Cover



- □ 4.1 Put headrest back in seat by pressing plastic tabs and pushing down on headrest.
- □ 4.2 Pull cover over head rest with "loop" Velcro in front and "hook" Velcro in rear.
- □ 4.3 Fasten Velcro tabs together under headrest.

