

It's not rocket science,
but following these
instructions will make
installing your seat covers
a lot easier.

We promise.

PART:	E82203
PRODUCT:	KOMATSU EXCAVATOR SEAT COVER
PIECES:	(1) SEAT BACK COVER (1) SEAT BOTTOM COVER (1) HEADREST COVER



*Basically, you break it, we buy it.
Seriously.*

Your new seat covers are covered by a two-year, unconditional, no B.S. warranty.

That means that if you manage to abuse them to a point that they can't perform like they're supposed to within two years of when you bought them, we'll make it right. Depending on what is more practical, we'll either repair or replace the damaged cover.

General care instructions:

1. In most cases dirt, debris, spills and pet hair can be removed by wiping with a damp cloth.
2. Seat covers can be removed and machine washed on low temperature setting using mild detergent.
Drip dry or machine tumble dry on a no heat cycle.
Straps should be coiled and secured with rubber bands for machine washing and drying.
3. Soil may be removed with spray cleaner or detergent and water.
4. Oil or grease stains should first be treated with a dry cleaning solvent followed by a spray cleaner or detergent and water.
5. Do not use bleach.

Install Seat Back

Start with the seat back. Undo all the velcro tabs on the cover. Slide cover over the headrest.

The flaps at the bottom should be facing you.



[View from back of seat]

Pull flaps tight and secure to the velcro on the back of the seat cover.

Work the cover the rest of the way down the seat back.



Fasten the three tabs at the top of the seat cover.

Press the edges under the plastic trim of the headrest mounts for a clean, finished look.

Align the small cutout with the switch on the side of the seat.

Press cover around switch to tuck it under the plastic trim.



Slide seat bottom cover on.

Make sure it is not covering the seat adjustment lever on the side, and that the opening goes around the adjustment bar in the middle.

Push flaps between the seat back and seat bottom.



Push flaps between the seat back and seat bottom.

Install Seat Bottom/Headrest

[View from back of seat]

Pull flaps tight and secure to the velcro on the back of the seat cover.



Tuck the tab inside the back of the headrest cover to secure the velcro.

Slide headrest cover over the headrest with the long tab facing you.



Mission Accomplished