It's not rocket science, but following these instructions will make installing your seat covers a lot easier.

We promise.

PART: | E82204

PRODUCT: | CAT WHEEL LOADER SEAT

COVER

PIECES: (1) SEAT BACK COVER (1) SEAT BOTTOM COVER (1) HEADREST COVER



Basically, you break it, we buy it. Seriously.

Your new seat covers are covered by a two-year, unconditional, no B.S. warranty.

That means that if you manage to abuse them to a point that they can't perform like they're supposed to within two years of when you bought them, we'll make it right. Depending on what is more practical, we'll either repair or replace the damaged cover.

General care instructions:

- 1. In most cases dirt, debris, spills and pet hair can be removed by wiping with a damp cloth.
- 2. Seat covers can be removed and machine washed on low temperature setting using mild detergent.
 - Drip dry or machine tumble dry on a no heat cycle.
 - Straps should be coiled and secured with rubber bands for machine washing and drying.
- 3. Soil may be removed with spray cleaner or detergent and water.
- 4. Oil or grease stains should first be treated with a dry cleaning solvent followed by a spray cleaner or detergent and water.
- 5. Do not use bleach.

Install Seat Back

Start with the seat back. Undo all the velcro tabs on the cover. Slide cover over the headrest.

The flaps at the bottom should be facing you.





Push the velcro flaps in between the seat back and bottom.

Folding the seat forward will give you more room for this step.

Work the cover the rest of the way down the seat back.






Pull tabs tight and secure to velcro at the back of the seat.

Align the small cutout with the switch on the back of the seat.

Secure the velcro tabs at the top of the cover.





Secure the small velcro tab underneath the armrest.

Work the cover around the seat adjustment knob.



Install Seat Bottom/Headrest

Pull the headrest cover over the headrest with the long tab towards the front.





Slide the seat bottom cover on over the seat bottom.

Fasten velcro to the velcro tab inside the headrest cover.





Push flaps between the seat back and bottom.

Folding the seat forward will give you more room for this step.

Pull tight and secure the velcro.

