

It's not rocket science,
but following these
instructions will make
installing your seat covers
a lot easier.

We promise.

PART:	E82208
PRODUCT:	DEERE MINI EXCAVATOR SEAT COVER
PIECES:	(1) SEAT BACK COVER (1) SEAT BOTTOM COVER



*Basically, you break it, we buy it.
Seriously.*

Your new seat covers are covered by a two-year, unconditional, no B.S. warranty.

That means that if you manage to abuse them to a point that they can't perform like they're supposed to within two years of when you bought them, we'll make it right. Depending on what is more practical, we'll either repair or replace the damaged cover.

General care instructions:

1. In most cases dirt, debris, spills and pet hair can be removed by wiping with a damp cloth.
2. Seat covers can be removed and machine washed on low temperature setting using mild detergent.
Drip dry or machine tumble dry on a no heat cycle.
Straps should be coiled and secured with rubber bands for machine washing and drying.
3. Soil may be removed with spray cleaner or detergent and water.
4. Oil or grease stains should first be treated with a dry cleaning solvent followed by a spray cleaner or detergent and water.
5. Do not use bleach.

Install Cover

Place seat bottom cover over the seat bottom with the long flaps at the front.

Push the short flap in between the seat back and bottom.



Work all of the way down the seat back. Push the velcro flap in between the seat back and seat bottom.

[View from behind seat] Pull strings tight and secure behind the base of the seat with the orange StringLock device (see next page)



Make sure cover is tucked behind this lever so it is still accessible.

Pull the long flaps tight and secure them to the flap you pushed through from the top.





Pull the flap tight and secure velcro behind seat.

Turn the seat back cover partly inside out. Slide over seat back with the pocket towards the back.



MISSION ACCOMPLISHED.

THE STRINGLOCK




①

Run one string through the channel on the end of the StringLock.




②

Pull the string tight, pulling the StringLock towards one edge of the seat. Press the string into the clamp, locking it in place.



③

Run the second string through the StringLock just like the other one.



④

Pull the loose end of the second string until everything is tight and lock it into place as well.



Watch the video
ttcovers.com/stringlock