It's not rocket science, but following these instructions will make installing your seat covers a lot easier.

We promise.

**PART: | E82216** 

PRODUCT: CAT DOZER SEAT COVER

- PIECES: (1) HEADREST COVER (1) SEAT BACK COVER (1) SEAT BOTTOM COVER



# Basically, you break it, we buy it. Seriously.

Your new seat covers are covered by a two-year, unconditional, no B.S. warranty.

That means that if you manage to abuse them to a point that they can't perform like they're supposed to within two years of when you bought them, we'll make it right. Depending on what is more practical, we'll either repair or replace the damaged cover.

#### General care instructions:

- 1. In most cases dirt, debris, spills and pet hair can be removed by wiping with a damp cloth.
- 2. Seat covers can be removed and machine washed on low temperature setting using mild detergent.
  - Drip dry or machine tumble dry on a no heat cycle.
  - Straps should be coiled and secured with rubber bands for machine washing and drying.
- 3. Soil may be removed with spray cleaner or detergent and water.
- 4. Oil or grease stains should first be treated with a dry cleaning solvent followed by a spray cleaner or detergent and water.
- 5. Do not use bleach.

### **Install Seat Bottom Cover**

Undo the all velcro on the seat back.

Slide over headrest with the pocket facing the back.





Drop the string closest to the door between the plastic trim and the seat cushion to run it on the inside of the seat frame. Drop the string on the other side down to the floor.

Push velcro tabs between the seat back and bottom.





Reach around from the back of the seat and secure the strings tightly using the StringLock device (see next page.) The tighter the strings, the better your cover will fit.

Fasten the flaps at the top to the velcro inside the cover.





Take the front flaps of the cover and run them between the plastic trim on the front of the seat and under the seat to the back, making sure it is above the seat mechanisms.

Tuck the sides of the cover between the plastic trim on the side of the seat.



## **Install Seat Bottom Cover**

Slide the seat forward and raising it to the highest position to give you the most amount of working room.

Unhook the flap behind seat that runs under bottom of the seat



Drop the string closest to the door between the plastic trim and the seat cushion to run it on the inside of the seat frame. Drop the string on the other side down to the floor.

## **MISSION ACCOMPLISHED**

