

It's not rocket science,
but following these
instructions will make
installing your seat covers
a lot easier.

We promise.

PART:	E82237
PRODUCT:	CAT WHEEL LOADER SEAT COVER
PIECES:	(1) BACK
	(1) BOTTOM
	(1) HEADREST



*Basically, you break it, we buy it.
Seriously.*

Your new seat covers are covered by a two-year, unconditional, no B.S. warranty.

That means that if you manage to abuse them to a point that they can't perform like they're supposed to within two years of when you bought them, we'll make it right. Depending on what is more practical, we'll either repair or replace the damaged cover.

General care instructions:

1. In most cases dirt, debris, spills and pet hair can be removed by wiping with a damp cloth.
2. Seat covers can be removed and machine washed on low temperature setting using mild detergent.
Drip dry or machine tumble dry on a no heat cycle.
Straps should be coiled and secured with rubber bands for machine washing and drying.
3. Soil may be removed with spray cleaner or detergent and water.
4. Oil or grease stains should first be treated with a dry cleaning solvent followed by a spray cleaner or detergent and water.
5. Do not use bleach.

Install Seat Cover

SEAT DOES NOT NEED TO BE REMOVED FROM EQUIPMENT

Undo all velcro on the seat back. With the three velcro tabs down the front of the seat, work over headrest and down seat back.



Pull tight and secure to the velcro on the back of the seat.

Make sure the knob on the back of the seat is exposed.




Pull headrest on with flaps down the front.

Secure the velcro tabs at the top of the seat back.



Fasten flaps inside the back of the headrest.

Push the flaps between the seat back and bottom.



Place seat bottom cover over seat bottom with the adjustment buttons coming through the gap in the cover.

CALL US AT 507.246.3545. FOR INSTALLATION ASSISTANCE

Install Seat Cover

Push flap between seat back and bottom from the front.

Pull tight from the back and secure to the velcro.



Finished!!

