

It's not rocket science,
but following these
instructions will make
installing your seat covers
a lot easier.

We promise.

PART:	E82240
PRODUCT:	KUBOTA U17, U25S EXCAVATOR SEAT COVER
PIECES:	(1) SEAT BACK COVER (1) SEAT BOTTOM COVER (1) HEADREST COVER

LIFETIME WARRANTY

*Basically, you break it, we buy it.
Seriously.*

Your new seat covers are covered by an unconditional, no B.S. warranty.

That means that if you manage to abuse them to a point that they can't perform like they're suppose, we'll make it right. Depending on what is more practical, we'll either repair or replace the damaged cover.

This warranty only applies to the original purchaser.

General care instructions:

1. In most cases dirt, debris, spills and pet hair can be removed by wiping with a damp cloth.
2. Seat covers can be removed and machine washed on low temperature setting using mild detergent. Drip dry or machine tumble dry on a no heat cycle. Straps should be coiled and secured with rubber bands for machine washing and drying.
3. Soil may be removed with spray cleaner or detergent and water.
4. Oil or grease stains should first be treated with a dry cleaning solvent followed by a spray cleaner or detergent and water.
5. Do not use bleach.

Install Seat Cover

Start with the seat back cover.

Un-do all velcro and slide it over the headrest with the long tab towards the front.

Start from the side of the headrest as shown, rather than pulling directly down.



Make sure that the bar on the side of the seat comes through the cover as you work it down the seat back.

Push flap between seat back and bottom.

Turning the knob at the bottom of the seat clockwise to extend the seat will give more room. bottom.



Pull the flap at the bottom tight and secure behind the cover.

At the top, fasten the tabs below the headrests inside the cover.



Pull the seat bottom cover on.

Make sure that the cover is above the adjustment bar on the seat bottom.



Push the flap between the seat back and bottom.

Turn the knob clockwise to move the seat cushion forward to make it easier.

Tuck flaps on the side between the cushion and metal frame.



Pull flap tight and secure to the hook-and-loop at the back.



Put the headrest cover on. Starting on one side goes smoother than pulling straight down!



Fasten the headrest flaps inside the back of the headrest cover.



FINISHED!

