It's not rocket science, but following these instructions will make installing your seat covers a lot easier.

# We promise.

**PART: I U192504** 

PRODUCT: | 60/40 FRONT BENCH

FITMENT DETAILS: JD GATOR

PIECES: (1) 40 PORTION BACK
(1) 40 PORTION BOTTOM
(1) 60 PORTION BACK
(1) 60 PORTION BOTTOM

Seat Backs & Bottoms have tags signifying Driver or Passenger.

## LIFETIME WARRANTY

Basically, you break it, we buy it.

Seriously.

Your new seat covers are covered by an unconditional, no B.S. warranty.

That means that if you manage to abuse them to a point that they can't perform like they're supposed to, we'll make it right. Depending on what is more practical, we'll either repair or replace the damaged cover.

This warranty only applies to the original purchaser.

#### General care instructions:

- 1. In most cases dirt, debris, spills and pet hair can be removed by wiping with a damp cloth.
- 2. Seat covers can be removed and machine washed on low temperature setting using mild detergent. Drip dry or machine tumble dry on a no heat cycle. Straps should be coiled and secured with rubber bands for machine washing and drying.
- 3. Soil may be removed with spray cleaner or detergent and water.
- 4. Oil or grease stains should first be treated with a dry cleaning solvent followed by a spray cleaner or detergent and water.
- 5. Do not use bleach.

## **Install Seat Cover**

page 1

These are your seats.

Let's cover 'em.





Pull the tabs in on either side and secure tightly as shown.

Place the driver's bottom cover on the driver's seat bottom. The long flap should be down the front.





Turn the seat back portion partway inside out.

Slide over the seat as shown (Tag should face the door)

Tip the seat forward as shown.





Make sure the cover is snug against the top of the seat, then unroll the cover the rest of the way down the seat back.

Run the flap through the gap where the seat hinges.

Pull tight and secure the tab to the tab at the back of the seat.





Pull the tabs tight and fasten at the back.

### **Install Seat Cover**

page 2

Place the seat bottom cover over the seat bottom with the long flaps towards the front.

Pull the cover over the corners and make sure everything is lined up.





Turn the seatback halfway inside out, and work over the seat back.

Make sure the cover is properly aligned, and the top is snug before proceeding.

Flip the seat up. Pull the short flaps so the cutouts line up with the three ruber bumpers.





Unroll the cover the rest of the way down the seat.

As you work it down the sides and front, it should bring the tabs behind the seat down along with it.

Pull the long flaps between the seat back and bottom.

Tipping the seat bottom at a 45\* angle gives you the most working room to get these through.





Last step - secure the flaps.

Tipping the seat bottom up will give you the most amount of working room.

Reach up behind the seat to bring the flaps the rest of the way down, and secure them to the flaps from the front.

Pull long flaps tight and secure them to the short flaps.





You're finished!