Singer 29-4

Form 8952, Revised (538)
Printed in U. S. A.

LIST SEPARTS



FOR FAMILY SHOPS

MACHINE No. 29-4

THE SINGER MANUFACTURING COMPANY

INSTRUCTIONS FOR OILING

To ensure easy running and prevent unnecessary wear of the parts which are in movable contact, the machine requires oiling and when in continuous use, "TYPE B" or "TYPE D" OIL, sold only by Singer Sewing Machine Company, should be applied at least twice each day to all oil holes marked "OIL", as instructed in Form 8166°

INDEX

	Lake
Accessories	 . 10
Bobbin Winders	 . 10
Machine No. 29-4	 . 5
Numerical List of Parts	 . 13
Obsolete Parts	 . 11

Copyright, U. S. A., 1918, 1923 and 1938 by The Singer Manufacturing Co. All Rights Reserved for all Countries

INSTRUCTIONS FOR ORDERING

In ordering from this list, use ONLY the part NUMBER in the FIRST Column.

The number stamped on a Sewing Machine Part is in every case the number of the single part only.

Every combination of parts sent out as such has its specific number, which, although not stamped on the parts, must be used when ordering the combination.

Each number always indicates the SAME PART in whatever list it appears, or for whatever machine.

The letters after some of the numbers indicate the style of finish only, as follows:

A-Hardened, Polished, Nickel Plated and Buffed.

A.A-Buffed and Chromium Plated.

A.B-Hardened, Polished, Buffed and Chromium Plated.

A.C-Brown Baking Ename! Finish.

A.D-Gray Baking Enamel Finish.

A.E-Hardened, Bright Rumbled and Nickel Plated.

A.F.-Hardened, Bright Rumbled, Nickel Plated, Bright Rumbled and Chromium Plated.

A.G-Alumilite, Plain.

A.H-Alumilite Dyed.

A.J-Polished, Nickel Plated and Chromium Plated.

A.K-Hardened, Polished, Nickel Plated and Chromium Plated.

A.L-Heat Treated for Toughness.

B-Polished, Nickel Plated and Buffed.

C-Hardened only.

C.R-Hardened and Merlized.

D-Polished Only.

E-Soft, Not Polished.

F-Hardened and Polished.

F.J-Hardened, Polished and Nickel Plated.

G-Bright Rumbled and Nickel Plated.

H-Blued.

J-Nickel Plated Only.

K-Hardened and Nickel Plated.

L-Brass Plated.

M-Oxidized.

N-Japanned, Dull.

P-Japanned, Bright.

P.P-Wrinkle Finish.

R-Merlized.

S-Cadmium Plated.

T-Copper Plated.

T.A-Hardened, Polished, Copper and Nickel Plated and Buffed.

T.B-Copper and Nickel Plated and Polished.

T.J-Copper and Nickel Plated Only.

T.K-Hardened, Copper and Nickel Plated.

T.i.-Copper and Brass Plated.

T.M-Copper Plated and Oxidized.

U-Zinc Plated.

V-Silver Plated.

W-Polished and Nickel Plated.

X-Black Oxide, for Iron and Steel.

X.C-Hardened and Black Oxide, for Iron and Steel.

Y-Black Nickel Plated Only.

Z-Chromium Plated.

Z.A-Hardened, Polished, Nickel Plated, Buffed and Chromium Plated.

Z.B-Polished, Nickel Plated, Buffed and Chromium Plated.

Z.C-Hardened and Chromium Plated:

Z.D-Polished and Chromium Plated.

Z.G-Bright Rumbled, Nickel Plated, Bright Rumbled and Chromium Plated.

Z.J-Nickel and Chromium Plated.

Z.T-Copper and Chromium Plated.

These letters MUST BE USED when they appear in the list; and AFTER the number as in the list.

In this series:

i to 1500, 50001 to 51500 and 140001 to 142000 are Screw Numbers.

1501 to 1800 and 51501 to 5!800 are Nut Numbers.

1801 to 2000 and 51801 to 52000 are Roller Numbers.


 $2001\ \ \, {
m to}\ \ \, 50000\ \ \, {
m and}\ \, 52001\ \ \, {
m to}\ \ \, 140000\ \ \, {
m and}\ \, 142001\ \ \, {
m to}\ \, 190000$

are Sewing Machine Parts, 190001 and upward are numbers of Electrical Parts.

The figures in the second column refer only to the plates, illustrating the parts, and are NOT TO BE USED in ordering.

Parts marked with an asterisk (*) are furnished only when repairs are made at factory.

LIST OF PARTS COMPLETE FOR



MACHINE No. 29-4

For Shoe Repairing, Putting in Gores, etc. Needle descends 1/8 inch from end of lower arm which is I inch deep and I inch across. Has upper feed only, which moves the work in any desired direction.

No.	Plate	•		****	Name	15404		
*8672 118E	7742	AIM #	OI	Machine				
	7742							
4288	1044		77				(back).	
51224W	7742	,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,	R		**	Ħ	m	Thumb
			Sc	rew		• • • • • •		
8673	1044	Arm	٥f	Machine	Side	Cover		 .
207D	1045	n	#	•	m	**	#	Screw

Ma	Plate	Name			No.	Plate	Name
No.		Balance Wheel with two 4450	•		128E	7742	Leg Screw
8674	1042	" Set Screw			9331	1045	" " Washer
445C	7742				8671	1045	Lifter
8659	1045	Check Lever			66 F	1045	" Bearing Screw
8554	1045	" Joint Pin	•	•	*8686	1040	Lower Arm and Bed
8555	1045	phring				1048	" " Dowel Pin
219D	1045	" " Screw			8582		Needle Bar
14026	1045	" " Steady Pin			8655	1043	" " Cam and Pulley Wheel (two
8559	1032	Feed Motion Bell Crank Lever			33514	1042	• • • • • • • • • • • • • • • • • • • •
194E	7742	" " " " Joint Screw					speed) 2 7/8 in.and 4 7/8 in.diam.,
8660	1043	" Cam Wheel with 33523					with 1299C
2117	1048	" " " Pin			3012	1048	Needle Bar Cam and Pulley Wheel Pin
8562	1043	" Ring Slide Bar with 1816			1299C	7742	" " " " " Set
1816	7742	" " " " Cam Roller					Screw
1010	, , 120	and Stud			8662	1042	Needle Bar Driving Lever with 1801 and
855 6	1046	Feeding Foot					14026
		" " (narrow fork, coarse)			1801	7742	Needle Bar Driving Lever Cam Roller and
8558	1046	" " (narrow fork, fine)					Stud
8557	1046	•	•	•	8586	1048	Needle Bar Driving Lever Joint Pin
193F	1045	* * Screw			8687	1045	" Needle Regulating Clamp with
8685	1043	Foot Bar			0001	1010	237F
8569	1048	uruge tra			19 3F	1045	Needle Bar Needle Regulating Clamp
8564	1030	* * Revolving Joint			1905	1040	Screw
8694	1030	" " " Bearing			0500	1070	Needle Bar Piston Joint
8566	1030	Foot Bar Revolving Joint Bearing com-			8588	1032	" " Pin
		plete, Nos. 8564, 8571 and 8694			8589	1048	
* 8567	1030	Foot Bar Revolving Joint Guide Plate			8656	1045	" Thread Retaining Spring
8568	1030				SS133D	7742	DCI C#
		Rivet			ີ 8590	1044	" Threading Wire
*857 0	1030	Foot Bar Revolving Joint Slide Rod	•	•	8693		Needle Bar complete, Nos.193F,8655,8656
33527		* * * * * * * 8570					8687 and two SS133D
		with 8567 and two 8568			33519		Needle Bar 8693 with 8588 and 8589
8571	1030	Foot Ber Revolving Joint Washer	4		237 F	1045	" Clamping Screw
8565	1030	Foot Bar Revolving Joint complete, Nos.			8591	1032	* Plate
0000		8566 and 33527			8592	1032	" " (broad end)
33520		Foot Bar Revolving Joint 8565 with 8569			8 4 J	7742	" " Bearing Screw
*8676		Head of Arm			8593	1047	" Catch Pin
*33524		" " 8676 with 41D,66F,193F,288D,			8594	1032	" " " Spring
#3000#		8556,8559,8562,8573 to 8577,8615,			2020	1045	" " " Screw
		8616, 8620, 8624, 8671, 8685,33519,			8595	1047	" " " " Stud
					8670	1044	011 Cup with 8597 and 8695
		33520,33525 and two each 152F,194E,			8695	1047	" * Oil Pad (felt)Per 100
1000	0040	202F and 207F			327D	7742	" Screw
128E	7742	Head of Arm Binding Screw			8 5 97	1032	" " Spring
8573	1043	Revolving Bush					Pinion Cover Plate
8574	1045	Filecton opting			8688	1047	" " Screw
8575	1045	H H H Pin			393E	1047	JCI CW.,
207 F	1045	" " " Screw	•	•	8689	1047	Rack
85 76	1043	" " " Handle			8690	1042	" Connecting Rod
152 F	7742	" " Screw			8601	1048	Reel Pin
8577	1045	" " Supporting Washer			11241	1032	" " Washer (cloth)Per 100
202 F	1045	· н н н н	ŕ		33515	1042	Shaft
		Screw					

No.	Plate	Name
*33521		Shaft 33515 with 8660 and 33516
*33517		" Bushing (front)
.8604	1047	Shuttle Bobbin
*8654	-,	" Body
662E	1047	Tension Regulating Screw
8611	1047	" Spring
8603	1047	Shuttle complete, Nos. 662E, 8604,8611,
		and 8654
8605	1047	Shuttle Carrier with 241D and 8610
33526	` 	" 8605 with 33513
33512	1047	" " Driving Pinion with two
		238D
33513	1047	Shuttle Carrier Driving Pinion with
		13350
8607	1047	Shuttle Carrier Driving Pinion Bushing.
1335C	1047	" " Screw Pin
238D	1047	" " " Set Screw
8692	1047	" Following Pinion
8609	1047	" " " " Stud
8610	1047	" " Spring
241D	1047	" Screw
33516	1044	" Driving Cam with 1299C
3012	1048	" " Pin
1808	7742	" " Roller and Stud
1299C	7742	"
8613	1044	" Lever with 1808 and 9614
7D	7742	" " Bearing Screw
8614	1048	" " Stud
2269	1048	" " " Pin
8615	1045	Stitch Regulator
5616	1045	" " Gib
286D	1045	" Thumb Screw
8617	104ϵ	Tension Cup (release)
5618	1046	" Disc
8879	1032	" " Washer (cloth)
156CD	1046	" Regulating Thumb Nut
8619	1046	" Spring
663E	1046	" Stud
33522		" " 668E with 1560D
33525		Tension complete, Nos.8617, 8619, 8879,
		33522 and two 9618
8620	1046	Thread Eyelet (head of arm)
207 F	1045	" Screw
8621	1043	Vibrating Presser Lifting Lever
41D	7742	" " Screw
8624	1046	" Regulating Lever
515R	1046	" "Clamp-
		ing Screw
8568	1030	Vibrating Presser Regulating Lever
		Clamping Screw Rivet

No.	Plate	Name
410	7742	Vibrating Presser Regulating Lever
8625	1046	Vibrating Presser Regulating Lever Slide Block
+33 518		Vibrating Presser Regulating Lever Slide Block 8625 with 515R and 8626
8626	1046	Vibrating Presser Regulating Lever Slide Block Washer
1879	1045	Vibrating Presser Roller
8623	1045	" " Pin
33523		" " " 8623 with
		1879
8627	1043	Vibrating Presser Spring (flat)
274J	7742	" " " Screw
1539J	1048	" " " Lock Nut
*15404		Trade Mark
15405		" " Rivet

SINGER Needles should be used in SINGER Machines. These Needles and their Containers are marked with the Company's Trade-Mark "SIMANCO.**" 1

Needles in Containers marked
"FOR SINGER MACHINES"
are NOT **SINGER** made needles. 2

BOBBIN WINDER	
---------------	--

•	_	^	_	_	$\overline{}$	$\overline{}$	\mathbf{r}		~
Α	C	L	Ł	5	5	U	K	۱Ŀ	:5

No.	Plate	Name
36569	1050	Oiler with 36571
36570		" 36569, filled with oil
36571	1050	* Spout, 1 3/4 in. long, with 36807
36807	1048	<pre>" " Washer (leather)</pre>
26026	1050	Screw Driver (large)
26485	1050	" (small)

BOBBIN WINDERS

BOBBIN WINDER

No.	Plate	Name
8684	1050	Eccentric
51224W	7742	* Thumb Screw
8683	1050	Frame
128D	7742	" Screw
2460	1050	Friction Ring (rubber)
2461	1050	Pulley
8651	1050	Spindle
8682	1050	Bobbin Winder complete, Nos. 2460,2461, 8651, 8683, 8684 and 51224W

BOBBIN WINDER

(SWINGING AUTOMATIC, RIGHT HAND)

No.	Plate	Name
27540	2211	Base
27302	2211	Frame
50356D	7742	* Hinge Screw
1620J	1048	*
27303	1048	* Spring
27541	2211	Pulley
27695	2211	Spindle
27306	2211	Spool Pin
27307	2211	* Stand
27308	2211	Spool Stand complete, Nos. 418E, 1562J,
		2106, 10141, 11241, 27306,27307 and
		two each 2455 and wood screws 1 in.
		No. 10
11241	2211	Spool washer (cloth)Per 100
27696	2211	Stop Latch

No.	Plate	Name
35D	7742	Stop Latch Hinge Screw
2455	1046	Tension Disc
1562J	1046	" Regulating Thumb Nut
418E	1046	* Screw Stud
10141	1046	" Spring
2106	1046	* Thread Guide
27697	2211	Bobbin Winder, Nos. 35D, 1620J, 27302, 27303, 27540, 27541, 27695, 27696, 50356D and two wood screws 1 in.No. 7
27698		Bobbin Winder (swinging automatic, right hand) complete, Nos. 27308 and 27697

OBSOLETE PARTS

No.	Plate	Name
286D	7742	Arm of Machine Side Cover (back) Thumb
286D	7742	Bobbin Winder Eccentric Thumb Screw for 8682
8661	1042	Needle Bar Cam and Pulley Wheel (two speed) 2 7/8 in. and 4 7/3 in.diam., with 361D for 8678
361D	1048	Needle Bar Cam and Pulley Wheel Set
5 90B	1045	Needle Bar Thread Retaining Spring Screw for 8693
8678	1042	Shaft
*44 49		* Bushing (front)
8691	1047	Shuttle Carrier Driving Pinion with 6270
627C	1047	Shuttle Carrier Driving Pinion Screw Pin
8664	1044	Shuttle Driving Cam with 361D
361D	1048	" " Set Screw

SINGER Needles should be used in SINGER Machines. These Needles and their Containers are marked with the Company's Trade-Mark "SIMANCO.**"

Needles in Containers marked
"FOR SINGER MACHINES"
are NOT **SINGER** made needles. 2

NUMERICAL LIST OF PARTS

No.	Plate	Name
7D	7742	Shuttle Driving Lever Bearing
		Screw
35D	7742	Bobbin Winder Stop Latch Hinge Screw for 27697
41D	7742	Vibrating Presser Lifting Lever
41D	7742	Screw Vibrating Presser Regulating Lever Screw for 33524
66 F	1045	Lifter Bearing Screw for 33524
8 4 J	7742	Needle Plate Bearing Screw
118E	7742	Arm of Machine Base Screw
128D	7742	Bobbin Winder Frame Screw for
128E	7742	8682 Head of Arm Binding Screw
128E	7742	Leg Compa
SS133D	7742	Leg Screw Needle Bar Thread Retaining
001002	774	Spring Screw for 8693
152 F	7742	Head Revolving Bush Handle Screw
		for 33524
193F	1045	Feeding Foot Screw for 33524
193F	1045	Needle Bar Needle Regulating
		Clamp Screw for 8693
194E	7742	Feed Motion Bell Crank Lever
		Joint Screw for 33524
202 F	1045	Head Revolving Bush Supporting
		Washer Screw for 33524
202D	1045	Needle Plate Catch Pin Spring
		Screw
207D	1045	Arm of Machine Side Cover (front) Screw
207F	1045	Head Revolving Bush. Friction
		Spring Screw for 33524
207 F	1045	Thread Eyelet Screw for 33524
219D	1045	Check Lever Spring Screw
237 F	1045	Needle Clamping Screw for 8687
238D	1047	Shuttle Carrier Driving Pinion
		Set Screw for 33512
241D	1047	Shuttle Carrier Spring Screw for
		8605
274J	7742	Vibrating Presser Spring Screw
286D	7742	Arm of Machine Side Cover (back)
		Thumb Screw, obsolete
286D	7742	Bobbin Winder Eccentric Thumb
		. Screw for 8682, obsolete

No.	Plate	Name
288D	1045	Stitch Regulator Thumb Screw for
		33524
327D	7742	Oil Cup Screw
361D	1048	Needle Bar Cam and Pulley Wheel
		Set Screw for 8661, obsolete.
361D	1048	Shuttle Driving Cam Set Screw for
		8664, obsolete
393E	1047	Pinion Cover Plate Screw
418E	1046	Bobbin Winder Tension Screw Stud
		for 27308
445C	7742	Balance Wheel Set Screw for 8674.
515R	1046	Vibrating Presser Regulating
		Lever Clamping Screw for
		33518
5 90B	1045	Needle Bar Thread Retaining
		Spring Screw for 8693, obso-
		lete
627C	1047	Shuttle Carrier Driving Pinion
		Serew Pin for 8691, obsolete.
662E	1047	Shuttle Tension Regulating Screw
14		for 8603
668E	1046	Tension Stud for 33522
1299C	7742	Needle Bar Cam and Pulley Wheel
		Pin Set Screw for 33514
1299C	7742	Shuttle Driving Cam Set Screw for
		33516
1335C	1047	Shuttle Carrier Driving Pinion
		Screw Pin for 33513
1539 J	1048	Vibrating Presser Spring Screw
		Lock Nut
1560D	1046	Tension Regulating Thumb Nut for
5		33522
1562 <i>J</i>	1046	Bobbin Winder Tension Regulating
		Thumb Nut for 27308
1620J	1048	Bobbin Winder Frame Hinge Screw
		Nut for 27697
1801	7742	Needle Bar Driving Lever Cam
		Roller and Stud for 8662
1808	7742	Shuttle Driving Cam Roller and
		Stud for 8613
1816	7742	Feed Motion Ring Slide Bar Cam
		Roller and Stud for 8562
1879	1045	Vibrating Presser Roller for
		33523
2106	1046	Bobbin Winder Tension Thread
		Guide for 27308
2117	1048	Feed Motion Cam Wheel Pin
2269	1048	Shuttle Driving Lever Stud Pin
2455	1046	Bobbin Winder Tension Disc for
		27308

No.	Plate	Name
2460	1050	Bobbin Winder Friction Ring (rub-
		ber) for 8682
2461	1050	Bobbin Winder Pulley for 8682
3012	1048	Needle Bar Cam and Pulley Wheel
		Pin
3012	1048	Shuttle Driving Cam Pin
4288	1044	Arm of Machine Side Cover (back).
4444 9		Shaft Bushing (front) obsolete
8554	1045	Check Lever Joint Pin
8555	1045	" " Spring
8556	1046	Feeding Foot for 33524
8557	1046	" " (narrow fork, fine).
8558	1046	" (narrow fork, coarse)
8559	1032	Feed Motion Bell Crank Lever for
		33524
8562	1043	Feed Motion Ring Slide Bar with
		1816, for 33524
8564	1030	Foot Bar Revolving Joint for 8566
8565	1030	Foot Bar Revolving Joint complete
		for 33520, Nos.8566 and 33527
8566	1030	Foot Bar Revolving Joint Bearing
		complete for 8565, Nos. 8564,
		8571 and 8694
* 8567	1030	Foot Bar Revolving Joint Guide
		Plate for 33527
85 6 8	1030	Foot Bar Revolving Joint Guide
		Plate Rivet for 33527
8 56 8	1030	Vibrating Presser Regulating
		Lever Clamping Screw Rivet
		for 33527
8569	1048 ′	Foot Bar Hinge Pin for 33520
* 8570	1030	" Revolving Joint Slide Rod
		for 33527
8571	1030	Foot Bar Revolving Joint Washer
		for 8566
8573	1043	Head Revolving Bush for 33524
8574	1045	" " Friction Spring
		for 33524
8575	1045	Head Revolving Bush Friction
		Spring Pin for 33524
8576	1043	Head Revolving Bush Handle for
		33524
8577	1045	Head Revolving Bush Supporting
0500	1010	Washer for 33524
8582	1048	Lower Arm and Bed Dowel Pin
8586	1048	Needle Bar Driving Lever Joint
DEGG	1070	Pin
8588 8589	1032	Needle Bar Piston Joint for 33519
0009	1048	" " Pin for
		33519

		••
No.	Plate	Name
8590	1044	Needle Bar Threading Wire
8591	1032	LTGOOTTO
8592	1032	foroad ond,
8593	1047	" Catch Pin
8594	1032	obi ing
8595	- 1047	* * * * * Stud
8597	1032	Oil Cup Spring for 8670
8601	1048	Reel Pin
8603	1047	Shuttle complete, Nos. 662E,8604,
		8611 and 8654
8604	1047	Shuttle Bobbin for 8603
8605	1047	" Carrier with 241D and
		8610 for 33526
8607	1047	Shuttle Carrier Driving Pinion
		Bushing
8609	1047	Shuttle Carrier Following Pinion
		Stud
8610	1047	Shuttle Carrier Spring for 8605
8611	1047	Tension Spring for 8603
8613	1044	Driving Lever with 1808
0010	24	and 8614
8614	1048	Shuttle Driving Lever Stud for
001-	1010	8613
8615	1045	Stitch Regulator for 33524
		" " Gib for 33524
8616	1045	Tension Cup (release) for 33525
8617	1046	* Disc for 33525
8618	1046 h	" Spring for 33525
8619	1046	Thread Eyelet (head of arm) for
8620	1046	33524
		Vibrating Presser Lifting Lever
8621	1043	" Roller Pin for
8623	1045	
		33523
8624	1046	Vibrating Presser Regulating
		Lever for 33524 Vibrating Presser Regulating
8625	1046	Lever Slide Block for 33518.
		Laver Singe Block for Socio.
8626	1046	Vibrating Presser Regulating Lever Slide Block Washer for
	-	33518
8627	1043	Vibrating Presser Spring (flat).
8651	1050	Bobbin Winder Spindle for 8682
*8654		Shuttle Body for 8603
8655	1043	Needle Bar for 8693
8656	1045	* Thread Retaining Sprin
		for 8693
8659	1045	Check Lever
8660	1043	Feed Motion Cam Wheel with 3352
		for 33521

No.	Plate	Name
8661	1042	Needle Bar Cam and Pulley Wheel
		(two speed) 2 7/8 in. and
		4 7/8 in.diam., with 361D, for
		8678, obsolete
8662	1042	Needle Bar Driving Lever with
0002	1010	1801 and 14026
8664	1044	Shuttle Driving Cam with 361D,ob-
0004	1011	solete
8670	1044	011 Cup with 8597 and 8695
8671	1045	Lifter for 33524
*8672	1040	Arm of Machine with 15404 and two
#007£		15405
8673	1044	Arm of Machine Side Cover (front)
8674	1042	Balance Wheel with two 445C
*8676	1042	Head of Arm for 33524
8678	1042	Shaft, obsolete
		•
8682	1050	Bobbin Winder complete, Nos.2460, 2461, 8651, 8683, 8684 and
0007	1050	51224W
8683	1050	" " Eccentric for 8682.
8684	1050	Eccondition for adox.
8685	1043	Foot Bar for 33524
*8686	1045	Lower Arm and Bed
8687	1045	Needle Bar Needle Regulating
0000	3047	Clamp with 237F, for 8693
8688 8689	1047 1047	Pinion Cover Plate
8690	1047	Rack
8691	1042	" Connecting Rod Shuttle Carrier Driving, Pinion
0091	1047	
8692	1047	with 627C, obsolete
	1047	-
8693		Needle Bar complete for 33519, Nos. 193F, 8655, 8656, 8687 and two
0004	1070	SS133D
8694	1030	Foot Bar Revolving Joint Bearing
0000	3040	for 8566
8695	1047	Oil Cup Oil Pad (felt) for 8670
0070	1032	Per 100 Tension Disc Washer (cloth) for
8879	1032	33525
9331	1045	Leg Screw Washer
10141	1046	Bobbin Winder Tension Spring for
10141	1046	27308
11241	2211	Bobbin Winder Spool Washer (cloth)
		for 27308Per 100
11241	1032	Reel Pin Washer (cloth)Per 100
14026	1045	Check Lever Spring Steady Pin for
		8662
+15404		Trade Mark for 8672



NUMERICAL LIST OF PARTS

***	1	
No.	Plate	Name
15405		Trade Mark Rivet for 8672
26026	1050	Screw Driver, large (Accessories)
26485	1050	" " small (Accessories)
27302	2211	Bobbin Winder Frame for 27697
27303	1048	" " Spring for
		27697'
27306	2211	Bobbin Winder Spool Pin for 27308
27307	2211	" " Stand for 27308
27308	2211	Bobbin Winder Spool Stand com-
		plete for 27698, Nos. 418E.
		1562J,2106,10141,11241,27306,
		27307 and two each 2455 and
		wood screws 1 in. No. 10
27540	2211	Bobbin Winder Base for 27697
27541	2211	" Pulley for 27697
27695	2211	" " Spindle for 27697
27696	2211	" Stop Latch for 27697
27697	2211	Bobbin Winder for 27698, Nos.35D,
		1620J,27302,27303,27540,27541,
		27695, 27696,50356D and two
		wood screws 1 in. No. 7
27698		Bobbin Winder (swinging automatic,
		right hand)complete, Nos. 27308
		and 27697
33512	1047	Shuttle Carrier Driving Pinion
		with two 238D
33513	1047	Shuttle Carrier Driving Pinion
		with 1335C for 33526
33514	1042	Needle Bar Cam and Pulley Wheel
		(two speed)2 7/8 in.and 4 7/8
		in.diam., with 1299C
33515	1042	Shaft for 33521
33516	1044	Shuttle Driving Cam with 1299C
		for 33521
*33517		Shuttle Bushing (front)
*33 518		Vibrating Presser Regulating
		Lever Slide Block 8625 with
	• •	515R and 8626
33519		Needle Bar 8693 with 8588 and
		8589, for 33524
33520		Foot Bar Revolving Joint 8565
		with 8569, for 33524
33521		Shaft 33515 with 8660 and 33516
33522		Tension Stud 668E with 1560D, for
		33525
33523		Vibrating Presser Roller Pin 8623
		with 1879, for 8660

No.	Plate	Name
+33524		Head of Arm 8676 with 41D, 66F,
		19 3F , 288D, 8556, 8559, 8562,
		8573 to 8577,8615,8616,8620,
		8624,8671,8685,33519,33520,
		33525 and two each 152F,194E,
		202F and 207F
33 525		Tension complete for 33524, Nos.
		8617,8619,8879,33522 and two
		8618
33526		Shuttle Carrier 8605 with 33513
33527		Foot Bar Revolving Joint Slide
		Rod 8570 with 8567 and two
		8568, for 8565
36569	1050	Oiler with 36571, for 36570
36570		" 36569, filled with oil (Ac-
		cessories)
36571	1050	Oiler Spout, 1 3/4 in. long, with
		36807, for 36569
36807	1048	Oiler Spout Washer (leather) for
		36571
50356D	7742	Bobbin Winder Frame Hinge Screw
		for 27697
51224W	7742	Arm of Machine Side Cover (back)
		Thumb Screw
51224W	7742	Bobbin Winder Eccentric Thumb
		Screw for 8682

SINGER Needles should be used in SINGER Machines. These Needles and their Containers are marked with the Company's Trade-Mark "SIMANCO.**" 1

Needles in Containers marked
"FOR SINGER MACHINES"
are NOT **SINGER** made needles. 2

SINGER Needles should be used in SINGER Machines. These Needles and their Containers are marked with the Company's Trade-Mark "SIMANCO.**" 1

Needles in Containers marked
"FOR SINGER MACHINES"
are NOT **SINGER** made needles, 2

PLATE 1030 - FULL SIZE 8565 8571 8570 8564 8568 8566 8694

PLATE 1042 - ONE-FOURTH SIZE 8678 33515 8662

PLATE 1043 - ONE-HALF SIZE 8562 33543 8573 V 8576 82123

PLATE 1044 - ONE-HALF SIZE

PLATE 1045 - FULL SIZE 14026 219




PLATE 1047 - FULL SIZE 8611 662 8610 241 33513 1335




PLATE 1050 - ONE-HALF SIZE

PLATE 2211 - ONE-HALF SIZE

