

HomeTroller SEL Quick-Start Guide

Congratulations on your purchase! Your HomeTroller SEL is ready to put you in control of your home. Please take a few minutes to read through this guide to familiarize yourself with the steps required to set up your Z-Wave network and your HomeTroller.

STEP #1 – HomeTroller SEL Setup

To begin using HS3 you must setup your HomeTroller SEL. Follow these steps:

HomeTroller Hardware Installation

- a) Unpack the HomeTroller and AC power supply.
- b) Connect a monitor, mouse, and keyboard for initial set up. (The unit is also accessible remotely using VNC or find.homeseer.com)
- c) Connect an Ethernet cable to your HomeTroller and to a network port on your internet router.
- d) Connect the AC power adapter to your HomeTroller to begin the boot process. Turn on the HomeTroller on and allow the unit to boot fully.



Accessing the HomeTroller Web Interface

Once the hardware is set up you will want to access the web interface to set up HS3. Please skip to Step 2 to access the HomeTroller remotely if you do not have a monitor and keyboard set up with the SEL.

The method below should work with any browser on any device (mobile or desktop).

- a) Navigate to <http://find.homeseer.com>
- b) Click the “Search” button. Your HomeSeer system should now appear at the bottom.
- c) Click the IP address hyperlink to access your system’s web interface.



Set Your System Password

The system password screen will appear the first time you run your HomeTroller SEL. **You MUST set a system password to prevent unauthorized access to your unit.** Please do this now by following the prompts on your screen.

Activate and Register Your HomeTroller SEL Online

Be sure to activate your HomeTroller SEL and register the unit to receive HomeSeer support. To do this, make sure that your unit is connected to the internet and follow these steps:

- a) From the HomeTroller SEL web interface, use the pull down menus to navigate to the General Tab of the Setup Area (TOOLS > Setup)
- b) Click the “Register Online” button in the License section of the Setup screen and enter your license codes.

Note: License codes are included on a sticker on the bottom of your HomeTroller SEL.

Registering your HomeTroller

You must register your unit to allow HS3 to boot up fully and automatically every time a restart occurs. Your licenseID and password is located on the bottom of the unit.

- a) Go to the Tools dropdown navigation at the top and click on Setup.
- b) Once the setup page loads, at the very top there is a License section. Click Register Online.
- c) Enter your License ID and Password located on the bottom of the unit.
- d) Once completed fill out the form and proceed to your next step.

Changing the Username and Password for HS3 Users

The default username is: *default* and the default password is: *default*. It is highly recommended that you change the username and password to something more secure. Please make sure to save this information.

- a) Go to the Tools menu and click Setup.
- b) Click on the Network tab at the top and you will see a list under Web User Settings.
- c) Enter a User Name and Password in to the respected fields and then choose the User Rights.
- d) Click Add User once all fields have been completed. Click Delete to remove a User.

Updating Your HomeTroller SEL and Setting the Time Zone

Be sure to check for updates and install any that are available and set the time zone. To do this, follow these steps:

- a) Upon HomeSeer booting it will check for updates.
- b) You can either restart your HomeTroller or just restart HS3.
- c) HomeSeer needs to be shut down once the update procedure begins.
- d) Double click on the time in the bottom right of your screen in the system tray and then click *Change Time Zone*.

Configuring the Wi-Fi Adapter

Wi-Fi is included with your SEL, follow these instructions for setting it up: (*You must have HS set up with the Ethernet cable first*)

- a) Access the Network Tab of the Setup section. Locate the Wi-Fi Settings section.
- b) Enter the SSID (Wi-Fi network name) of your Wi-Fi. (This is case sensitive)
- c) Choose your encryption type and enter your Wi-Fi password. Keep 'Use DHCP' checked.
- d) Go to Tools->System->Shutdown System. Once the system is shutdown. Unplug the power and then the Ethernet cable. Now reconnect the power and let the system boot.
- e) If you go to find.homeseer.com now, it should show another HomeTroller SEL. This is your new IP address and are all set to use the Wi-Fi adapter.

STEP #2 – Local/Remote Remote Access

MyHS Remote is a free remote tool that will allow you to access the HS3 interface of the HomeTroller from any remote computer via home network (LAN) or the internet (WAN). The HomeTroller can also be accessed locally via IP address and/or computer name. See below for instructions.

Accessing Your HomeTroller Locally

HS3 can be accessed from any computer on the same local network just by typing in the IP Address (*i.e. 192.168.1.10*) of your HomeTroller. You can also access your HomeTroller by entering '*hometrollerSEL/*' into your address bar.

Using HomeSeer MyHS Remote Service

Welcome to the MyHomeSeer Remote. MyHS will allow you to access your HS3 system from anywhere without having to access your router. There are requirements for MyHS to work. HS3 must be version 3.0.0.81 or later. HSTouch Android client requires 1.0.0.76 or later. Please make sure to update to these versions. It is recommended



that you uninstall the application and then reinstall it from the Play Store/iTunes Store. (*This guide assumes you have HSTouch Server already set up. If you do not, please refer to the HS3 Quick Start Guide on setting that up*). Now, let's get started!

To begin using MyHSRemote you will need to register your HS3 software with the connected service.


Registration

- Once the HSTouch has finished installing, go ahead and open it up. You will be prompted with a Log In to MyHS screen.
- Click *Register*. Your default browser will come forward and load the registration page.
- Enter in the preferred email address you would like to use to be tied to your MyHS for the *Account Email Address*. This will later be used as your MyHS username.
- Enter a preferred *Account Password*. You will use this as the password to enter in your MyHS settings.
- The *License ID* you are asked for is your HS3 licenseID. The same goes for your *License Password*. (*For HomeTroller HS3 users, this is located on the bottom of your unit. For HS3 Software users, this information was emailed to you.*)
- Click *Register*. You will receive a confirmation on the next screen unless errors are detected. You will also be emailed an email that requires a confirmation. Click the link in the email.

STEP #3 – Installing Plug-ins

HomeSeer works with many different protocols. All of these protocols require a plug-in to be installed. There are HomeSeer Tech plug-ins and many 3rd Party plug-ins. Please follow the instructions below on installing a plug-in or you can [click here](#) to watch a video tutorial.

- Locate the Plug-Ins drop down at the top of the screen. With that dropdown click *Manage*.
- Click the yellow circle to right of the *Additional Interfaces*. This will present you with a list of categories. Each category has a list of plug-ins that can be installed.
- Click on the circle next to the category that you wish to expand.



Register

Account Information

Account Email Address

Account Password

Confirm Account Password


HomeSeer System Information

License ID


License Password

Register

© 2014 - HomeSeer Technologies




4. Once you see the list of plug-ins, click the check box to the left of the plug-ins that you want to install. (You may check more than one at a time.)
5. After you have selected the plug-ins you wish to install, a *Download and Install* button will appear. Click this button to proceed with the install.
6. You will be given a progress bar under the *Installed Plug-ins* section indicating the status of the install.
7. You must now *Enable* your plug-ins to use them. Once they are enabled they will be available to configure. Some plug-ins will require you to enter a COM port before going into the configuration pages.
8. To get to the configuration pages, go back to the top where the plug-ins menu is and you will see a list of your installed plug-ins. Within each plug-in there is another menu that has a link to the configuration pages.



STEP #4 – Adding a Z-Wave Controller

In order to control Z-Wave devices, such as light switches, thermostats, door locks and sensors, they must be included into a Z-Wave “network”. Follow the steps below to add your Z-Wave controller and create a Z-Wave network. For a more visual walkthrough, [click here](#).

- a) Go to the Plug-ins drop down menu and hover over Z-Wave. Select Controller Management.
- b) Click the Add Interface button to begin the management process.
- c) You will now be prompted to add an interface name, interface type, and the COM port of the interface. A good naming scheme is either the name of the interface you are using or the location of your Z-Wave controller (if you have multiple). The interface type corresponds to the type of Z-Wave controller you are using. If you are using an IP2SL/WF2SL, select the Ethernet option.
- d) Go ahead and click *Add* and let HomeSeer initialize the unit. Once initialized, you will be brought to a new screen.
- e) You must now enable the controller. Click the red circle with a line through it (“No symbol”) to enable it. You will see a green checkmark if the interface enabled correctly.
- f) To add another Z-Wave interface simply follow these instructions again.



STEP #5 - Z-Wave Network Setup

In order to control Z-Wave devices, such as light switches, thermostats, door locks and sensors, they must be included into a Z-Wave “network”. Follow the steps below to create your Z-Wave network and to include devices. *Note: the steps below assume you’ve already physically installed Z-Wave devices in your home.*

Including Externally Powered Devices (wall switches, receptacles, plug-in modules, etc)

- a) Take your Z-Stick and put it into “inclusion mode” by pressing and releasing the large round button on one side. A blue LED light around the button will begin blinking slowly.
- b) While the Z-Stick is in inclusion mode, position it within 1-3 feet of your Z-Wave device. Now press the network button (or paddle) on your Z-Wave device and observe the blinking LED on the Z-Stick. If successful, the LED light will glow solidly for about 2 seconds and then will begin blinking slowly again. *Note: If the LED does not glow solidly, the device may need to be reset. Reset the device by following the procedure outlined in “Excluding Devices” below.*
- c) If you have other Z-Wave devices to add to your network, you may keep the Z-Stick in inclusion mode and add the remaining devices using the procedure above. Once you’re finished, tap the button on the Z-Stick again. The LED light will turn off and it will no longer be in inclusion mode.

Including Battery Powered Devices (door locks, environmental sensors, etc)

Battery operated devices must be included into your Z-Wave network using the HomeTroller web interface. Your Z-Wave Controller must be plugged into your HomeTroller while following these instructions. Follow the steps below to include your battery operated device(s). This is the recommended method for adding all devices and using the HomeSeer Z-Wave Controller.

- a) Position your battery operated Z-Wave device within 1-3 Feet of your HomeTroller.
- b) From the web interface, use the pull down menus to navigate to the Z-Wave Controller Management page (PLUG-INS > Z-Wave > Controller Management).
- c) Locate the “Z-Wave Interfaces” area and expand your Z-Wave Controller section. Open the “Actions:” menu and choose “Add/Include a Node”.
- d) Click the ‘Start’ button below the Actions menu. Your HomeTroller is now in inclusion mode and is ready to communicate with your battery operated device.
- e) Activate the network button (or button sequence) on your battery operated device and observe the inclusion process in the green log window. When done, you’ll receive an acknowledgement such as “Finished with Replication process”. Your battery operated device is now included in your Z-Wave network!

Excluding Devices

Follow the procedure below to (a) reset the device to its factory settings or (b) remove the device from your Z-Wave interface.

- a) From the web interface, use the pull down menus to navigate to the Z-Wave Controller Management page (PLUG-INS > Z-Wave > Controller Management).
- b) Locate the “Z-Wave Interfaces” area and expand your Z-Wave Controller section. Open the “Actions:” menu and choose “Remove/Exclude a Node”.
- c) Click the ‘Start’ button below the Actions menu. Your HomeTroller is now in inclusion mode and is ready to communicate with your battery operated device.
- d) Activate the network button (or button sequence) on your battery operated device and observe the inclusion process in the green log window. When done, you’ll receive an acknowledgement such as “Finished with Replication process”. Your battery operated device is now included in your Z-Wave network!

STEP #6 – Importing, Editing and Controlling Your Z-Wave Devices

After you've created your Z-Wave network, you'll need to import that network into your HomeTroller, so that your devices can be monitored and controlled. Here's how to do that:

Importing Z-Wave Devices

- From the web interface, use the pull down menus to navigate to the Z-Wave Controller Management page (PLUG-INS > Z-Wave > Controller Management).
- Locate the "Z-Wave Interfaces" area and expand the section of your Z-Wave Controller. Open the "Actions:" menu and choose "Import Node Info from Controller and Scan Devices".
- Click the 'Start' button below the Actions menu. Your HomeTroller will now import your device information from the Z-Stick. When done, you'll receive an acknowledgement such as "Finished with Z-Wave device synchronization". Your Z-Wave devices may now be monitored and controlled from the HomeTroller!

Editing and Controlling Your Z-Wave devices

- From the web interface, use the pull down menus to navigate to the Device Management Page (VIEW > Device Management). Click the "Show All" button in the upper right hand area of the page. A list of all your devices will now be displayed.
- To edit the name, location and other properties of any device, click the [Name](#).

Status	Category	Room	Name	Address	Type	Last Change	Control	
<input type="checkbox"/>	 No Status	Lighting	Kitchen	Motion Sensor Root	003D46CA-034	Z-Wave On/Off Sensor Root Device	Never_Set	
<input type="checkbox"/>	 100%	Lighting	Kitchen	Motion Sensor Battery	003D46CA-034-Q38	Z-Wave Battery	9/5/2013 5:18:28 PM	
<input type="checkbox"/>	 No Motion	Lighting	Kitchen	Motion Sensor	003D46CA-034-Q39	Z-Wave Sensor Binary	9/6/2013 5:58:33 PM	
<input type="checkbox"/>	 On	Lighting	Kitchen	Pannini Maker	003D46CA-036	Z-Wave Switch Binary	9/5/2013 8:56:48 AM	<input type="button" value="Off"/> <input type="button" value="On"/>
<input type="checkbox"/>	 On	Lighting	Kitchen	Light-Overhead	003D46CA-014	Z-Wave Switch Binary	Today 8:37:32 AM	<input type="button" value="Off"/> <input type="button" value="On"/>

- To control the device, use the buttons in the Control column.

STEP #7 – Z-Wave Device Configuration

With Z-Wave devices, configuration can be done for each device. There are also tools for failed communication with these devices as well. Follow these steps to

Configuring Device Settings

- From the web interface, go to your Device Management page and click on the device you wish to configure.
- Click on the Z-Wave tab.
- Here you can Rescan, Remove, Test, Optimize, and Audit the node. Associations can also be set here.
- Expanding the Settings section will allow you to change the wake-up interval for battery operated devices. Here you will also see many settings for different parameters depending on the device.

Functions

Settings

The device periodically sends notifications for its sensors. Set the interval as minutes (6-1500).
Note that shorter intervals will reduce battery life.

Wake Up Interval(minutes):

STEP #8 – Creating Automation Events

Simply put, an automation event consists of an action (or actions) that are set into motion by one or more triggers. Example: Turning on lights at sunset. Trigger = sunset, Action = turning lights on. With HomeSeer, you can quickly and easily create all the events you need. Here's how to create the sunset event above:

Creating Events

- From the web interface, use the pull down menus to navigate to the Events page (VIEW > Events).
- Change the event group name from “New Group” to “Lighting”.
- Now expand the “New Event” section and rename the new event to “Lights on at Sunset”
- In the shaded blue “Trigger” section, choose “The Time Is...” and then select “The Time is Sunset”
- If the shaded green “Actions” section, choose “Control a Device” and then select the device you wish to control and the method of control (on / off) you wish to use. See image above for resulting view.



STEP #9 – HSTouch Server Setup

After you have successfully connected to your Wi-Fi network, you must make sure HSTouch Server is properly set up before connecting the client to your HomeSeer system. Follow the instructions below to set up HSTouch Server.

- Go to the Plug-in's menu within your HomeSeer Web Control and click on *Manage*.
- If HSTouch Server is not installed follow these steps, otherwise skip to **step f**
- Click on *Additional Interfaces* to expand the plug-in updater.
- Scroll down to *User Interfaces* and expand that. Check the box next to *HomeSeer HSTouch Sever*.
- Scroll back up and click on *Download and Install*.
- Now that HSTouch Sever is installed, it must be enabled for mobile access. Underneath the Enable column, click on the red toggle. It should become green with a check mark in it.

Plug-In	Instance	Enable	COM Port	Version	Update	License
HSTouch Server			N/A	3.0.0.20	N/A	Licensed
Z-Wave			N/A	3.0.0.88	N/A	Licensed

- HSTouch Server is now enabled. You can now go into HSTouch on your device to configure HSTouch.

STEP #10 – HSTouch Client Setup

Here you will configure your settings and connect to your HomeSeer system to allow for control from your device. Follow the instructions below to set up the HSTouch Client.

For iOS, please go to your Settings App first.

- HSTouch will prompt you to select a server or settings. Click settings. (*The first launch will require an initial setup.*) A menu on the bottom right will pop up. Click Settings again. (*This menu can also be used to switch between servers, go to settings, or exit the app.*)
- Within the settings you are given multiple options. Servers 1-4 allow you to configure



- each server for different locations.
- Select the server you would like to have as your Home setup.
 - Configure a Label for that HomeSeer system. Click *Address* to enter the IP Address or Domain of the HomeSeer System.
 - Now that you have set up the connection address, go ahead and enter in your Username and Password for that server. **There is no need to change the port.**
 - You can follow steps **c-e** for the remaining 3 connections.
 - If you go back to the main settings screen, there are other options for setting up HSTouch.
 - Connection Mode allows you to choose a default connection for each time you start HSTouch. (*HSTouch will no longer prompt to choose a connection at the beginning.*)
 - Dim *Systembar* allows for the bottom systembar to be dimmed. *Font Scaling* allows for changing the scaling factor.
 - Auto Size* allows for auto-sizing of the project being used for your device. *Client Name* will allow you to change the name of your device's HSTouch Client. (For use with HSTouch Designer). *Zipcode* is used for weather.
 - Now that your Client has been set up, go back to the Main Screen and go to the settings menu on the bottom right. Click Exit. Now go to your app drawer and click HSTouch. This will allow for any changes to take place.
 - You are now ready to control your home via your device!

Server 1

Label
A label for this server.

Configuration File
Configuration file to use with this server.

Address
HomeSeer server IP address or host name.

Username
Username from HomeSeer web users screen.

Password
Password from HomeSeer web users screen.

Port
Port to use (advanced), do not change, default is 10200.

HSTouch

Connection Mode
Select which server to use on startup.

Dim Systembar
If checked, system bar at bottom of screen will be dimmed. (restart after change)

Font Scaling
Set the font scaling factor, 1.0=no scaling, 0=use scaling from project file. (restart after change)

Auto Size
If checked, screens will autosize to the screen. (restart after change)

Client Name
The name of this client

Setting Up MyHS Remote

The next step involves going into the HSTouch application and entering in your Account Username and Account Password.

- Open up the HSTouch application. It will give you the same prompt as earlier to Log In to MyHS.
- The email you used to register is your Username and the password you used will be used as the Password.
- Click Ok and HSTouch will now connect.
- HSTouch will now always connect through MyHS when launching. This will work from any location and any network.

Log In to MyHS

Username

Password

Register... Settings...

Cancel Ok

Icon Legend for HS3

This is a list of the icons that are found in HS3 with a description of their function.

Note : Some buttons are multi-functional.

ICON	DESCRIPTION
	Add / Delete
	Copy Event
	Standard Editing / Advanced Editing
	Toggle Edit Mode
	Enabled / Disabled
	Error communicating
	Expand / Collapse Section
	Marked Devices Shown/Header and Menus Shown – Marked Devices Hidden/Header and Menus Not Shown
	Access Log Settings
	Poll Devices for Status
	Reset Layout to Default
	Run Event
	Devices Ungrouped / Grouped
	Add a Keyword or Pair
	Group Conditions are used / not being used

**If you want to know what that button will do, just hover your cursor over the icon and small text will appear to provide definition.*

Trouble Shooting Your HomeTroller

All customers have lifetime support. Initially you have **30 Day Priority Phone Support** and after that you have support through our **Help Desk** (helpdesk.homeseer.com) and our community based **Message Board** (board.homeseer.com).

Symptom	Cause	Solution
Unit Won't Power On	Ac Adapter Unplugged	Plug-In Adapter
	AC Adapter Bad	Contact HomeSeer
	Power Cable Bad	
Unit Powers On But Won't Boot	USB Hardware Conflict	Detach USB Device And Reboot
	Software Failure	Contact HomeSeer
	Hardware Failure	
Z-Wave Devices Cannot Be Included Into Z-Wave Network	Device Was Previously Installed On Another Z-Wave Network	Use "Exclude Device" Procedure To Reset Device, Then Try To Include
	Device Failure	Replace Device
	Z-Stick Failure	Contact HomeSeer
HSDiscover Cannot Locate Device	HomeTroller Not Powered On	Power Unit On
	HomeTroller Not Fully Booted	Wait 2 Minutes For Unit To Boot
	HomeTroller Not Connected To LAN	Connect Unit To Router And Reboot
Door Locks Won't Include Or Can't Be Controlled	Inclusion Process Incorrect Or Incomplete	Exclude Devices and Repeat Procedure Outline In "Including Battery Powered Devices" Section
Sensors Won't Include Or Can't Be Monitored		
All Other Problems		Contact HomeSeer

HomeSeer Technologies

10 Commerce Park North, Unit #10

Bedford, NH 03110

www.homeseer.com

603-471-2816