

PLAYBACK MENU: Press the  **PLAYBACK** button to display the most recent TX/RX. Scroll up and down and press the  **MENU** button to play.



Press  **HOME SCREEN** to return to the display.

VOICE PLAYBACK: Press and hold  **PLAYBACK** to replay the most recent RX.

PRIORITY SCAN ON HAND HELD: Press the  **SCAN** button to turn scan ON/OFF.

PRIORITY SCAN ON REMOTE HEAD: Press the  **MENU** button three times. Press arrow down to highlight "ON" and press  **MENU** to select.

Press  **HOME SCREEN** to return to the display.

MENUS: Press the  **MENU** button to enter the menu options. Use the  **horizontal arrow keys** to select Scan, Squelch, or the Settings Menu.

The settings menu contains LCD brightness, Clock and colors. Press  **MENU** to select. Press  **HOME SCREEN** to return to the display.



562-427-8177



www.pciraceradios.com



6185 Phyllis Drive, Cypress, CA 90630

