

Point 1 GPS Antenna

HDS - Setup Instructions

If you are unsure about any step in this setup please call PCI for assistance.

The Lowrance Point 1 Antenna provides extremely accurate and rapid position and speed updates. This antenna has many features that are boat specific and they must be turned off to properly function when off road.



Update GPS Software

1. Go to: <http://www.lowrance.com/en-US/Software-Updates/>
2. Download most recent software for your GPS, put any update files onto a blank SD card (8gb or less).
3. Put the SD card in your GPS and power on the unit. This will automatically start the update then follow the instructions on the screen.


Make sure Point 1 Antenna is Active

1. Press MENU twice.
2. Select NETWORK > DATA SOURCES > GPS > ALL DATA
- If the Point 1 Antenna does not show up, the GPS is not communicating with the external antenna.
3. AUTO will be selected by default. You want to select 'Point 1 Antenna'; the circle will be highlighted blue.

Turn Off Features

1. Select VESSEL
 - a. Heading - Unselect 'Point 1'
 - b. Rate of Turn - Unselect 'Point 1'
 - c. Attitude Pitch - Unselect 'Point 1'
 - d. Attitude Roll - Unselect 'Point 1'

2. Close the screen and return to the map.



800-869-5636 - www.pciraceradios.com