

CURVED CANOPY INSTRUCTION MANUAL



1.

Unpack your canopy and lay it flat out on the ground, begin to assemble the long flexible pole until it is fully extended.

2.

Carefully push the long flexible pole through the slit located at the end of the canopy opposite the eyelet - make sure to push NOT pull the pole as this will disassemble it and make it harder for yourself.

3.

Carefully push the long flexible pole through the slit located at the end of the canopy opposite the eyelet - make sure to push NOT pull the pole as this will disassemble it and make it harder for yourself.

4.

Hook the ends of the flexible pole into the metal pegs found at the bottom of the canopy. If you are struggling please loosen the straps to allow more room to maneuver. Once those are in the canopy should begin to take shape.



5.

Connect the eyelet to the A-Frame in the centre of the bell tent door - making sure to remove the rain cap and placing it back once the canopy is attached.

6.

Using the pegs provided secure the canopy making sure that everything is as tight as it can be. You don't want wrinkles in the fabric

7.

Once this is secure you can begin to bring the entrance of the canopy out until the canvas is tight. Using pegs secure the entrance to the ground

8.

You can then begin to peg out the guy ropes, ensuring you tighten them afterwards to ensure the canopy has an even and symmetrical arch.

Ta-da!

You now have the perfect entrance way to your beautiful tent! Perfect for leaving dirty shoes!