





Tel: +1(626) 208-9606

E-Mail: support@nexoes.com


MODEL: NX3001T DINING TABLE

Please follow Assembly Instruction carefully. Step by step.

ASSEMBLY INSTRUCTION'S

PART LIST		
1	TABLE TOP 	1pc
2	LEG 	4pcs

HARDWARE LIST			
A	HEX COMB 5/16" x 2 1/2"		8pcs
B	FLAT WASHER 5/16"		8pcs
C	SPRING WASHER 5/16"		8pcs
D	SPANNER 12.8MM		1pc



COMPLETED ASSEMBLY