

GRID 3

Training cards

Lesson 1

1. Creating a write cell
2. Changing a picture
3. Editing a picture
4. Moving a cell
5. Editing the grid layout
6. Changing cell appearance
7. Creating jump cells
8. Chat and writing cells

Lesson 2

1. Introducing commands
2. Word lists
3. Adding grids
4. Cell accessibility
5. Adding sound to a cell
6. Setting up your accounts
7. Send to Grid Player
8. Remote editing

Lesson 3

1. Settings - Grid set
2. Settings - Email accounts
3. Settings - Speech
4. Settings - Mouse or head pointer
5. Settings - Touch
6. Settings - Eye gaze
7. Settings - Switch
8. Settings - Mobile and cell phone

Tip

Visit our website at www.thinksmartbox.com to access training videos, guides and support.

Edit mode keyboard shortcuts

F11	-	Start/Finish editing
<hr/>		
Ctrl + X	-	Cut
Ctrl + C	-	Copy
Ctrl + V	-	Paste
Ctrl + Z	-	Undo
Ctrl + S	-	Save
Ctrl + A	-	Select all
Ctrl + D	-	Deselect all
Ctrl + P	-	Change cell picture
Ctrl + J	-	Create jump
Ctrl + F	-	Follow jump
Ctrl + W	-	Create write cell
<hr/>		
Arrows	-	Navigate cells (+ shift to select)
Enter	-	Create cell
Insert	-	Add command (or create cell if blank)
Delete	-	Clear cell
<hr/>		
F1	-	Help
F2	-	Change cell label
F3	-	Find picture
F4	-	Edit picture
F5	-	Remove picture
F10	-	Settings
F12	-	Show/Hide menu bar in Grid Viewer
<hr/>		
Alt	-	Bring up Keytips to navigate the ribbon menus with keyboard letters