






Included with your Wego™ 13A:




- 1 Speaker charger
- 2 Speaker
- 3 Device charger
- 4 Stylus (x2)
- 5 Device strap
- 6 Welcome folder



Smartbox family

 talktometechnologies.com

 877.392.2299

Hardware, Buttons, & Features



Power

Press and hold this button (plus a volume button on some models) to turn the device on or off.

Note: Press this button one time while the device is on to put it into "Sleep" mode. This feature will conserve battery life when the device is not in use.



Volume

Use these buttons to increase or decrease volume level.



Home

Swipe up from the bottom to view the Home screen.


Note: If your Wego A model has a circular button to right of the screen, it will perform the same function.



Charging the Wego™ 13A

Charge device and TTMT Speaker (SPKR) at night or when not in use. Please only use TTMT-approved chargers with your device.

Note: Pull down the tab to reveal the device charging port.



Need help?



877.392.2299 Option 3



support@talktometechnologies.com



talktometechnologies.com