

öhl®

öhl-in bag

User's guide



Discovering your Öhll-in bag



Shoulder strap



Discovering your Öhl-in bag



Discovering your Öhll-in bag



R-Pet

All fabrics have been made from recycled plastics



Water resistant

Weatherproof fabrics



Shell: 400-600D

Bottom: 850 D

Inner: Ripstop 200D



Öhll Clip connector

Öhll Clip* compatible



* Öhll Clip is the vertical carry support for e-scooters and urban bicycles with the highest compatibility of the market. Sold separately



SAFETY INSTRUCTIONS

Do not load your Öhll-in bag with more than 8 kg., nor load it with sharp, abrasive, or any other type of elements that could damage the bag.

After installation, check that the vehicle can be maneuvered normally, and the brakes, the lights, or other elements work normally.

Vehicle behavior may change in terms of driving or braking when front weight is carried.

Do not stop holding the vehicle while an accessory is clipped. The weight could destabilize the vehicle even when supported on its side stand.

Ride carefully and anticipate the possible situations that both pedestrians and other vehicles may present to you during your journeys.



MAIN ACCESS

OPEN

Use the zipper leather puller to unzip and open the bag.



CLOSE

Pull the end tabs down at the same time to align the internal frame and then zip.



THE SPACE: MAIN

26,5 liters

A study of measures has been carried out to maximize the load capacity and determine the length, width and height.



Tall enough to carry standing bottles.



Wide enough to fit a 6-pack





THE SPACE: POCKETS

2 side mesh pockets:

Carry a bottle, your gloves, your sunglasses or whatever you need to have at hand.



Self-foldable bottles compartment. Holds up to 3 standard wine bottles



Interior zipped pocket: for your personal items or whatever you want to carry isolated.



OTHERS

Helmet loop:

Carry your helmet - when not riding -, by using the 2 snap buttons for different lengths.



Multifunctional molle:

Sturdy and ready to be used. Hang a carabiner or use it e.g. to carry a u-lock (depending the measures)



Leather accessory holder:

It can be used to clip an extra light for better visibility and security (light not included)



HOW TO CARRY

On your vehicle:

Safe and very easy to clip and unclip



On your hand:

Use its comfortable handles, short enough to avoid the bag touching the ground



On your shoulder:

Using its comfortable handles, long enough to avoid pressure underarm



Crossbody:


Use the adjustable shoulder strap and the d-rings front & rear



HOW TO CLIP AND UNCLIP

Clipping the bag onto the Öhll Clip:

Hold the bag by its leather handles and bring it closer to the vehicle support. The vehicle connector should slide through the bottom of the bag support piece until you hear "click".



Unclipping the bag from the Öhll Clip:

Pull the bag up with one hand using its handles and with the other hand, press the tab on top of the bag holder to release it.

Press the tab to release while pulling the bag up



CARE INSTRUCTIONS



Do not wash.



Do not bleach.



Do not tumble dry.



Do not iron.



Do not dry clean.

Hand-wash only using a damp washcloth. If water alone doesn't remove your stain and/or odor, try using a mild detergent (a very small bit of dish or laundry soap) or an outdoor-gear-specific cleaner. Afterward, rinse with warm water. If the stain/odor is still present after the first rinse, repeat the hand wash, and gently scrub it with a soft-bristled brush. Rinse and repeat as necessary.

To clean leather parts, use a specific leather cleaner. Natural leather changes color with use and this is part of its beauty.

Do not use abrasive scrubbers or chemicals. A washcloth or sponge should help enough.

Do not submerge the bag in water and never put it through the washing machine.

Let the bag fully dry in a well-ventilated area. Avoid storing the bag in damp or non-ventilated environments, as this can form mildew.