

Product Name:	4.5Ft Pre-Lit Artificial Tree
SKU#	WHAP2512

Thank you for purchasing this LuxenHöme product. This product has been manufactured with the highest standards of safety and quality.

PLEASE READ ALL INSTRUCTIONS BEFORE ASSEMBLY.

Unpack all parts from the packaging inside the carton to ensure there are no missing or damaged parts. If any parts are missing or damaged, do not attempt to assemble or use the product.

CARTON CONTENTS:

Description	Quantity
Tree Top (A)	1
Tree Bottom (B)	1
Tree Base	1
UL 30V Plug	1

Before You Start


1. Please read the assembly and Instruction procedure carefully. Retain the instructions for future use and save the carton for storing your tree.
2. Decide on an appropriate location for your product.
Note: This tree may utilize light sets marked for indoor and outdoor use, but the artificial tree is for indoor display only.

Assembly and Instruction Procedure (no tools required for assembly):

If your artificial tree has snow-flocking, we suggest unpacking the tree on a large cloth. Some of the flocking may come off during unpacking and fluffing of branches.

1. Assemble the Tree:
Carefully insert the bottom of the tree section (B) into the pot. Make sure the tree pole is firmly inserted inside the pot.
Insert section (A) into section (B).
Now that the tree is fully assembled, connect the light plugs as shown in the image below. Attach the plug to the string lights located in the bottom section of the tree and plug it into an electrical outlet. If lights do not come on, skip to the section for troubleshooting tips.

Product Name:	4.5Ft Pre-Lit Artificial Tree
SKU#	WHAP2512



2. Shape the Tree:

Begin to shape the branches from the bottom of the tree to the top. Start with the tree tips farthest away from the center pole.

After shaping the tree, step back to look for any gaps. Reshape branches as needed. You can upsweep the branch tips for a uniform look. Once you have the tree the way you want it, you can start decorating!




Fig.1




Fig.2




Fig.3

Product Name:	4.5Ft Pre-Lit Artificial Tree
SKU#	WHAP2512



Warnings:

1. To move the assembled tree, unplug first, and then move the tree by holding the pot base. Do not lift by the trunk.
2. Risk of Fire and Electric Shock – please follow instructions and warnings on string lights.
3. Do not place near fireplaces, candles, heaters, other similar sources of heat, or any items that are flammable. This item is not flame retardant.
4. Do not install near pools, fountains, tubs, sinks, or other areas of standing water that the tree may fall or blow into.
5. Keep wires clear of being pinched or cut during assembly or installation. Do not use wires with cut or pinched insulation.
6. Make sure the final assembly is stable enough to hold the tree upright.
7. Do not use candles on tree. Use only with the pre-installed string lights included.
8. This product is for decoration use only. Not to be used by children as a toy. Keep out of reach of small children.

Troubleshooting:

1. Lights do not come on when plugged in: Check the connection for the string light between the tree sections to ensure it is secure and not loose.
2. The tree is not straight: Try adjusting the tree to ensure it is secured into tree pot.
Note: If these actions do not resolve the issue with the tree, please do not disassemble the tree yet. Please contact customer service for assistance.

Storage:

1. Remove all decorations (this does NOT include the pre-installed string lights).
2. Starting from the top, carefully unassembled the tree sections. Press the tree tips back up against the pole.
3. Place the branch sections back into the carton, putting the longest one on the bottom.
4. Store the product in a cool, dry location protected from sunlight where the temperature does not exceed 35°C (95°F).