

Instruction Manual Please save this manual for future reference.

SKU #: WHIF1876

Thank you for purchasing this LuxenHöme product. This product has been manufactured with the highest standards of safety and quality.

PLEASE READ ALL INSTRUCTIONS CAREFULLY BEFORE ASSEMBLY.

Unpack all parts from the packaging inside the carton to ensure there are no missing or damaged parts. Place all wooden furniture parts on a clean, flat and soft surface to prevent scratches. Refer to the steps provided below for assembly.

Do not attempt to assemble or use the product if any parts are missing or damaged.






ITEM






A	Backrest	1 PC
B	Front Leg	2 PCS
С	Box Seat	1 PC
D	Seat	1 PC





1	JCBC Screw M6 x 80mm	4 PCS
2	JCBC Screw M6 x 60mm	4 PCS
3	JCBC Screw M6 x 35mm	1 PC
4	Spring Washer M6 x 13mm	9 PCS
5	Flat Washer M7 x 19mm	9 PCS
6	Allen Key M4 X 55mm	1 PC
7	CSK Screw M4 x 30mm	3 PCS




STEP 1


STEP 2





STEP 3





COMPLETED ASSEMBLY