



# **Wood Outdoor Bench**

SKU WHOF2277



ASSEMBLY INSTRUCTIONS



\*The estimated assembly time may vary depending on the individual.

# Hey, there

Now is assembly time!

Deeeeeep breathe.... and again.... Tools ready, Easy peasy!

#### **Estimated**

40 min. assembly person

### **Tools Required**

- Allen key (included)
- Magic screw (included)

important: Cautious when you use power tools

### Need Help?

Call us at +1 909 548 6688
Email customerservice@luxenhome.com
Submit a ticket on www.luxenhome.com/help

Thank you for purchasing this LuxenHome product. This product has been manufactured with the highest standards of safety and quality.

### PLEASE READ ALL INSTRUCTIONS CAREFULLY BEFORE ASSEMBLY.

Unpack all parts from the packaging inside the carton to ensure there are no missing or damaged parts. Lay out all the parts on a clean, flat, and soft surface to prevent scratches. Refer to the steps provided as assembling guide.

Do not attempt to assemble or use the product if any parts are missing or damaged.

#### REMINDERS

#### SAFE USAGE IS KEY

Your well-being is our top priority when you use our product. Please prioritize your safety by diligently following the assembly guidelines and inspecting the product carefully both when it arrives and before each use.


Please be aware that LuxenHome and Winsome House, Inc. cannot be held liable for any injuries or fatalities that occur due to not adhering to the provided instructions or misuse of the product.

#### DO NOT MODIFY

Our products undergo rigorous testing to ensure they meet established safety standards before being released for sale. Altering the product in any way can lead to serious safety concerns, for which LuxenHome cannot assume responsibility.

# What's in the box


### **Parts**



## **Hardware & Accessory**





# **Assembly**



### Step 1


Connect part (2) to part (1) with hardware B, C and D, using Allen key F to 'Tighten'.






### Step 2


Connect part (3) to part (2) with hardware A, E and G, using Allen key F to 'Tighten'.







### Step 3

Connect part (2) to part (1) with hardware B, C and D, using Allen key F to 'Tighten'. Connect part (3) to part (2) with hardware E, G and A, using Allen Key F to "Tighten'.





# VOILA! Now enjoy.





# Something not right?

We are always here to help.

### We make mistakes like every human does.

Though we always strive to provide the best possible products at competitive prices and the best service in the industry, it's not possible to completely eliminate mistakes. If you experience any dissatisfaction, feel free to contact us immediately. Our in-house customer care team will respond ASAP.



customerservice@luxenhome.com Get response within 24 hrs



909.548.6688 Mon-Fri 9am-5pm PST/PDT



www.luxenhome.com/help Submit a ticket on our website

# Thing to do to expedite the process

- Have your order# ready
- Take photos/video to help us better identify the issues
- · DO NOT throw away the packaging

# Happy with our product?

### Leave us a review

It really help us as a small business

- Find the product you purchased on our website (tip: search by SKU) and leave us a review.
- Alternatively, you can always return to the marketplace where you purchased it and leave a review there.

### **Share with others**

Our customers look for REAL stuff



- Follow us on IG @luxen.home
- Share your #liveluxen moments





Please save this manual for future reference.