

# START HERE to install your Haikubox using your smartphone


## Before installing your Haikubox:

- **Purchase an appropriate CB certified USB wall charger plug** and connect to the Haikubox's USB cord.
- Download the Haikubox Connect mobile app from the Google Play Store or Apple Store. This is a different app from the one used to see your birds (see below). 
- Ensure your smartphone's Bluetooth is turned on.
- Have the name and password for your WiFi handy.
- Use the Haikubox smartphone app or website ([listen.haikubox.com](http://listen.haikubox.com)) to create an account or create one during the connection process. You will receive an email confirmation; please check Spam or Junk folders.

## Connecting your Haikubox to your home's Wifi:


- 1) Plug in your Haikubox and wait 30 seconds for it to boot.
- 2) Open the Haikubox Connect mobile app and follow the prompts to connect your Haikubox to WiFi. Stay near your Haikubox; it may be helpful to set up indoors near your WiFi router. Move the box outside after completing the connection process.
- 3) When prompted, choose your WiFi from the dropdown list, enter the WiFi password, give your box a name (you can change it later), and click "Submit Credentials." Continue following prompts and then launch the Haikubox app.
- 4) Once the process is complete you may remove the Haikubox Connect app from your device.

## Placement of your Haikubox:

- Choose a spot outside with a GFCI power outlet and a strong Wifi signal. Outlet should be protected from rain, snow and other inclement weather.
- Tie a loose loop in USB cord near the plug to prevent water from running down cord to your outlet. 
- Hang your Haikubox and keep out of rising water and puddles. Use M4 steel screws for hard surfaces and M4 toggle bolts for hollow walls, both 75mm long.
- Try to avoid noisy locations (e.g., near a ticking clock or wind chimes) which can lead to incorrect bird detections.

## Learn About Your Birds

Download the Haikubox smartphone app from the Google Play or Apple Store or visit the website ([listen.haikubox.com](http://listen.haikubox.com)).



- **Identify visiting birds using their songs, chirps, and peeps**
- **Listen to recorded songs**
- **See images of the identified species**
- **Check charts showing how often and when each species visits**
- **Set up notifications for new and favorite birds (app only)**
- **Connect to resources and learn more about your birds**

## Important Safety Information

READ ALL INSTRUCTIONS BEFORE USING THIS PRODUCT TO REDUCE THE RISK OF FIRE, ELECTRIC SHOCK, OR INJURY. SAVE FOR FUTURE REFERENCE.

- 1) Use only as described in this manual.
- 2) Do not attempt to dismantle your Haikubox or alter the USB cable in any way. If parts came loose during shipping (e.g., cable gland), contact us for further instructions at [support@haikubox.com](mailto:support@haikubox.com)
- 3) Use a GFCI outdoor power outlet that is protected from rain, snow and other inclement weather. The outlet must remain dry at all times.
- 4) Do not place the USB cable near a heated surface.
- 5) Never operate the Haikubox if the plug or cord is damaged or appears damaged.
- 6) Never use the USB cable to pick up, carry, drag, pull, or lift the Haikubox. Do not pull the cable against or around sharp corners or edges.
- 7) Never touch the Haikubox or its plug when your hands are wet.
- 8) Only use in an upright position. Do not place anything on top of the Haikubox.



## Your Haikubox Warranty

Your Haikubox comes with a one-year limited warranty from the original purchase date. It will be replaced if found to be defective due to faulty material or workmanship during normal use. Haikubox's sole obligation under this warranty is to replace, or at Haikubox's discretion, to repair, free of charge, all defective parts. Proof of purchase is required. Warranty is not valid if damage is caused by the user.

# Haikubox

## Quick Start Guide

