



Installation and Troubleshooting Guide



NOTE: This installation is to be completed by an Authorized Dealer or Professional Service Technician. For questions regarding installation or warranty, call CDI Tech Support at 866-423-4832. **Do not return to the Dealer or Distributor where the part was purchased. Contact CDI Electronics Directly for Return Material Authorization.**

CDI P/N: 136-3029-3 Trigger 3 Cyl.

Replaces P/N: 653029, 300F653029-1, F653029, F653029-1 and 300-888796.

Warning! This product is designed for installation by a professional marine mechanic. CDI Electronics cannot be held liable for injury or damage resulting from improper installation, abuse, neglect or misuse of this product.

NOTICE: This trigger has been redesigned to use only four wires as opposed to the 6 wires used on the original design. This allows the use of heavier gage wire, resulting in better durability. Connect the black wire to engine ground.

INSTALLATION

1. Disconnect the stator and trigger wires from the terminal strip, making sure the remaining wires on the terminal strip are labeled.
2. Remove the flywheel.
3. Remove the stator – Use extra care handling the stator, due to it being very fragile. The coating on the charge winding is very easy to break (Like an eggshell). Once the coating on the charge windings is broken, the stator will have to be replaced.
4. Disconnect the trigger linkage and remove the trigger.
5. Install the new trigger and reconnect the linkage.
6. Using extreme care, reinstall the stator.
7. Connect the trigger wires according to the numbers and wire color.
8. Connect the black wire to engine ground.
9. Reconnect the stator wires.
10. Install the flywheel according to the service manual.

Connections

Pack #1 (Firing #1 and #2 cylinders)

Trigger: White/Orange (Orange)	Pack: White/Orange stripe or Orange
No Connection	White/Yellow stripe or Green
No Connection	White/Red stripe or Red
White/Green	White/Green Stripe
Black	Engine ground
Stator: Yellow	Pack: Brown/Yellow stripe or Yellow
Blue (both)	Brown/Blue stripe or Blue
Coil #1: White	Pack: Orange/blue stripe or Blue/Orange stripe
Coil #2: White	Pack: Blue/Red stripe or Red

Pack #2 (Firing #3 cylinder)

Trigger: White/Orange (Orange)	Pack: White/Orange Stripe or Orange
No Connection	White/Yellow Stripe or Green
Stator: Yellow	Pack: Brown/Yellow Stripe
Blue (must be connected to the Blue or Brown/Blue Stripe on pack 1)	
Coil #3: White	Pack: Orange/Blue stripe

NOTICE: The color codes listed above may appear on the packs, stators or triggers. Some packs have solid colors and some triggers have striped wires. If you need further assistance, please call our technical support department.

NOTE: This installation is to be completed by an Authorized Dealer or Professional Service Technician. For questions regarding installation or warranty, call CDI Tech Support at 866-423-4832. **Do not return to the Dealer or Distributor where the part was purchased. Contact CDI Electronics Directly for Return Material Authorization.**

