

AURELIAN

Gold & metal detector

USER MANUAL







Critical Warning

be sure to read the instruction of how to use the device correctly to get accurate results

- The device cannot be used will its raining to avoid any technical error
- Always keep the battery charged to avoid battery breakdown
- Do not use any different charger to avoid battery damage
- Main unit of the device is under Guarantee against all electronic breakdowns for three (3) years
- 5 Keep the device with in it protective case will transporting the device

Overview: **AURELIAN:**

is a long-range searching device contains both auto and manual search system Easy to use and very light weight for long hours of search and treasure hunting

auto search system:

allowed you to search for

(Gold – Natural gold - Silver – Bronze – Cavity)

Manual search system:

this system allowed you to search for specific type of gold which can be found in some area according to previous civilization such as

(Ottoman Gold - Roman Gold - Treasures -

Gold Nuggets - Silver Coins - Silver Bars)

The device depth is 25 meters underground





connect the handle of the device as in the photo and make sure its locked correctly

connect the antennas on the front side of the device

start the device by pressing the on/off button under the screen



Operating steps:

the device will automatically start and transfer you to the main page the main page contains 3 option languages and info and sittings by pressing info, the device will display the information of the device such as serial number and manufacturing year and guaranty buried

the sitting option will allow you to change the sound and brightness level according to your needs

language option will transfer you to the device languages which is you can select the language you want the device to operate in



after selecting the language search type menu will appear on the screen to select the search system you want to process with


auto search system
allowed you to search for
(Gold – Natural gold - Silver – Bronze – Cavity)

Manual search system
this system allowed you to search for specific type
of gold which can be found in some area according
to previous civilization such as
(Ottoman Gold - Roman Gold - Treasures Gold Nuggets - Silver Coins - Silver Bars)



Move directly without shaking the device and the device will guide you throw the target location if exist in the area you are in When the device is above the target t he device will star spinning alerting you that a target has been detect it

And if the device turns back this means the target exist behind you and you should turn and start walking



After selecting search type and target type front range will appear on the screen to select the range you want to cover in your search

After selecting the front range, the search page will appear on the screen Now the device is ready for your search





Move directly without shaking the device and the devicewill guide you throw the target location if exist in the area you are in When the device is above the target the device will star spinning alerting you that a target has been detect it



Parts and accessories:



Device main unite



Device grip



SP antenna





2 lithium-ion battery



Compass



2 recipient antennas



Charging cablVe



car & home chargers



Note:

Guarantee incudes all technical issues

Batteries are not under guarantee

The device breakdown due to user
cause its not included in the guarantee.

For further information please do not hesitate
to contact our support team to assist you,
also please check our website from more
videos and visual instruction





Get In Touch

P: +491788202552

E: nextlab.detectors@gmail.com

W: nextlabsdetectors.com