



HCX91 Barbie Dream Camper Advanced Series	
Age Range:	3 - 7 years
Weight Limit:	130 lbs.
Surfaces:	Grass/Hard Surfaces
Speed:	2.5 - 5 MPH Forward 2.5 MPH Reverse
Colors:	Pink Body/Black Wheels
Intró:	2020
Suggested Retail:	\$472.50
Box Dimensions:	34" L x 34" W x 52" H
Warranty:	One Year Vehicle Six Months Battery



Item	Part #	Description	QTY	Item	Part #	Description	QTY
1	<b>3900-4948</b>	<b>Motor Gearbox Assembly (left)</b>	1	35	3900-6588	Roof for Barbie Camper FRC29 (pink)	1
2	B9785-2229	.437 Bushing (black)	2	36	<b>3900-6786</b>	<b>Rear Body Left for Barbie Camper</b>	1
3	3900-4890	Front Axle for Mustang	2	37	<b>3900-6787</b>	<b>Rear Body Right for Barbie Camper</b>	1
4	3900-6738	Wheel Driver for Barbie Camper	2	38	3900-6586	Front Pillar Left for FRC29 (pink)	1
5	3900-6599	Front Bumper Support for FRC29	1	39	3900-6587	Front Pillar Right for FRC29 (pink)	1
6	3900-6740	Front Rim for Barbie Camper FRC29	2	40	3900-6594	Dashboard for Barbie Camper FRC29	1
7	3900-6784	Center Hub Cap for Barbie Camper	4	41	3900-6585	Front Bumper w/Lights & Emblem FRC29	1
8	FRC29-9029	Hinge Cap Bag (2) for Barbie Camper	1	42	3900-6595	Battery Cover for Barbie Camper FRC29	1
9	3900-6607	Shelf for Microwave FRC29 (pink)	1	43	3900-6483	Steering Wheel for Barbie Camper FRC29	1
10	3900-6593	Counter Top for Barbie Camper	1	45	3900-6739	Rim Rear for Barbie Camper	2
11	See Parts Bag	Cooking Pot	46	46	00801-1621	Cap (retainer .437) (blk)	1
12	3900-6596	Top Rail Left for Barbie Camper	1	47	3900-6598	Seat for Barbie Camper FRC29 (blue)	1
13	3900-6597	Top Rail Right for Barbie Camper	1	48	L2170-2689	Bushing - Upper (black)	2
14	3900-6477	Rear Axle for Barbie Camper FRC29	1			<b>Parts Not Shown</b>	
15	3900-6633	Steering Column for Barbie Camper	1			<b>Description</b>	<b>QTY</b>
16	<b>3900-6785</b>	<b>Wiring Harness for Barbie Camper</b>	1		3900-6021	Battery Retainer for Boomerang FLC33	1
17	<b>3900-4949</b>	<b>Motor Gearbox Assembly (right)</b>	1		3900-6658	Hardware Bag for Barbie Camper FRC29	1
18	3900-6632	Steering Wheel Cap for Camper	1		3900-6608	Label Sheet for Barbie Camper FRC29	1
19	<b>3900-6020</b>	<b>Shifter Boomerang &amp; Barbie Camper</b>	1		3900-6657	Manual for Barbie Camper FRC29	1
20	J4390-2279	Left Wheel for Mustang (black)	2		<b>3900-6654</b>	<b>Motor Pinion for Barbie Camper</b>	2
21	See 20	Left Wheel for Mustang (black)			<del>00868-2824</del>	<b>#7R Gearbox (18-19-20)</b>	2
22	J4390-2289	Right Wheel for Mustang (black)	2		3900-6752	Parts Bag 1 for Barbie Camper FRC29	1
23	See 22	Right Wheel for Mustang (black)			3900-6753	Parts Bag 2 for Barbie Camper FRC29	1
24	<b>3900-6884</b>	<b>Footboard Assembly for PW BRB Camper</b>	1		<b>3900-6958</b>	<b>Footswitch for Barbie Camper</b>	1
25	See Parts Bag	Smores			<b>3900-6750</b>	<b>EMU Cover for Barbie Camper</b>	1
26	3900-6735	Fire Pit for Barbie Camper FRC29	1		<b>3900-6749</b>	<b>EMU for Barbie Camper FRC29</b>	1
27	3900-6600	Microwave for Barbie Camper FRC29	1		00801-1661	Battery 12v 12 Ah (orange top)	1
28	3900-6601	Door Rear Left (dryer) for FRC29	1		00801-1778	12 Volt Charger w/Probe	1
29	3900-6602	Door Rear Right (fridge) for FRC29	1		3900-7701	Tailights (lt & rt) for Barbie Camper	1
30	*3900-6485	Soundbox FRC29 (dom after 9/26/18)*	1		00801-1565	5/32" x 1 1/2" Steering Pin	1
31	3900-6589	Backsplash for Barbie Camper FRC29	1		00801-1939	Cap Nut .437 (black)	2
32	<b>3900-6789</b>	<b>Steering Linkage for Barbie Camper</b>	1		0801-0196	0801-0196 7/16" Washer	2
33	3900-6606	Faucet for Barbie Camper FRC29	1		3900-6024	Ring Pin for Boomerang FLC33	2
34	3900-6592	Oven Panel for Barbie Camper FRC29	1		3900-6790	Bag (lt & rt) Connectors for Grille	1

\*Please see Service Bulletin 214 - Barbie Camper Soundbox Replacement

**Bold and underlined parts are to be purchased and installed by Service Centers only. These items may not be sold directly to consumers by Service Centers or**

**Fisher-Price.**

© 2020 Mattel