

High Spirits Flutes

Eco Flute Stand - Assembly Instructions


Note - These assembly instructions can be used for a Single Eco Stand, a Double Eco Stand, or a Triple Eco Stand.

Step 1



Lay the pieces out as shown, and assemble the stand one side at a time.

Step 2



Insert the crossbar into the side piece and engage it with the notch-side facing downward.

Step 3



Repeat for any additional crossbars, and the second side.

Single Eco Stand



Double Eco Stand



Triple Eco Stand

