

## RZR 900S Dobeck Tuning

Green Mode: Green output value. Adjustment Range from -5 to +5 Fuel. Light number 1 is equal to -5, Light number 8 is equal to +5. Turn on RPM is 0, active until yellow shuts green mode off.

Yellow Mode: Yellow output value, Adjustment Range from -5 to + 5 Fuel. Light number 1 is equal to -5, Light number 8 is equal to +5. When yellow mode activates it shuts off green mode.

Red Mode: Red output value, Adjustment Range from -5 to +5 Fuel. Light number 1 is equal to -5, Light number 8 is equal to +5. Red mode disables yellow mode when active.

Green Blue Mode: Amount of fuel per psi of boost. Lower the light the lesser fuel it will add. Higher the Light the more fuel it will add.

Yellow Blue Mode: Turn on RPM range for Yellow Mode: Light number 1 is equal to 1800 RPM, light number 8 is equal to 5400 RPM.

Red Blue Mode: Turn on RPM range for Red Mode: Light number 1 is equal to 4500 RPM, light number 8 is equal to 7650 RPM.