

Yxz Turbo Fuel Controller

- Green Mode- Green mode is low speed fuel adjustment. Turns on at 2200rpm. Adjustment range is 0-10% Raising the green light is more fuel and lowering is less fuel.
- Yellow Mode- Yellow mode is midrange fuel adjustment adjustment range is 0-10% fuel. Active anytime yellow light is displaying. Raising the yellow light is more fuel and lowering is less fuel.
- Red Mode- Red mode is Full Throttle mode. Active anytime Red lights are displaying. Adjustment range is 0-10% Raising the light is more fuel and lowering is less.
- Green Blue-Green blue is boost fuel. Active anytime the control box is displaying a blue light. Raising the light is more fuel, lowering it is less.
- Yellow blue- yellow blue is rpm adjustment for yellow mode to activate. Lowering yellow blue will allow yellow mode to activate at lower rpm, raising it will make yellow to turn on at higher rpm.
- Red blue-red blue mode is rpm turn on point for red. Lowering the light will allow red mode to activate at lower rpm, raising it will make red to turn on at higher rpm.