

Arctic Cat Proclimb M800 Control Box Settings

Green Mode: TPS Clamp. Lower the light the lower voltage the TPS will clamp at. The higher the light the higher the voltage the TPS will clamp at. This mode will allow you to pull fuel away on bottom end throttle stabs. To tell this mode is active while stabbing the throttle at idle notice a blue light will come on at light number 8.

Yellow Mode: Midrange Fuel. Lower the light the lesser fuel will be added. The higher the light the more fuel will be added. This mode is active while lights are yellow on the control box. When yellow mode activates it will turn off Green mode.

Red Mode: Minimum Boost Fuel. Lower the light the less fuel it will add when on boost fuel. Higher the light the more fuel it will add when entering boost fuel.

Green Blue Mode: Maximum Boost Fuel. Lower the light the less fuel it will add, Higher the light the more fuel it will add. Use this mode to adjust your WOT AFR's.

Yellow Blue Mode: RPM turn on for Yellow Mode. Lower the light the yellow mode will be active during lower rpm's. The higher the light the Mode will become active at higher RPM's.

Red Blue Mode: Boost Fuel turn on PSI. Lower the light boost fuel will turn on at a lower psi. Higher the light boost fuel will turn on at a higher psi. Range is from .5 psi to 5 psi.

Base Settings Green 5, Yellow 3, Red 2.5, Green Blue 5, Yellow Blue 6.5, Red Blue 7