


RSB1 - Parts List



#	Item #	Description	QTY
1	RSB1001	Hood Handle	1
2	RSB1002	Hood	1
3	RSB1003	Top Grate	1
4	RSB1004	Burner Assembly	1
5	RSB1005	Ignition Electrode	1
6	RSB1006	Ignition Wire	1
7	RSB1007A	Orifice LP	1
	RSB1007B	Orifice NG	1
8	RSB1008	Burner Base Assembly	1
9	RSB1009	Hinge Pin	2
10	RSB1010	Basin Assembly	1
11	RSB1011	Flex Tube 200mm	1
12	RSB1012	Valve	1
13	RON049	Knob Bezel	1
14	RON048	Knob	1