CLASSIC RANGE



TAKE CARE OF YOUR WINE CABINET DO THE MAINTENANCE



Why look after my wine cellar?

Wine cabinet maintenance is very important for its good working. It also reduces power consumption and prolongs its life.



MAINTENANCE TO DO ONCE A YEAR:

- Unplug the cabinet
- Remove all bottles and shelves from the cabinet, and pull the cabinet to have access to the back of it
- Wash the inside panels and the bottom of the cabinet by using water and a soft detergent and then dry it with a soft rag
- Clean the water drain at the bottom bottom. Pay attention that nothing is blocking this drain
- Vaccum the condenser on the back (metal grid) to remove the dust and wash the water drip tray
- · Check the power cord
- Check the door setting and the conformity of the door seal
- Replace the active charcoal filter, by removing the one all ready in place from the inside of the cabinet and push the new one in the hole
- Reposition the cabinet in the desired location and make sure that it is level
- Put the shelves back in the cabinet and reorganize your wines
- Plug the cabinet in
- Control temperature setting



WHAT IS THE CHARCOAL FILTER FOR?

The charcoal filter regulates the humidity rate in your wine cabinet and limits bad smells and mould by a natural aeration « besement window effect». For most of the new cabinets a visual alarm starts up every year to remind you that it is time to change it. The alarm has to be reset every year.

WHERE TO BUY IT?

Charcoal filters are sold on our website or in EuroCave stores.

Check website our www.eurocave.com to find the nearest EuroCave store.


Are you aware? EuroCave has the label French origin guaranteed



COMPACT RANGE



TAKE CARE OF YOUR WINE CABINET DO THE MAINTENANCE




Why look after my wine cellar?

Wine cabinet maintenance is very important for its good working. It also reduces power consumption and prolongs its life.



\ggg MAINTENANCE OPERATIONS TO BE CARRIED OUT EVERY 3 MONTHS (059 only)

- · Remove the 2 screws from the grid with a no. 2 allen key (included in the accessories bag, remove the grid, take out the filter and wash it under the tap
- Dry it and re-assemble all components



It will ensure the good fonctionning of your cellar because the grid allows aerating of the condenser and rejecting the hot air. The filter will prevent dust or particles from entering the unit. Maintenance is essential to stop dust from accumulating on the filter and potentially block the ventilation causing temperature troubles inside the unit.



MAINTENANCE TO DO ONCE A YEAR:

- Unplug the cabinet
- Remove all bottles and shelves from the cabinet, and pull the cabinet to have access to the back of it
- Wash the inside panels and the bottom of the cabinet. Use water and a soft detergent and dry with a soft rag
- Clean the water drain at the bottom inside. Pay attention that nothing is blocking this drain
- Vaccum the condenser on the back (metal grid) to remove the dust and wash the water drip tray
- Check the power cord
- Check the door setting and the conformity of the door seal
- Replace the active charcoal filter, by removing the one all ready in place from the inside of the cabinet and push the new one in the hole
- · Reposition the cabinet in the desired location and make sure that it is level
- Put the shelves back in the cabinet and reorganize your wines
- Plug the cabinet in
- Control temperature setting





WHAT IS THE CHARCOAL FIL-TER FOR?

The charcoal filter regulates the humidity rate in your wine cabinet and limits bad smells and mould by a natural aeration « besement window effect». For most of the new cabinets a visual alarm starts up every year to remind you that it is time to change it. The alarm has to be reset every year.

WHERE TO BUY IT?

Charcoal filters are sold on our website or in EuroCave stores.

Check our website www.eurocave.com to find the nearest EuroCave store.

Are you aware? EuroCave has the label French origin guaranteed

