

## Xtreme Charge XC-822-Test Quick Battery and Alternator Tester

**Part #:** 100X822

**Model #:** XC-822-TEST

- Tests any kind of 12-volt lead- acid battery
- Tests 12-volt electrical system
- Fast, safe and simple operation
- Small enough to fit in your pocket
- Easy-to-interpret test results
- GOOD or BAD alternator voltage output LED display
- Percentage battery state of charge LED display
- Tests batteries remotely with leave-on charge cable adapter
- 90-Day Limited Warranty



### Description:

When you need to know some basic battery and alternator information quickly, the Quick Battery and Alternator Tester is a fast, simple and safe tool to do just that. It is compact and lightweight. Measuring just 4.75"L x 1"W x 0.6"H and weighing less than 2 oz. it'll easily fit into your pocket.

The colored LED lights display easy-to-interpret results instantly. The alternator results on the top of the tester indicate a GOOD or BAD alternator voltage output. When the voltage is too high, the illuminated BAD LED lights up. The battery test display on the bottom of the tester shows your 12-volt battery's state of charge as a percentage of output circuit voltage – 100%, 75%, 50% or 25%.

The tip probes are designed to work either remotely by inserting the test probes directly into the standard quick disconnect connection without touching the battery posts directly or by touching the tips to the battery terminals directly. Touch the red fixed post probe to the positive battery terminal and the black coiled-cord removable probe to the negative battery terminal to instantly see the 12-volt battery's state of charge.

### Specifications:

Battery Type	12-Volt
Weight	1.5 oz
Dimensions	4.75" x 1" x 0.6"
Negative Probe Cable	17.5"
Operating Temperature	32°F to 122°F (0°C to 50°C)
Storage Temperature	0°F to 130°F (-18°C to 54°C)
Battery Indicators	25%, 50%, 75%, 100%
Alternator Indicators	Good, Bad
Battery Cable Length	5'