

| PART NUMBER | DESCRIPTION | REF. NO. |
|-------------|----------------------------------|----------|
| 528690 | RETAINING PLATE | 1H05 |
| 528701 | BEARING | 1H05 |
| 528702 | THRUST WASHER | 1J06 |
| 528720 | DISTANCE PIECE | 1H05 |
| 528721 | DISTANCE PIECE | 1H05 |
| 528722 | DISTANCE PIECE | 1H05 |
| 528747 | SEAL-OIL | 1I11 |
| 528865 | STUD | 1H03 |
| 529394 | BAFFLE PLATE | 1C08 |
| 529823 | SUMP | 1C07 |
| 529823 | SUMP-ENGINE OIL | 1E07 |
| 530178 | THRUST WASHER | 1C04 |
| 530179 | RETAINING RING | 1C04 |
| 530343 | OIL THROWER | 1D04 |
| 530476 | THERMOSTAT BYPASS | 1C10 |
| 530476 | HOUSING-WATER | 1E10 |
| 530478 | PUMP CASING | 1C10 |
| 530478 | BODY WATER PUMP | 1E09 |
| 530481 | SEALING PLATE | 1D06 |
| 530890 | PULLEY | 1C10 |
| 530890 | PULLEY-FAN | 1E09 |
| 530966 | OLIVE | 1N10 |
| 530984 | SHIM 0.003 | 1J06 |
| 530985 | SHIM 0.005 | 1J06 |
| 530986 | SHIM 0.010 | 1J06 |
| 530987 | SHIM 0.030 | 1J06 |
| 530988 | SWIVEL PIN & STEERING LEVER | 1J06 |
| 530989 | SWIVEL PIN & STEERING LEVER | 1J06 |
| 530990 | SWIVEL PIN & STEERING LEVER | 1J06 |
| 530991 | SWIVEL PIN & STEERING LEVER | 1J06 |
| 531001 | LOCKER | 1J06 |
| 531040 | RELAY LEVER UPPER | 1K05 |
| 531043 | STUD | 1J06 |
| 531104 | ENGINE BRACKET | 1H09 |
| 531388 | CONTROL ROD | 1008 |
| 531388 | CONTROL ROD PEDAL SHAFT | 1011 |
| 531390 | CONTROL ROD | 1007 |
| 531390 | ROD-ACCELERATOR CROSS SHAFT | 1011 |
| 531391 | CONTROL ROD | 1012 |
| 531392 | BELL CRANK | 1012 |
| 531394 | CLIP | 1007 |
| 531394 | RETAINER-ACCELERATOR CONTROL ROD | 1008 |
| 531394 | CLIP-ACCELERATOR ROD | 1011 |
| 531394 | RETAINER-ACCELERATOR ROD | 1012 |
| 531394 | RETAINER-CONTROL ROD | 1014 |

| PART NUMBER | DESCRIPTION | REF. NO. |
|-------------|------------------------------------|----------|
| 531395 | CROSS SHAFT LEVER | 1007 |
| 531395 | LVR-ACCELERATOR CROSS SHAFT | 1011 |
| 531433 | O RING | 1J06 |
| 531440 | CONTROL ROD ASSEMBLY | 1008 |
| 531440 | CONTROL ROD ASSEMBLY | 1010 |
| 531494 | STUD | 1J06 |
| 531586 | GASKET FOR HEAD LAMP | 2F02 |
| 531684 | STOP TAIL LAMP | 2F03 |
| 531873 | VALVE ROCKER | 1D08 |
| 531874 | VALVE ROCKER | 1D08 |
| 531888 | ANCHOR PLATE | 1L04 |
| 531889 | ANCHOR PLATE | 1L04 |
| 531893 | SPRING | 1L04 |
| 532319 | O RING | 1D11 |
| 532319 | 'O' RING-OIL DIPSTICK TUBE | 1F02 |
| 532323 | SEAL | 1H07 |
| 532323 | 'O'RING | 1I09 |
| 532387 | SEALING RING | 1C07 |
| 532387 | O RING | 1D08 |
| 532387 | 'O'RING DIPSTICK | 1E07 |
| 532387 | O RING | 1E08 |
| 532453 | THERMOSTAT | 1C10 |
| 532453 | THERMOSTAT | 1E10 |
| 532879 | BASE FOR STOP TAIL LAMP | 2F03 |
| 532880 | LENS FOR STOP TAIL LAMP | 2F03 |
| 532881 | STOP TAIL LAMP | 2F03 |
| 532926 | ADJUSTING SCREW FOR SELECTOR SHAFT | 1H13 |
| 532979 | LOW GEAR WHEEL | 1H08 |
| 533040 | BOTTOM COVER | 1H09 |
| 533080 | GEAR CLUSTER | 1H07 |
| 533358 | PLUG-GEARBOX OIL FILLER | 1I04 |
| 533358 | PLUG-OIL FILLER GEARBOX | 1I05 |
| 533731 | HOUSING ASSEMBLY | 1H09 |
| 533765 | RETAINER-SPEEDO GEAR | 1I11 |
| 533786 | THRUST WASHER | 1J08 |
| 533787 | THRUST WASHER | 1J08 |
| 533788 | THRUST WASHER | 1J08 |
| 534021 | SPRING DOWEL | 1010 |
| 534790 | NUT | 1M09 |
| 534897 | BOLT-BANJO | 1F06 |
| 535023 | FOOT PUMP | 2L11 |
| 535068 | TOWING JAW AND PINTLE | 2L03 |
| 535168 | CARBURETTER LEVER BALL END | 1008 |
| 535173 | REAR ROAD SPRING | 1J18 |
| 535286 | RELAY LEVER | 1K05 |

| PART NUMBER | DESCRIPTION | REF.NO. |
|-------------|---------------------------|---------|
| 535708 | STUD & DOWEL KIT | 1D03 |
| 535989 | VALVE SPRING | 1D07 |
| 536152 | FLASHER LAMP LENS | 2F04 |
| 536273 | PISTON ASSY | 1D04 |
| 536275 | PISTON ASSY | 1D04 |
| 536514 | EXHAUST MANIFOLD | 1E13 |
| 536577 | PLUG | 1C02 |
| 536577 | PLUG-DRAIN ENINE OIL | 1C07 |
| 536577 | PLUG | 1C10 |
| 536577 | PLUG | 1C11 |
| 536577 | PLUG | 1D07 |
| 536577 | PLUG | 1D08 |
| 536577 | PLUG | 1E02 |
| 536577 | PLUG-ENGINE OIL DRAIN | 1E07 |
| 536577 | PLUG | 1E08 |
| 536577 | PLUG | 1E10 |
| 536577 | PLUG-CYLINDER HEAD | 1E11 |
| 536872 | INLET CAM FOLLOWER RH | 1D08 |
| 536873 | INLET CAM FOLLOWER LH | 1D08 |
| 536913 | BARREL LOCK | 2F09 |
| 536937 | LUCRIMP CONNECTOR 3 WAY | 1N08 |
| 536937 | BULLET CONNECTOR | 2F02 |
| 537229 | OIL FILTER ASSEMBLY | 1C12 |
| 537229 | FILTER-OIL | 1E12 |
| 537229 | OIL FILTER ASSEMBLY | 1E12 |
| 537269 | PISTON ASSY | 1D04 |
| 537271 | PISTON ASSY | 1D04 |
| 537685 | SHACKLE PLATE | 1J17 |
| 537686 | PLATE | 1J17 |
| 537687 | PLATE | 1J15 |
| 537734 | SHACKLE PLATE INNER | 1J18 |
| 537740 | BOLT | 1J18 |
| 537740 | SHACKLE PIN | 1J17 |
| 537741 | SHACKLE PIN | 1J15 |
| 537741 | BOLT | 1J16 |
| 537741 | BOLT | 1J17 |
| 537741 | BOLT | 1J17 |
| 537741 | BOLT | 1J18 |
| 537742 | SHACKLE PIN | 1J15 |
| 537742 | BOLT | 1J16 |
| 537763 | BRAKE PIPE COMPLETE FRONT | 1L09 |
| 537763 | BRAKE PIPE | 1L12 |
| 537778 | SHACKLE PLATE OUTER | 1J18 |
| 537791 | CONTROL ROD | 1012 |
| 537805 | CLIP-TEE PIECE REAR BRAKE | 1L09 |

| PART NUMBER | DESCRIPTION | REF. NO. |
|-------------|------------------------------------|----------|
| 537877 | SPLIT BUSH | 1K05 |
| 537964 | MAIN LEAF | 1J18 |
| 538038 | JOINT WASHER | 1C07 |
| 538038 | GASKET FRONT COVER | 1E08 |
| 538039 | JOINT WASHER | 1C07 |
| 538039 | GASKET-FRONT COVER | 1E08 |
| 538073 | COVER | 1C05 |
| 538073 | COVER-CAMSHAFT-REAR | 1E05 |
| 538131 | THRUST WASHER | 1C03 |
| 538131 | WASHER THRUST | 1E03 |
| 538132 | THRUST WASHER | 1C03 |
| 538132 | WASHER THRUST | 1E03 |
| 538133 | THRUST WASHER | 1C03 |
| 538133 | WASHER THRUST | 1E03 |
| 538134 | THRUST WASHER | 1C03 |
| 538134 | WASHER THRUST | 1E03 |
| 538499 | JOINT WASHER DIAPHRAGM TO | 1N07 |
| 538536 | CONNECTOR | 1H12 |
| 538616 | GASKET | 1L07 |
| 538671 | JOINT WASHER | 1C10 |
| 538671 | GASKET-WATER PUMP | 1E09 |
| 538768 | DOUBLE CLIP FOR BRAKE PIPES | 1L09 |
| 539572 | WEIGHTS-DISTRIBUTOR | 2E04 |
| 539575 | SPINDLE-DISTRIBUTOR | 2E04 |
| 539576 | CLAMP-DISTRIBUTOR | 2E04 |
| 539703 | CROSS SHAFT | 1J08 |
| 539706 | PINION BEARING | 1J08 |
| 539707 | PINION BEARING | 1J07 |
| 539718 | SHIM | 1J07 |
| 539720 | SHIM | 1J07 |
| 539722 | SHIM | 1J07 |
| 539724 | SHIM | 1J07 |
| 539741 | HOUSING-SWIVEL PIN | 1J05 |
| 539742 | RAILKO BUSH | 1J06 |
| 539745 | WASHER | 1J07 |
| 539787 | CASING ASSEMBLY | 1H09 |
| 539828 | INTERMEDIATE GEAR | 1H07 |
| 539887 | LINK FOR TRANSFER SELECTOR SHAFT | 1H13 |
| 539956 | MAINSHAFT BEARING HOUSING ASSEMBLY | 1H09 |
| 539993 | FLANGE | 1H10 |
| 540004 | SPEEDOMETER WORM | 1H08 |
| 540530 | WASHER-PLAIN | 1I11 |
| 540842 | BOLT | 1H12 |
| 540870 | PLUG | 1H03 |
| 541195 | FLYWHEEL HOUSING | 1G02 |

| PART NUMBER | DESCRIPTION | REF. NO. |
|-------------|-----------------------------------|----------|
| 541215 | GROMMET | 1M09 |
| 541229 | PLATE | 1N13 |
| 541229 | PLATE | 1N13 |
| 541760 | FLYWHEEL ASSEMBLY | 1G02 |
| 541860 | TUBE | 1C07 |
| 541860 | TUBE-DIPSTICK | 1E07 |
| 541860 | DIPSTICK TUBE | 1E08 |
| 541910 | CRANKSHAFT STD | 1D04 |
| 541921 | OIL SEAL | 1D04 |
| 542036 | SCREW & WASHER FOR STOP TAIL LAMP | 2F03 |
| 542038 | SCREW AND WASHER FOR FLASHER LAMP | 2F04 |
| 542041 | SPECIAL SCREW | 2F03 |
| 542042 | SPECIAL SCREW AND WASHER | 2F04 |
| 542043 | LENS | 2F03 |
| 542045 | BULB HOLDER | 2F03 |
| 542048 | LENS FOR FLASHER LAMP | 2F04 |
| 542073 | MUD EXCLUDER | 1D09 |
| 542256 | RIVET 0.125 DIA X 0.625 LONG | 1D09 |
| 542396 | OIL PUMP BODY | 1D05 |
| 542410 | CRANKCASE VENT UNIT | 1C08 |
| 542425 | SIDE ROCKER COVER | 1D08 |
| 542492 | OIL SEAL | 1C03 |
| 542492 | SEAL-OIL-REAR MAIN BEARING | 1D04 |
| 542492 | SEAL ASSY-OIL REAR MAIN | 1E03 |
| 542494 | OIL SEAL | 1C03 |
| 542494 | OIL SEAL AND RETAINER- | 1D04 |
| 542494 | SEAL ASSY-OIL REAR MAIN | 1E03 |
| 542515 | LOCKING PLATE FOR ADJUSTER | 1L05 |
| 542600 | SIDE COVER | 1E09 |
| 542600 | SIDE COVER ASSY | 1C08 |
| 542601 | STUD | 1E09 |
| 542601 | STUD | 1C08 |
| 542622 | KEY | 1D04 |
| 542623 | KEY | 1D04 |
| 542762 | BOSS | 1010 |
| 542776 | PIN | 1010 |
| 542783 | SPIRAL PIN | 1010 |
| 542845 | NUT | 1N08 |
| 542845 | NUT-FUEL PIPE | 1N12 |
| 542846 | OLIVE | 1N08 |
| 542846 | OLIVE-FUEL PIPE | 1N11 |
| 542846 | OLIVE-FUEL PIPE | 1N12 |
| 542846 | OLIVE-FUEL PIPE | 1N13 |
| 542846 | OLIVE-FUEL PIPE | 1N13 |
| 542861 | SPRING | 1010 |

| PART NUMBER | DESCRIPTION | REF.NO. |
|-------------|------------------------------------|---------|
| 543108 | 'U' BOLT FRONT SPRING | 1J15 |
| 543209 | AIR CLEANER | 1N02 |
| 543254 | BRACKET | 1D15 |
| 543275 | DISTANCE PIECE | 1L14 |
| 543281 | PIN | 1L14 |
| 543291 | PLUNGER ROD | 1L14 |
| 543292 | PLUNGER ROD | 1L14 |
| 543301 | JACK HANDLE | 2L11 |
| 543498 | ANCHOR | 1011 |
| 543546 | RATCHET | 1L14 |
| 543589 | CLIP | 1N17 |
| 543589 | CLIP | 2L14 |
| 543589 | CLIP | 2L15 |
| 543764 | HOSE | 1N14 |
| 543764 | PIPE-FUEL FILLER | 1N17 |
| 543765 | HOSE | 1N14 |
| 543766 | PIPE | 1002 |
| 543766 | BREATHER PIPE-FUEL TANK | 1003 |
| 543766 | HOSE-FUEL TANK BALANCE | 1004 |
| 543766 | HOSE-FUEL TANK BALANCE | 1006 |
| 543767 | PIPE | 1N14 |
| 543767 | PIPE | 1N15 |
| 543767 | BREATHER HOSE | 1N16 |
| 543767 | BREATHER HOSE | 1N17 |
| 543767 | HOSE-BREATHER FUEL TANK | 1004 |
| 543803 | BOLT(0.3125 UNF X 1.50) | 1002 |
| 543808 | PLATE | 1002 |
| 543818 | STEM WASHER OUTER | 1K08 |
| 543818 | STEM FIXING WASHER STEERING DAMPER | 1K07 |
| 543819 | STEM WASHER INNER | 1K08 |
| 543819 | INTERMEDIATE STEM FIXING WASHER | 1K07 |
| 543972 | HOUSING FOR RELAY SHAFT | 1K05 |
| 544337 | BOLT SPECIAL | 1K05 |
| 544389 | DISTANCE PLATE | 1N10 |
| 544573 | LICENCE HOLDER | 2G10 |
| 544581 | DRAG LINK TUBE | 1K07 |
| 544658 | ELBOW | 1002 |
| 544674 | ELBOW | 1002 |
| 545010 | SWITCH | 1C11 |
| 545010 | SWITCH-THERMOSTAT | 1D11 |
| 545010 | SWITCH-WATER TEMPERATURE | 1F06 |
| 545571 | BEARING | 1010 |
| 546026 | RATCHET | 1C04 |
| 546026 | RATCHET-TIMING CHAIN | 1E05 |
| 546177 | ADAPTOR | 1E11 |

| PART NUMBER | DESCRIPTION | REF.NO. |
|-------------|----------------------------|---------|
| 546203 | BREATHER FILTER | 1D12 |
| 546210 | CLIP | 1D12 |
| 546211 | CLIP | 1C08 |
| 546211 | CLIP-SPRING-FUEL BREATHER | 1N14 |
| 546211 | CLIP-SPRING-FUEL BREATHER | 1N15 |
| 546211 | HOSE CLIP | 1N16 |
| 546211 | CLIP-FUEL BREATHER PIPE | 1004 |
| 546211 | CLIP | 2L12 |
| 546211 | CLIP-HOSE | 2L16 |
| 546277 | BREATHER FILTER | 1C08 |
| 546282 | SLEEVE | 1N10 |
| 546324 | STARTING DOG | 1D04 |
| 546440 | FILLER CAP | 1C08 |
| 546457 | WASHER JOINT | 1D08 |
| 546488 | JOINT WASHER | 1002 |
| 546488 | JOINT WASHER | 1004 |
| 546540 | CLIP | 1C08 |
| 546541 | CLIP | 1C08 |
| 546548 | HOSE | 1C08 |
| 546583 | DIP STICK TUBE | 1D08 |
| 546584 | ADAPTOR | 1D08 |
| 546588 | HOSE | 1C08 |
| 546590 | UNION | 1C08 |
| 546592 | SIDE COVER-OIL FILLER PIPE | 1C08 |
| 546798 | TAPPET PUSH ROD | 1C06 |
| 546799 | PUSH ROD FOR VALVES | 1E06 |
| 546841 | JOINT WASHER SUMP | 1C07 |
| 546841 | GASKET-SUMP | 1E07 |
| 546841 | JOINT WASHER | 1E08 |
| 547968 | HOSE | 1C08 |
| 548169 | SPRING | 1L04 |
| 548205 | BUSH | 1J15 |
| 548205 | BUSH-ROAD SPRING | 1J16 |
| 548205 | BUSH-ROAD SPRING SHACKLE | 1J17 |
| 548205 | BUSH-ROAD SPRING SHACKLE | 1J18 |
| 549168 | PIVOT SHAFT | 1H12 |
| 549169 | BOLT | 1H12 |
| 549200 | SHIM | 1H09 |
| 549201 | PIVOT SHAFT | 1H12 |
| 549229 | NIPPLE | 1J02 |
| 549229 | NIPPLE-GREASE | 1J03 |
| 549229 | GREASE NIPPLE | 1J04 |
| 549229 | NIPPLE-GREASE | 1J14 |
| 549230 | SHIM | 1J08 |
| 549232 | SHIM | 1J08 |

| PART NUMBER | DESCRIPTION | REF.NO. |
|-------------|---|---------|
| 549234 | SHIM | 1J08 |
| 549236 | SHIM | 1J08 |
| 549238 | SHIM | 1J08 |
| 549240 | SHIM | 1J08 |
| 549242 | SHIM | 1J08 |
| 549244 | SHIM | 1J08 |
| 549246 | SHIM | 1J08 |
| 549248 | SHIM | 1J08 |
| 549250 | SHIM | 1J08 |
| 549252 | SHIM | 1J08 |
| 549473 | CIRCLIP | 1J11 |
| 549473 | CIRCLIP | 1J13 |
| 549475 | NUT | 1J10 |
| 549610 | ADAPTOR | 2E02 |
| 549610 | ADAPTOR | 2E03 |
| 549611 | DISTRIBUTOR DRIVE COUPLING | 2E02 |
| 549611 | COUPLING DISTRIBUTOR DRIVE | 2E03 |
| 549702 | CUP PLUG | 1C11 |
| 549761 | FUEL PUMP-MECHANICAL | 1N06 |
| 549840 | SPANNER | 2L11 |
| 549909 | PLUG | 1C04 |
| 549909 | PLUG-OIL RELIEVE VALVE | 1E04 |
| 549911 | BUSH CRANKSHAFT | 1F03 |
| 550732 | MASTER CYLINDER | 1G04 |
| 550732 | CYLINDER-CLUTCH MASTER | 2L12 |
| 551349 | BATTERY LEAD TO SOLENOID | 2F12 |
| 551436 | SPECIAL SCREW | 2F03 |
| 551508 | SWITCH | 2F09 |
| 551595 | REAR REFLECTOR | 2F05 |
| 551652 | PIPE-BRAKE | 1L09 |
| 551714 | SHROUD FOR FAN COWL | 2D02 |
| 551884 | ATTACHMENT PLATE | 2L02 |
| 552097 | BELL CRANK LEVER ASSEMBLY | 1008 |
| 552129 | HINGE CENTRE | 2I02 |
| 552132 | BRACKET | 2I02 |
| 552133 | BRACKET | 2H16 |
| 552133 | BRACKET | 2I02 |
| 552174 | FUEL TANK | 1002 |
| 552175 | FUEL TANK | 1002 |
| 552223 | TORSION SPRING | 1008 |
| 552388 | STEERING DAMPER MOUNTING BRACKET RH STG | 1K07 |
| 552407 | BRAKE ROD | 1L15 |
| 552435 | PIPE TANK TO PUMP | 1N11 |
| 552436 | PIPE TANK TO PUMP | 1N11 |
| 552436 | FUEL PIPE | 1N13 |

| PART NUMBER | DESCRIPTION | REF. NO. |
|-------------|---|----------|
| 552436 | FUEL PIPE | 1N13 |
| 552517 | INLET PIPE | 1D10 |
| 552520 | BRACKET-ACC PEDAL | 1009 |
| 552524 | BRACKET | 1010 |
| 552526 | CONTROL ROD | 1010 |
| 552574 | STEERING DAMPER MOUNTING BRACKET LH STG | 1K07 |
| 552578 | CROSS SHAFT | 1L15 |
| 552583 | RATCHET | 1L14 |
| 552681 | CLIP-FUEL PIPE | 1N12 |
| 552681 | CLIP | 1N13 |
| 552681 | CLIP | 1N13 |
| 552720 | HEAT SHIELD | 2C10 |
| 552784 | BRACKET ASSEMBLY | 1010 |
| 552804 | SPECIAL NUT | 1K02 |
| 552805 | DISTANCE PIECE | 1L14 |
| 552818 | BUSH | 1J16 |
| 552819 | BUSH FOR SHOCK ABSORBER | 1J16 |
| 552856 | PLUNGER | 1L14 |
| 552857 | WASHER | 1L14 |
| 552858 | SUPPORT PLATE | 1L15 |
| 552975 | BRACKET-ACC PEDAL | 1009 |
| 552980 | SHAFT AND LEVER | 1010 |
| 552989 | SHAFT AND LEVER | 1010 |
| 553000 | PROP SHAFT FRONT 4 CYL | 1J02 |
| 553084 | BLOCK | 1H04 |
| 553084 | BLOCK | 1H06 |
| 554049 | CLIP | 1M08 |
| 554049 | CLIP FIXING FUEL TRAP TO | 2L17 |
| 554163 | WASHER JOINT | 1C08 |
| 554163 | WASHER JOINT | 1C09 |
| 554163 | JOINT WASHER | 1M04 |
| 554175 | ADAPTOR | 1M04 |
| 554260 | CLIP WATER HOSE | 1D09 |
| 554260 | CLIP | 1E12 |
| 554260 | CLIP-BATTERY BOX TUBE | 2G04 |
| 554260 | CLIP | 2L12 |
| 554260 | CLIP | 2L14 |
| 554260 | CLIP | 2L15 |
| 554260 | CLIP-HOSE | 2L16 |
| 554383 | ELBOW | 1N02 |
| 554414 | CARB ELBOW | 1C08 |
| 554418 | HOSE | 1N02 |
| 554423 | CLIP FOR FUEL PIPE | 1N11 |
| 554541 | COVER ASSY | 1C07 |
| 554541 | FRONT COVER | 1E08 |

| PART NUMBER | DESCRIPTION | REF.NO. |
|-------------|---|---------|
| 554602 | ROCKER BRACKET | 1C06 |
| 554621 | SET BOLT (0.50" UNF X 5.1875") | 1C11 |
| 554832 | TUBE-OIL LEVEL ROD | 1D08 |
| 554834 | OIL LEVEL ROD | 1D08 |
| 554924 | FRONT COVER ASSY | 1D09 |
| 555711 | GROMMET | 1014 |
| 555711 | GROMMET | 2F15 |
| 555711 | GROMMET-RUBBER-RED | 2L09 |
| 555835 | FUEL GAUGE | 2F08 |
| 555837 | IGNITION WARNING LIGHT LENS | 2F08 |
| 555844 | GAUGE UNIT | 1002 |
| 555845 | GAUGE UNIT | 1002 |
| 555846 | GAUGE UNIT | 1002 |
| 555846 | FUEL GAUGE UNIT | 1004 |
| 555847 | GAUGE UNIT | 1002 |
| 555877 | SWITCH | 2F09 |
| 556010 | 3RD SPEED GEAR | 1H04 |
| 556239 | SPRING | 1I03 |
| 556379 | RETAINING PLATE | 1H03 |
| 556445 | SPIROLOX RING FOR FRONT AXLE | 1J10 |
| 556449 | PROP SHAFT FRONT 6 CYL | 1J02 |
| 556508 | BLEED SCREW-CLUTCH PIPE | 1G05 |
| 556508 | BLEED SCREW-CLUTCH CYLINDER | 1G05 |
| 556508 | SCREW-BLEED | 1L03 |
| 556508 | SCREW-BLEED | 1L04 |
| 556508 | BLEED SCREW | 1L02 |
| 556570 | PLUG FOR SELECTOR SPRING | 1H03 |
| 556628 | DISTANCE PIECE-FRONT AXLE | 1J10 |
| 556633 | WASHER-THRUST, CONCAVE | 1I10 |
| 557523 | LOCKER | 1C04 |
| 557523 | WASHER-LOCK | 1D06 |
| 557523 | WASHER-LOCK | 1E05 |
| 557782 | BANJO | 1D11 |
| 558168 | HOT PLUG | 1E11 |
| 558302 | OIL FEED PIPE TO CYLINDER HEAD | 1D11 |
| 559128 | LEAD | 2F15 |
| 559141 | LEAD | 2F10 |
| 559168 | CLIP | 1N12 |
| 559563 | PIN | 1L14 |
| 559636 | TOWING JAW AND PINTLE | 2L03 |
| 559705 | PLATE-EXHAUST MOUNTING TO PIPE | 2C03 |
| 559705 | MTG BRACKET FOR EXHAUST PIPE ϕ LHS | 2C05 |
| 559705 | PLATE-EXHAUST MOUNTING TO PIPE | 2C10 |
| 559705 | PLATE | 2C11 |
| 560223 | SPECIAL BOLT | 1L06 |

| PART NUMBER | DESCRIPTION | REF.NO. |
|-------------|----------------------------------|---------|
| 560567 | CABLE | 2F12 |
| 560744 | GAUGE PANEL COMPLETE | 2F08 |
| 560746 | WATER TEMPERATURE GAUGE | 2F08 |
| 560794 | WATER TEMP TRANSMITTER | 1C11 |
| 560794 | SWITCH-WATER THERMOSTAT | 1D11 |
| 560794 | SWITCH-WATER TEMPERATURE | 1E11 |
| 560887 | WHEELBOX FOR WIPER | 2F06 |
| 560967 | NUT PLATE | 2F06 |
| 561195 | STUD SHORT | 1J02 |
| 561195 | BOLT-SPECIAL | 1J03 |
| 561195 | BOLT-SPECIAL | 1J12 |
| 561196 | STUD LONG | 1J02 |
| 561196 | BOLT-SPECIAL | 1J03 |
| 561196 | BOLT-SPECIAL | 1J12 |
| 561197 | SHIM | 1H07 |
| 561221 | SPRING | 1H12 |
| 561368 | OIL CATCHER | 1L05 |
| 561434 | BOLT(0.375" WHIT X 1.90625) | 1H03 |
| 561699 | SEAL-OIL | 1I09 |
| 561856 | JOINT WASHER | 1L05 |
| 561954 | BUSH FOR REVERSE WHEEL | 1H05 |
| 561954 | BUSH-REVERSE GEAR | 1H06 |
| 562019 | PRESSURE GAUGE | 2L11 |
| 562481 | CLEVIS PIN | 1013 |
| 562481 | CLEVIS PIN FOR ACCELERATOR SHAFT | 1012 |
| 562637 | 'U' BOLT | 1J15 |
| 562641 | 'U' BOLT FRONT SPRING | 1J15 |
| 562654 | BRACKET | 1D03 |
| 562670 | BRACKET | 1010 |
| 562717 | SPRING | 1010 |
| 562731 | SILENCER RH STG | 2C06 |
| 562731 | SILENCER AND TAIL PIPE | 2C07 |
| 562737 | EXHAUST SILENCER | 2C10 |
| 562763 | HEAT SHIELD MTG BRKT BOTTOM | 2C09 |
| 562781 | HEAT SHIELD | 2C10 |
| 562785 | INTERMEDIATE EXHAUST PIPE | 2C10 |
| 562823 | PIPE CLAMP | 2C10 |
| 562823 | CLAMP | 2C11 |
| 562858 | FRONT EX PIPE | 2C03 |
| 562875 | SHAFT | 1K05 |
| 562885 | FRONT EXHAUST PIPE COMPLETE | 2C10 |
| 562912 | EXTERIOR MIRROR COMPLETE | 2G07 |
| 562915 | WATER HSE PUMP TO INLET PIPE | 1D10 |
| 562940 | GASKET-PEDAL BRACKET | 1G04 |
| 562940 | GASKET | 1L06 |

| PART NUMBER | DESCRIPTION | REF. NO. |
|-------------|-------------------------------|----------|
| 562944 | COWL FOR FAN | 2D02 |
| 562953 | 'J' BOLT | 2G04 |
| 562979 | DRIVE SCREW | 2D02 |
| 562979 | DRIVE SCREW | 2D03 |
| 563037 | IMPELLOR | 1D09 |
| 563038 | JOINT WASHER | 1D10 |
| 563047 | WATER PIPE | 1D03 |
| 563050 | WEDGELOK SCREW | 1D10 |
| 563122 | THERMOSTAT | 1D11 |
| 563132 | FAN BELT | 1C10 |
| 563132 | BELT-FAN | 1E09 |
| 563145 | CHAIN WHEEL | 1D06 |
| 563146 | FUEL PUMP | 1N10 |
| 563154 | ADAPTOR | 1D10 |
| 563165 | PIPE | 1N13 |
| 563165 | PIPE | 1N13 |
| 563166 | PIPE | 1N13 |
| 563166 | PIPE | 1N13 |
| 563167 | PIPE | 1N13 |
| 563167 | PIPE | 1N13 |
| 563168 | PIPE | 1N13 |
| 563168 | PIPE | 1N13 |
| 563190 | FUEL FILTER | 1N10 |
| 563195 | UNION | 1N10 |
| 564157 | JOINT WASHER | 1D10 |
| 564163 | TIMING POINTER | 1D09 |
| 564164 | TUBE | 1D09 |
| 564165 | CONNECTOR | 1D10 |
| 564197 | WATER PUMP | 1D09 |
| 564215 | SUMP | 1D08 |
| 564258 | 'O'RING ENGINE OIL FILLER CAP | 1C12 |
| 564258 | 'O'RING-OIL FILLER CAP | 1F10 |
| 564267 | PULLEY | 1D10 |
| 564270 | HUB | 1D09 |
| 564307 | JOINT WASHER | 1C13 |
| 564308 | CLAMP | 1C13 |
| 564308 | CLAMP-EXHAUST MANIFOLD | 1E13 |
| 564332 | INJECTOR COMPLETE | 1N10 |
| 564335 | OIL PUMP COVER | 1D05 |
| 564375 | CRANKSHAFT PULLEY | 1C03 |
| 564375 | PULLEY-CRANKSHAFT | 1E03 |
| 564394 | FLYWHEEL HOUSING | 1G02 |
| 564446 | ADAPTOR | 1M05 |
| 564447 | WASHER | 1N02 |
| 564456 | SPRING | 1C04 |

| PART NUMBER | DESCRIPTION | REF. NO. |
|-------------|------------------------------------|----------|
| 564456 | SPRING-OIL RELIEVE VALVE | 1E04 |
| 564463 | CHAIN WHEEL | 1D04 |
| 564467 | BAFFLE PLATE | 1E09 |
| 564470 | TIMING POINTER | 1E09 |
| 564495 | DISTRIBUTOR PUMP | 1N10 |
| 564574 | STUD | 1C11 |
| 564603 | PIPE | 1M05 |
| 564704 | FRONT BUMPER | 2G02 |
| 564718 | OVERFLOW BOTTLE | 2D02 |
| 564719 | CAP FOR OVERFLOW BOTTLE | 2D02 |
| 564720 | HOSE RADIATOR TO OVERFLOW BOTTLE | 2D02 |
| 564724 | FLEXIBLE PIPE OVERFLOW BTLE OUTLET | 2D02 |
| 564792 | EXTENSION SHAFT | 1010 |
| 564793 | EXTENSION SHAFT | 1010 |
| 564794 | CONTROL ROD | 1010 |
| 564797 | CONTROL ROD | 1010 |
| 564813 | PEDAL SHAFT | 1L06 |
| 564816 | PEDAL BUSH | 1L06 |
| 564825 | WASHER SPRING | 1K05 |
| 564893 | PACKING PIECE | 1N03 |
| 564898 | PIPE | 1N13 |
| 564898 | PIPE | 1N13 |
| 564899 | PIPE | 1N13 |
| 564899 | PIPE | 1N13 |
| 564902 | PIPE | 1N13 |
| 564902 | PIPE | 1N13 |
| 564905 | PIPE | 1N13 |
| 564905 | PIPE | 1N13 |
| 564907 | PIPE | 1N13 |
| 564907 | PIPE | 1N13 |
| 564911 | BRACKET FOR ACCELERATOR CONTROL | 1012 |
| 564944 | PACKING PIECE | 1L07 |
| 564944 | PACKING PIECE | 1L07 |
| 564962 | PIPE | 1N13 |
| 564962 | PIPE | 1N13 |
| 564999 | JOINT WASHER FOR FILLER CAP | 2D02 |
| 565434 | PLUG SPANNER | 2L11 |
| 565443 | TOMMY BAR | 2L11 |
| 565466 | BRAKE PIPE MASTER CYLINDER | 1L09 |
| 565656 | HOSE CLIP | 1N17 |
| 565656 | CLIP ELBOW TO TEE PIECE | 2K14 |
| 565656 | CLIP | 2L15 |
| 565668 | CONNECTOR TUBE | 1L07 |
| 565668 | CONNECTOR TUBE BRAKE PIPE TO | 1L07 |
| 565719 | 4 WAY CONNECTION FOR BRAKE | 1L09 |

| PART NUMBER | DESCRIPTION | REF.NO. |
|-------------|----------------------------------|---------|
| 566222 | RUBBER-ENGINE MOUNTING | 1F02 |
| 566222 | RUBBER-GEARBOX MOUNTING | 1I05 |
| 566222 | RUBBER-GEARBOX MOUNTING | 1I05 |
| 566222 | MOUNTING RUBBER | 1I05 |
| 566426 | ACCELERATOR CABLE | 1013 |
| 566851 | FLYWHEEL ASSEMBLY | 1G03 |
| 566859 | DISTRIBUTOR CAP | 2E02 |
| 566957 | BREATHER PIPE | 1D09 |
| 567959 | MOUNTING CLIP | 2F09 |
| 568055 | SWITCH-WATER TEMPERATURE | 1F07 |
| 568189 | PETROL PUMP ELECTRIC | 1N08 |
| 568244 | EARTHING BRAID STRIP UPPER | 1N08 |
| 568244 | EARTH STRIP | 1N08 |
| 568301 | SEAL-WATER PUMP | 1D09 |
| 568333 | CHAIN WHEEL | 1C03 |
| 568333 | CHAINWHEEL-CRANKSHAFT | 1E03 |
| 568335 | HEATER PLUG | 1E11 |
| 568364 | JOINT WASHER | 1M05 |
| 568364 | JOINT WASHER-CARBURETTER ADAPTOR | 1M07 |
| 568364 | JOINT WASHER FOR ADAPTOR | 2L17 |
| 568365 | JOINT WASHER | 1M05 |
| 568365 | JOINT WASHER-CARBURETTER ADAPTOR | 1M07 |
| 568380 | ADAPTOR | 1N02 |
| 568391 | HOSE | 1D12 |
| 568392 | CLIP | 1D12 |
| 568431 | RING GEAR | 1G03 |
| 568457 | ADAPTOR TEMP TRANSMITTER | 1C11 |
| 568474 | CHAINWHEEL FOR CAMSHAFT | 1C05 |
| 568475 | PUSH ROD | 1D07 |
| 568542 | COVER | 1E09 |
| 568550 | VALVE SPRING | 1C06 |
| 568550 | SPRING-VALVE | 1E06 |
| 568575 | OLIVE | 1N12 |
| 568664 | STUD | 1C13 |
| 568664 | STUD | 1E13 |
| 568686 | VALVE GUIDE-INLET | 1C11 |
| 568687 | VALVE GUIDE-EXHAUST | 1C11 |
| 568688 | VALVE GUIDE ASSEMBLY | 1E11 |
| 568689 | VALVE GUIDE ASSEMBLY | 1E11 |
| 568725 | COVER ASSEMBLY | 1D12 |
| 568786 | EXHAUST VALVE | 1D07 |
| 568788 | PULLEY ALTERNATOR 2.25 LITRE | 2E10 |
| 568788 | PULLEY-ALTERNATOR | 2E14 |
| 568789 | ALTERNATOR ADJUSTING LINK | 2E11 |
| 568789 | LINK-ALTERNATOR ADJUSTING | 2E15 |

| PART NUMBER | DESCRIPTION | REF. NO. |
|-------------|---------------------------------|----------|
| 568802 | SUPPORT FOR FUEL TANK | 1005 |
| 568805 | AIR CLEANER | 1N03 |
| 568858 | RUBBER BUSH | 1K08 |
| 568858 | STEM RUBBER FOR STEERING DAMPER | 1K07 |
| 568883 | SPINDLE-CLUTCH PEDAL | 1G04 |
| 568883 | TRUNNION | 1L06 |
| 568893 | PEDAL & BRACKET ASSEMBLY | 1G04 |
| 568894 | PEDAL & BRACKET ASSEMBLY | 1G04 |
| 568895 | PEDAL AND BUSHES | 1G04 |
| 568896 | PEDAL AND BUSHES | 1G04 |
| 568916 | COWL FOR FAN | 2D02 |
| 568917 | SHROUD FOR FAN COWL | 2D02 |
| 569005 | STEERING DAMPER | 1K07 |
| 569028 | 'U' BOLT | 1J15 |
| 569047 | PLUG-WATER DRAIN | 1C02 |
| 569047 | PLUG-WATER DRAIN | 1E02 |
| 569047 | DRAIN PLUG FOR RADIATOR | 2D02 |
| 569054 | BRAKE PEDAL & BRACKET ASSY | 1L06 |
| 569055 | PEDAL BRACKET | 1L06 |
| 569057 | PEDAL BRACKET | 1L06 |
| 569058 | BRACKET | 1L06 |
| 569084 | BRAKE PEDAL & BRACKET ASSY | 1L06 |
| 569085 | PEDAL BRACKET | 1L06 |
| 569086 | PEDAL & BUSHES | 1L06 |
| 569096 | NYLON SPACER | 1L07 |
| 569096 | SPACER FOR MASTER CYLINDER | 1L07 |
| 569117 | END STOP | 1L06 |
| 569117 | END STOP-SWITCH TO HANDBRAKE | 2L13 |
| 569201 | SWITCH PROTECTOR PLATE | 1L06 |
| 569204 | WHEEL-ROAD | 1J18 |
| 569212 | SHROUD FOR FAN COWL | 2D02 |
| 569291 | SPRING | 1L06 |
| 569291 | SPRING-BRAKE-PEDAL RETURN | 2L13 |
| 569338 | SERVO UNIT | 1L07 |
| 569339 | CYLINDER-BRAKE MASTER | 1L07 |
| 569434 | PIPE | 1L07 |
| 569492 | GROMMET | 2K14 |
| 569522 | PACKING PIECE | 1K04 |
| 569584 | SWITCH LEVER | 1L06 |
| 569601 | PEDAL BRACKET | 1L06 |
| 569606 | BRACKET | 1L06 |
| 569609 | NYLON BUSH | 1L06 |
| 569609 | BUSH-STOP LIGHT MOUNTING | 2L13 |
| 569652 | PEDAL & BRACKET ASSEMBLY | 1L06 |
| 569652 | BRAKE PEDAL AND BRACKET | 2L13 |

| PART NUMBER | DESCRIPTION | REF.NO. |
|-------------|-----------------------------------|---------|
| 569687 | WHEEL NUT WRENCH | 2L11 |
| 569693 | FRONT EXHAUST PIPE | 2C10 |
| 569701 | SPRING-CLUTCH PEDAL | 1G04 |
| 569701 | RETURN SPRING | 1L06 |
| 569701 | SPRING-CLUTCH PEDAL | 2L12 |
| 569746 | BUSH SPRING | 1J15 |
| 570091 | PIPE-BRAKE REAR TO TEE PIECE | 1L09 |
| 570351 | CLIP CUTOUT SWITCH CAPILLARY TUBE | 2F06 |
| 570753 | FLANGE FINISHER | 2H02 |
| 570753 | FLANGE FINISHER | 2H05 |
| 570753 | FLANGE FINISHER | 2H07 |
| 570822 | BULB | 2F03 |
| 570822 | BULB-NUMBER PLATE LAMP | 2F04 |
| 571043 | SELECTOR PAD | 1I12 |
| 571059 | SEAL | 1H03 |
| 571059 | SEAL-OIL-GEARBOX | 1H04 |
| 571059 | SEAL-OIL | 1I03 |
| 571059 | SEAL-OIL | 1I06 |
| 571062 | BEARING-ROLLER | 1I06 |
| 571063 | WASHER-THRUST | 1I06 |
| 571064 | BEARING-THRUST | 1I06 |
| 571065 | WASHER-THRUST | 1I06 |
| 571066 | WASHER-THRUST GEARBOX | 1I06 |
| 571067 | BEARING-THRUST GEARBOX | 1I06 |
| 571090 | CIRCLIP | 1I06 |
| 571134 | SPINDLE | 1I03 |
| 571137 | GASKET-FRONT COVER AND OIL PUMP | 1I03 |
| 571139 | RETAINER | 1I03 |
| 571142 | SEAL-OIL | 1I06 |
| 571144 | CIRCLIP | 1I09 |
| 571144 | CIRCLIP | 1I09 |
| 571145 | ROLL PIN | 1H11 |
| 571145 | ROLL PIN | 1I12 |
| 571146 | BALL-STEEL | 1I10 |
| 571146 | BALL-STEEL | 1I12 |
| 571158 | ROLL-PIN | 1I10 |
| 571158 | ROLL PIN | 1I12 |
| 571160 | PUSH ROD-CLUTCH CYLINDER | 1G05 |
| 571161 | INSERT CLUTCH RELEASE LEVER | 1G05 |
| 571163 | CLIP CLUTCH RELEASE LEVER | 1G05 |
| 571164 | CAP-CLUTCH RELEASE LEVER | 1G05 |
| 571164 | CAP CLUTCH RELEASE LEVER PIVOT | 1H03 |
| 571168 | PLUG | 1I03 |
| 571174 | WASHER-PLAIN | 1I10 |
| 571175 | SEAL-OIL | 1I10 |

| PART NUMBER | DESCRIPTION | REF.NO. |
|-------------|------------------------------------|---------|
| 571177 | EXCLUDER-MUD | 1I10 |
| 571187 | BEARING-ROLLER | 1I06 |
| 571235 | DRIVING MEMBER | 1J10 |
| 571439 | SPRING | 1I12 |
| 571447 | BOLT | 1J04 |
| 571452 | SHIM | 1I06 |
| 571453 | SHIM | 1I06 |
| 571454 | SHIM | 1I06 |
| 571455 | SHIM | 1I06 |
| 571468 | WASHER-SPACING | 1I11 |
| 571661 | TOLERANCE RING | 1H11 |
| 571665 | SEAL-OIL | 1I11 |
| 571682 | CIRCLIP | 1I11 |
| 571711 | DRIVING MEMBER | 1J10 |
| 571711 | DRIVING MEMBER | 1J11 |
| 571711 | DRIVE MEMBER-REAR AXLE | 1J13 |
| 571718 | SEAL-OIL | 1J05 |
| 571723 | WASHER-PLAIN | 1I04 |
| 571723 | WASHER-THRUST | 1I06 |
| 571732 | SLEEVE-EXTENSION-FRONT COVER | 1I03 |
| 571770 | INNER MEMBER TRANSFER CHANGE SPEED | 1H07 |
| 571837 | JOINT WASHER | 1I04 |
| 571838 | SEAL-OIL | 1I06 |
| 571841 | GASKET-GEARBOX SIDE COVER | 1I04 |
| 571846 | GASKET-REAR MAIN BEARING HOUSING | 1I04 |
| 571855 | SELECTOR ROD | 1H12 |
| 571875 | LOCK-UP DOG-TRANSFER BOX | 1I10 |
| 571876 | GASKET | 1I05 |
| 571885 | WASHER-THRUST | 1I09 |
| 571885 | WASHER-THRUST | 1I09 |
| 571922 | WASHER | 1J10 |
| 571930 | WASHER-THRUST | 1I06 |
| 571931 | WASHER-THRUST GEARBOX | 1I06 |
| 571940 | GASKET-REAR COVER | 1I05 |
| 571944 | PLUG-GEARBOX | 1I04 |
| 571947 | HOUSING-VACUUM ACTUATOR | 1I05 |
| 571956 | SELECTOR FORK | 1I10 |
| 571957 | VACUUM ACTUATOR | 1I10 |
| 571959 | HOUSING-VACUUM ACTUATOR | 1I05 |
| 571962 | PLUNGER-SELECTOR-SHAFT | 1I12 |
| 571969 | WASHER-PLAIN-SPECIAL | 1L05 |
| 571970 | SHIELD-OIL | 1I11 |
| 571971 | CATCHER-OIL-TRANSMISSION | 1L05 |
| 571977 | COVER-BOTTOM-TRANSFER CASING | 1I04 |
| 571979 | GASKET-TOP COVER | 1I05 |

| PART NUMBER | DESCRIPTION | REF. NO. |
|-------------|----------------------------------|----------|
| 571980 | PIN-DETENT SPRING | 1I12 |
| 571981 | SHAFT-GEAR CHANGE | 1I12 |
| 571982 | LEVER-GEAR SELECTOR | 1I12 |
| 571983 | LEVER-GEAR SELECTOR | 1I12 |
| 571991 | SEAL-OIL | 1I10 |
| 572166 | RUBBER BUSH | 2C11 |
| 572167 | RUBBER BUSH | 2C11 |
| 572168 | INSULATING WASHER | 2C11 |
| 572313 | DISTANCE TUBE | 2D03 |
| 572535 | ADAPTOR | 1N08 |
| 572535 | REDUCER ADAPTOR FOR FUEL PIPES | 1N08 |
| 572541 | HOSE CLIP | 1N05 |
| 572548 | CORBIN CLIP | 1L07 |
| 572772 | HOSE PIPE TO MASTER CYLINDER | 1L07 |
| 572839 | HOSE CLIP FUEL PIPES | 1N11 |
| 572839 | CLIP-FUEL PIPE HOSE | 1N12 |
| 572839 | HOSE CLIP | 1N14 |
| 572839 | HOSE CLIP-FUEL BREATHER PIPE | 1N17 |
| 572839 | CLIP-BREATHER HOSE | 1003 |
| 572839 | HOSE CLIP-FUEL BREATHER PIPE | 1004 |
| 572839 | CLIP-BREATHER HOSE | 1006 |
| 572839 | CLIP-BREATHER CONNECTION | 2L14 |
| 572839 | CLIP | 2L15 |
| 572994 | TRUNNION PIN | 1N04 |
| 573038 | IGNITION COIL | 2F09 |
| 574044 | FAN BLADE | 1D10 |
| 574048 | STUD | 1C13 |
| 574048 | STUD | 2L12 |
| 574262 | CONNECTING PIPE | 1C08 |
| 574264 | BRACKET | 1C08 |
| 574654 | CLIP | 1E12 |
| 574656 | CONNECTING TUBE | 1E13 |
| 574658 | BREATHER FILTER | 1E12 |
| 574661 | INLET MANIFOLD | 1E13 |
| 574749 | ADAPTOR ASSEMBLY | 1C08 |
| 574750 | HOSE | 1C08 |
| 574855 | BRACKET-ALTERNATOR FIXINGS | 2E15 |
| 574855 | MOUNTING BRACKET FOR ALTERNATOR | 2E11 |
| 574871 | HOSE | 1C10 |
| 574871 | HOSE-WATER | 1E10 |
| 574878 | RUBBER SLEEVE-SUCTION PIPE | 1M04 |
| 574878 | CONNECTOR-RUBBER-VACUUM PIPE | 1M05 |
| 574948 | SPACER FRONT COVER | 1E08 |
| 574948 | SPACER ALTERNATOR ADJUSTING LINK | 1C07 |
| 575014 | SPRING WASHER | 2F12 |

| PART NUMBER | DESCRIPTION | REF.NO. |
|-------------|------------------------------------|---------|
| 575047 | OUTER CASING | 2F06 |
| 575092 | LEAD COIL TO CARBURETTER SOLENOID | 2L12 |
| 575123 | FLASHER LAMP COMPLETE | 2F04 |
| 575125 | FLASHER LAMP COMPLETE | 2F04 |
| 575146 | SWITCH | 2F15 |
| 575166 | MECHANICAL STOP SWITCH | 1L06 |
| 575166 | SWITCH-STOP LIGHT-MECHANICAL | 2L13 |
| 575312 | BULB | 2F04 |
| 575373 | MAIN HARNESS RHD | 2F10 |
| 575383 | INDICATOR HEADLAMP DIP AND | 2F09 |
| 575390 | BRKT FOR COMBINED SWITCHES | 2F09 |
| 575395 | FUSE UNIT BOX | 2F09 |
| 575396 | FUEL LEVEL WARNING LIGHT | 2F07 |
| 575408 | MAIN HARNESS LHD | 2F10 |
| 575437 | WIPER BLADE | 2F06 |
| 575457 | FRONT FLASHER LAMP | 2F04 |
| 575651 | BRACKET-GEARBOX MOUNTING | 1I05 |
| 575651 | MOUNTING BRACKET | 1I05 |
| 575718 | TOP HOSE | 2D04 |
| 576137 | CLUTCH RELEASE LEVER ASSY | 1G05 |
| 576149 | RETAINER | 1I12 |
| 576149 | RETAINER | 1I12 |
| 576159 | PIN | 1J07 |
| 576195 | GASKET-GEAR TOP COVER | 1I04 |
| 576201 | LOW GEAR WHEEL | 1H07 |
| 576203 | STAPLE CLUTCH LEVER TO | 1G05 |
| 576209 | OUTER MEMBER-TRANSFER CHANGE SPEED | 1H07 |
| 576210 | TRANSFER GEAR CHANGE LEVER | 1H13 |
| 576220 | FILTER-OIL-GEARBOX | 1I04 |
| 576236 | SHIM | 1J08 |
| 576237 | SHIM | 1J08 |
| 576238 | SHIM | 1J08 |
| 576239 | SHIM | 1J08 |
| 576316 | KNOB | 1H11 |
| 576319 | BOLT-SPECIAL | 1I13 |
| 576320 | PLUG-RETAINING GEAR LEVER | 1I13 |
| 576340 | OIL PUMP AND FRONT COVER | 1I03 |
| 576342 | GEAR AND SPINDLE-OIL PUMP | 1I03 |
| 576343 | LAYSHAFT CLUSTER | 1I09 |
| 576351 | SHIM | 1I09 |
| 576352 | SHIM | 1I09 |
| 576353 | SHIM | 1I09 |
| 576354 | SHIM | 1I09 |
| 576355 | SHIM | 1I09 |
| 576356 | SHIM | 1I09 |

| PART NUMBER | DESCRIPTION | REF. NO. |
|-------------|--------------------------------------|----------|
| 576357 | SHIM | 1I09 |
| 576358 | SHIM | 1I09 |
| 576359 | SHIM | 1I09 |
| 576360 | SHIM | 1I09 |
| 576361 | SHIM | 1I09 |
| 576362 | SHIM | 1I09 |
| 576363 | SHIM | 1I09 |
| 576364 | SHIM | 1I09 |
| 576365 | SHIM | 1I09 |
| 576366 | SHIM | 1I09 |
| 576367 | SHIM | 1I09 |
| 576368 | SHIM | 1I09 |
| 576369 | SHIM | 1I09 |
| 576370 | SHIM | 1I09 |
| 576476 | COVER-CLUTCH | 1G03 |
| 576521 | BOLT(0.375 BSF X 1.375) | 1J05 |
| 576521 | BOLT-SPECIAL | 1L02 |
| 576521 | BOLT | 1L04 |
| 576522 | BOLT 0.375 BSF X 1.50" | 1J05 |
| 576557 | CLUTCH COVER COMPLETE | 1G02 |
| 576557 | CLUTCH COVER | 1G03 |
| 576583 | SWIVEL PIN UPPER COMPLETE | 1J06 |
| 576627 | HUB-OUTPUT GEAR | 1I11 |
| 576656 | LEVER-SELECTOR | 1I12 |
| 576683 | BEARING-INTERMEDIATE GEARS | 1I09 |
| 576686 | LAYSHAFT CLUSTER-ALL SYNCHRO GEARBOX | 1H05 |
| 576703 | FORK | 1H11 |
| 576704 | FORK | 1H11 |
| 576707 | REVERSE GEAR | 1H05 |
| 576714 | BELL HOUSING | 1H02 |
| 576717 | SERRATED BOLT-0.3125 cBSF X 2 LONG | 1H03 |
| 576718 | FRONT COVER ASSY GEARBOX | 1H03 |
| 576720 | PIVOT-CLUTCH RELEASE | 1G05 |
| 576720 | PIVOT PIN CLUTCH RELEASE | 1H03 |
| 576723 | CLIP | 1G05 |
| 576724 | JOINT WASHER G/BOX FRT COVER | 1H03 |
| 576725 | MAINSHAFT | 1H04 |
| 576726 | MAINSHAFT | 1H04 |
| 576729 | SELECTOR SHAFT | 1H11 |
| 576730 | R GEARBOX ASSEMBLY REBUILT | 1H02 |
| 576734 | BUSH | 1H04 |
| 576735 | THRUST WASHER | 1H04 |
| 576751 | PUSH ROD SLAVE CYLINDER | 1G05 |
| 576761 | R GEARBOX ASSEMBLY REBUILT | 1H02 |
| 576762 | BELL HOUSING | 1H02 |

| PART NUMBER | DESCRIPTION | REF.NO. |
|-------------|-------------------------------------|---------|
| 576767 | HALF SHAFT | 1J13 |
| 576768 | HALF SHAFT | 1J13 |
| 576777 | HALFSHAFT AND JOINT RH FOR | 1J05 |
| 576778 | HALFSHAFT AND JOINT LH FOR | 1J05 |
| 576779 | ROLL-PIN | 1I12 |
| 576825 | STUD | 1J10 |
| 576825 | STUD | 1J11 |
| 576825 | STUD | 1J13 |
| 576843 | BAFFLE-GEARBOX BREATHER | 1I05 |
| 576844 | HUB ASSEMBLY | 1J10 |
| 576844 | HUB-REAR | 1J13 |
| 576895 | LOCK TAB | 1J07 |
| 576907 | DISTANCE PIECE FOR BEARING | 1H05 |
| 576973 | BRAKE DRUM | 1L04 |
| 576973 | BRAKE DRUM | 1L03 |
| 576974 | BRAKE DRUM | 1L03 |
| 577020 | BATTERY FRAME | 2G04 |
| 577095 | OPERATING LEVER HAND CONTROL | 1014 |
| 577098 | BASE PLATE FOR HAND CONTROL | 1014 |
| 577111 | KNOB FOR HAND CONTROL | 1014 |
| 577127 | SHFT LEVER FOR HAND-CONTROL | 1014 |
| 577137 | SHAFT HAND BRAKE LEVER | 1L15 |
| 577138 | WASHER PLATE | 1L15 |
| 577230 | CNTRL ROD PEDAL TO RELAY AND ENGINE | 1008 |
| 577258 | BRACKET FOR ACCELERATOR CONTROLS | 1008 |
| 577262 | BRACKET FOR STG COLUMN MTG | 1K04 |
| 577271 | BOLT SELF LOCK STEERING UNIT | 1K04 |
| 577272 | BOLT SELF LOCK STEERING UNIT | 1K04 |
| 577304 | ACCELERATOR RELAY SHAFT | 1007 |
| 577304 | SHAFT-ACCELERATOR LEVERS | 1011 |
| 577338 | SEALING PAD FOR HAND-CONTROL | 1014 |
| 577342 | COWL FOR FAN | 2D02 |
| 577346 | HOSE FOR RADIATOR TOP | 2D02 |
| 577354 | WASHER | 1L15 |
| 577383 | RADIATOR BLCK ASSY-(LESS-COWL) | 2D02 |
| 577384 | PROTECTION PLATE FOR PIPE | 2K14 |
| 577384 | PLATE-FUEL PIPE PROTECTION | 2L15 |
| 577414 | CROSSMEMBER NO 3 ASSEMBLY | 2G02 |
| 577458 | RUBBER ELBOW JOINING PIPES | 1N17 |
| 577458 | ELBOW-RUBBER | 2L14 |
| 577458 | ELBOW-RUBBER-JOINING PIPES | 2L15 |
| 577459 | RUBBER CONNECTION | 2K14 |
| 577464 | ELBOW | 2K14 |
| 577464 | ELBOW | 2L15 |
| 577465 | CONNECTOR | 2K14 |

| PART NUMBER | DESCRIPTION | REF. NO. |
|-------------|--------------------------------------|----------|
| 577465 | CONNECTOR | 2L15 |
| 577466 | BREATHER HOSE | 2K14 |
| 577466 | HOSE-BREATHER | 2L15 |
| 577472 | DUST SHIELD FOR OUTER COLUMN | 1K02 |
| 577609 | RADIATOR 4 CYLINDER | 2D02 |
| 577664 | PIPE SUPPLY TANK TO BRAKE | 1L07 |
| 577664 | PIPE-SUPPLY TANK TO BRAKE | 1L07 |
| 577665 | PIPE-SUPPLY TANK TO BRAKE | 1L07 |
| 577665 | PIPE-SUPPLY TANK TO MASTER | 1L07 |
| 577679 | BRAKE PIPE RH JUMP HOSE TO | 1L09 |
| 577681 | BRAKE HOSE FRONT | 1L09 |
| 577687 | BRAKE PIPE COMPLETE CLUTCH MASTER | 1G04 |
| 577694 | PIPE-MASTER CYLINDER TO | 1L07 |
| 577695 | PIPE-MASTER CYLINDER TO | 1L07 |
| 577697 | MOUNTING BRACKET-JUMP HOSE | 1L09 |
| 577697 | MOUNTING BRACKET | 1L10 |
| 577697 | MOUNTING BRACKET | 1L11 |
| 577697 | BRACKET-JUMP HOSE | 1L12 |
| 577697 | MOUNTING BRACKET | 1L13 |
| 577844 | HOSE-SERVO TO MANIFOLD | 1L07 |
| 577846 | SHIELD-HEAT RH | 1F02 |
| 577874 | STEADY STRIP FOR SHROUD | 2D02 |
| 577898 | CLIP FOR TIE ROD BALL JOINT | 1K06 |
| 577898 | CLIP-STEERING TUBES | 1K07 |
| 577898 | CLAMP | 1K08 |
| 577927 | CLIP FOR TRACK ROD | 1K06 |
| 578023 | SPECIAL NUT 0.25" UNF | 1N04 |
| 578086 | HOSE-SERVO TO MANIFOLD-LHSTG | 1L07 |
| 579006 | WIPER WASHER SWITCH | 2F09 |
| 579014 | CABLE PETROL PUMP FEED | 2F10 |
| 579023 | WARNING LIGHT DIRECTION INDICATORS | 2F07 |
| 579025 | LEAD FOR SOLENOID SWITCH | 2F12 |
| 579027 | SWITCH WIPER | 2F09 |
| 579054 | LEAD FOR ROOF LAMP RH STG | 2F06 |
| 579058 | LEAD FOR ROOF LAMP LH STG | 2F06 |
| 579121 | INSPECTION LIGHT SOCKET RED | 2F09 |
| 579122 | INSPECTION LIGHT SOCKET BLACK | 2F09 |
| 579198 | SPEEDOMETER MPH | 2F08 |
| 579243 | LEAD TO DISTRIBUTOR | 2F10 |
| 586440 | CLIP PIPE | 1F10 |
| 586742 | SWITCH-OIL PRESSURE | 1F05 |
| 587001 | SHIELD | 2E04 |
| 587077 | MTG BRKT REAR FOR ALTERNATOR 2-LITRE | 2E13 |
| 587078 | MTG BRKT FRONT FOR ALTERNATOR | 2E13 |
| 587080 | SPACER FOR ALTERNATOR BRKT | 2E13 |

| PART NUMBER | DESCRIPTION | REF. NO. |
|-------------|------------------------------------|----------|
| 587095 | SHIELD | 2C02 |
| 587104 | HOSE FLAME TRAP TO CARBURETTER | 1D09 |
| 587105 | HOSE | 1D09 |
| 587119 | CLIP-HOSE | 2L16 |
| 587119 | CLIP PIPE TO ROCKER COVER | 2L12 |
| 587120 | HOSE ELBOW TO FLAME TRAP | 2L16 |
| 587338 | SET BOLT 0.4375UNF X 5.15625 | 1D12 |
| 587339 | PLAIN WASHER-CYL HEAD BOLT | 1D12 |
| 587401 | EXHAUST MANIFOLD ASSY | 1D13 |
| 587405 | PLAIN WASHER | 1C13 |
| 587433 | ADJUSTING LINK FOR | 2E13 |
| 587463 | WATER OUTLET PIPE 2 6 LITRE | 1D11 |
| 587468 | DRIVING BELT | 1D10 |
| 587499 | MOUNTING BRACKET FOR VACUUM SWITCH | 2L15 |
| 587502 | BANJO BOLT | 1C13 |
| 587502 | BANJO BOLT | 2L15 |
| 587517 | SERVO ADAPTOR | 2L15 |
| 587522 | PULLEY FOR ALTERNATOR 2 6 LITRE | 2E12 |
| 587622 | SUPPORT PLATE | 1G04 |
| 587628 | CUP PLUG | 1C02 |
| 587628 | CORE PLUG | 1E02 |
| 587653 | AIR CONTROL VALVE. | 1N06 |
| 587659 | FUEL PIPE FILTER TO CARBURETTER | 1N12 |
| 587684 | FUEL PIPE PETRO-FLEX PIPE | 1N11 |
| 587686 | FUEL PIPE AND CONNECTION | 1N11 |
| 587723 | PLUG 0.50 UNF | 1D13 |
| 587726 | STUD INLET MANIFOLD | 1C13 |
| 587923 | PLUG | 1D08 |
| 587986 | HOSE BREATHER TO THROTTLE BODY | 1E12 |
| 589018 | CABLE ASSEMBLY | 2F04 |
| 589026 | CABLE ASSY NO PLATE LAMP | 2F04 |
| 589033 | CABLE ENGINE HARNESS | 2F10 |
| 589034 | CABLE ENGINE HARNESS DIESEL | 2F11 |
| 589035 | CABLE ENGINE HARNESS | 2F10 |
| 589063 | SWITCH-HANDBRAKE | 2L13 |
| 589115 | BRACKET FOR CHOKE CONTROL | 1014 |
| 589202 | LENS-FLASHER-REAR | 2F04 |
| 589208 | SADDLE-BRKT FOR STARTER-SWITCH | 1014 |
| 589210 | LEAD SHUTTLE VALVE SWITCH | 2L13 |
| 589219 | SWITCH, VACUUM LOSS | 2F13 |
| 589219 | VACUUM LOSS SWITCH | 2L13 |
| 589223 | SWITCH, PEDAL TRAVEL | 2F13 |
| 589283 | SIDE LAMP LENS | 2F03 |
| 589284 | SIDE LAMP LENS | 2F03 |
| 589285 | FRONT FLASHER LAMP LENS | 2F04 |

| PART NUMBER | DESCRIPTION | REF. NO. |
|-------------|------------------------------------|----------|
| 589289 | CLIP | 2L08 |
| 589403 | SIDE LAMP COMPLETE | 2F03 |
| 589404 | SIDE LAMP COMPLETE | 2F03 |
| 589409 | FRONT FLASHER LAMP COMPLETE | 2F04 |
| 589414 | LAMP-FLASHER-REAR | 2F04 |
| 589419 | STOP TAIL LAMP | 2F03 |
| 589420 | LENS FOR STOP TAIL LAMP | 2F03 |
| 589446 | STOP/TAIL LAMP COMPLETE | 2F03 |
| 589448 | STOP/TAIL LAMP LENS | 2F03 |
| 589452 | GROMMET | 2L09 |
| 589553 | STRIKER ASSEMBLY | 1K02 |
| 589665 | RELAY-STARTER | 2F09 |
| 589665 | RELAY | 2F13 |
| 589705 | CABLE ASSEMBLY CHASSIS HARNESS | 2F10 |
| 589706 | CABLE ASSEMBLY CHASSIS HARNESS | 2F10 |
| 589707 | CABLE ASSEMBLY CHASSIS HARNESS | 2F10 |
| 589708 | CABLE CHASSIS HARNESS | 2F11 |
| 589709 | CABLE CHASSIS HARNESS | 2F11 |
| 589710 | CABLE CHASSIS HARNESS | 2F11 |
| 589806 | CLIP | 1G04 |
| 589806 | CLIP-PIPE | 1N12 |
| 589812 | STOP TAIL LAMP | 2F03 |
| 589812 | LAMP-STOP TAIL | 2F03 |
| 589851 | CABLE ENGINE HARNESS | 2F10 |
| 589853 | CABLE ENGINE HARNESS | 2F10 |
| 589872 | HEAVY CABLE BATTERY-EARTH NEGATIVE | 2F12 |
| 589877 | REFLECTOR | 2F05 |
| 589878 | LEAD STARTER MOTOR TO EARTH | 2F12 |
| 591039 | BRAKE DRUM | 1L04 |
| 591039 | BRAKE DRUM 88 | 1L02 |
| 591231 | SLAVE CYLINDER | 1G05 |
| 591278 | PROPELLOR SHAFT | 1J03 |
| 591279 | REAR PROPELLOR SHAFT | 1J14 |
| 591283 | REAR PROPELLOR SHAFT | 1J14 |
| 591290 | PLUG-CUP | 1I04 |
| 591320 | SPRING | 1I12 |
| 591345 | WASHER-PLAIN | 1I10 |
| 591362 | GEAR 1ST MAINSHAFT | 1H04 |
| 591363 | 2ND SPEED GEAR | 1H04 |
| 591364 | SYNCHRO CONE | 1H04 |
| 591378 | AXLE SHAFT | 1J12 |
| 591379 | AXLE SHAFT | 1J12 |
| 591394 | RING-OIL FEED | 1I03 |
| 591429 | REAR OUTPUT SHAFT | 1H07 |
| 591519 | SPRING PIN-REVERSE GEAR SHAFT | 1H05 |

| PART NUMBER | DESCRIPTION | REF. NO. |
|-------------|------------------------------|----------|
| 591527 | SHAFT FOR REVERSE GEAR | 1H05 |
| 591603 | SOUND DEADNING-G/BOX TOP COV | 1I05 |
| 591891 | GEAR-LOW RANGE | 1I09 |
| 591900 | WASHER-THRUST | 1I09 |
| 591988 | BACKING PLATE SEALING GASKET | 1G05 |
| 592177 | PLATE BOTTOM-ROAD SPRING | 1J16 |
| 592179 | PLATE-BOTTOM-ROAD SPRING | 1J18 |
| 592179 | BOTTOM PLATE | 1J17 |
| 592182 | 'U' BOLT | 1J17 |
| 592183 | U BOLT | 1J18 |
| 592184 | U BOLT | 1J16 |
| 592185 | U BOLT | 1J16 |
| 592219 | JACK ROD | 2L11 |
| 592269 | DISTANCE PLATE-FUEL FILTER | 1N09 |
| 592269 | DISTANCE PIECE-FILTER BOWL | 2L15 |
| 592306 | DISTANCE PIECE | 1007 |
| 592306 | PCKNG-ACCELERATOR X-SHAFT | 1011 |
| 592309 | FUEL PIPE PUMP TO FILTER | 1N12 |
| 592324 | NYLON FILTER FOR SUPPLY TANK | 1L07 |
| 592324 | FILTER | 1L08 |
| 592324 | FILTER-BRAKE FLUID RESERVOIR | 2L13 |
| 592325 | FILTER-NYLON-SUPPLY TANK | 1L07 |
| 592325 | FILTER-NYLON-SUPPLY TANK | 1L07 |
| 592326 | PETROL CATCH TANK | 2K14 |
| 592326 | TANK | 2L15 |
| 592358 | GASKET-MASTER CYLINDER | 1G04 |
| 592358 | GASKET-BRAKE MASTER CYLINDER | 1L07 |
| 592358 | GASKET BRAKE AND CLUTCH | 1L07 |
| 592358 | GASKET-CLUTCH MASTER | 2L12 |
| 592364 | BRAKE PIPE COMPLETE TO FRONT | 1L09 |
| 592374 | PIPE-LH REAR TO TEE PIECE | 1L09 |
| 592375 | PIPE-RH REAR TO TEE PIECE | 1L09 |
| 592564 | MOUNTING PLATE | 1L06 |
| 592564 | STOP LIGHT MOUNTING PLATE | 2L13 |
| 592567 | SPRING | 1L06 |
| 592567 | SPRING FOR MOUNTING PLATE | 2L13 |
| 592592 | CROSSMEMBER NO 4 109 4 CYL | 2G02 |
| 592594 | CROSSMEMBER NO 4 109 6 CYL | 2G02 |
| 592774 | PROTECTION PAD | 2G02 |
| 592778 | FLEXIBLE MOUNTING | 2C03 |
| 592778 | MOUNTING-RUBBER-EXHAUST PIPE | 2C04 |
| 592778 | FLEXIBLE MOUNTING | 2C05 |
| 592778 | RUBBER-MOUNTING EXHAUST | 2C06 |
| 592778 | MOUNTING-RUBBER-EXHAUST | 2C07 |
| 592778 | MOUNTING-RUBBER-EXHAUST | 2C08 |

| PART NUMBER | DESCRIPTION | REF.NO. |
|-------------|------------------------------------|---------|
| 592778 | MOUNTING-RUBBER-EXHAUST | 2C10 |
| 592778 | FLEXIBLE MOUNTING | 2C11 |
| 592903 | CNTRL ROD FOR HAND-CONTROL | 1014 |
| 592904 | LEVER ASSY FOR HAND-CONTROL | 1014 |
| 592956 | PACKING PIECE STG COLUMN MTG | 1K04 |
| 592984 | STEERING COLUMN MOUNTING | 1K04 |
| 592985 | STG COLUMN MTG BRACKET LH | 1K04 |
| 593619 | BEARING-BALL | 1I06 |
| 593619 | BEARING-BALL | 1I06 |
| 593664 | BRACKET | 1G05 |
| 593692 | BOLT 0.375 UNF X 1.125 ϕ LONG | 1J08 |
| 593693 | WASHER | 1J08 |
| 593694 | SHIM | 1I11 |
| 593695 | SHIM | 1I11 |
| 593696 | SHIM | 1I11 |
| 593697 | SHIM | 1I11 |
| 593698 | SHIM | 1I11 |
| 593699 | SHIM | 1I11 |
| 593700 | SHIM | 1I11 |
| 593701 | SHIM | 1I11 |
| 593702 | SHIM | 1I11 |
| 593703 | SHIM | 1I11 |
| 593704 | SHIM | 1I11 |
| 593705 | SHIM | 1I11 |
| 593706 | SHIM | 1I11 |
| 593707 | SHIM | 1I11 |
| 593708 | SHIM | 1I11 |
| 593709 | SHIM | 1I11 |
| 593710 | SHIM | 1I11 |
| 593711 | SHIM | 1I11 |
| 593712 | SHIM | 1I11 |
| 593713 | SHIM | 1I11 |
| 593714 | SHIM | 1I11 |
| 593715 | SHIM | 1I11 |
| 593716 | SHIM | 1I11 |
| 593717 | SHIM | 1I11 |
| 593802 | SPRING | 1I10 |
| 593802 | SPRING | 1I12 |
| 593814 | SHIM | 1I06 |
| 593815 | SHIM | 1I06 |
| 593816 | SHIM | 1I06 |
| 593817 | SHIM | 1I06 |
| 593818 | SHIM | 1I06 |
| 593819 | SHIM | 1I06 |
| 593820 | SHIM | 1I06 |

| PART NUMBER | DESCRIPTION | REF.NO. |
|-------------|-------------------------------|---------|
| 593821 | SHIM | 1I06 |
| 593981 | SELECTOR-GEAR CHANGE | 1I12 |
| 593983 | BUSH-GEAR LEVER EXTENSION | 1I12 |
| 593991 | SELECTOR | 1I12 |
| 594018 | WASHER-THRUST | 1H04 |
| 594018 | SHIM | 1I06 |
| 594019 | WASHER-THRUST | 1H04 |
| 594019 | SHIM | 1I06 |
| 594020 | WASHER-THRUST | 1H04 |
| 594020 | SHIM | 1I06 |
| 594021 | WASHER-THRUST | 1H04 |
| 594021 | SHIM | 1I06 |
| 594022 | SHIM | 1I06 |
| 594023 | SHIM | 1I06 |
| 594024 | SHIM | 1I06 |
| 594026 | SEAL-TRANSMISSION BRAKE | 1L05 |
| 594029 | SEAL-OIL | 1I11 |
| 594087 | SEAL-BELL HOUSING COVER | 1I03 |
| 594089 | SHAFT-SELECTOR | 1I12 |
| 594091 | DUST CAP FOR BLEED SCREW | 1G05 |
| 594104 | NUT | 1J06 |
| 594134 | BOLT-SPECIAL | 1I03 |
| 594150 | PLATE | 1H11 |
| 594195 | INTERMEDIATE GEAR SHAFT | 1H07 |
| 594244 | GEAR-REVERSE IDLER | 1I09 |
| 594290 | BEARING ROLLER | 1I09 |
| 594291 | BEARING-ROLLER | 1I06 |
| 594292 | BEARING-ROLLER | 1I06 |
| 594312 | FRONT AXLE ASSEMBLY LESS | 1J03 |
| 594320 | COVER-SIDE-GEARBOX | 1I04 |
| 594322 | HALF SHAFT COMPLETE RH | 1J05 |
| 594323 | HALF SHAFT COMPLETE LH | 1J05 |
| 594338 | SHAFT-REAR OUTPUT | 1I11 |
| 594340 | DIFFERENTIAL COMPLETE-GEARBOX | 1I10 |
| 594349 | REAR AXLE ASSEMBLY LESS | 1J12 |
| 594361 | FRONT PROPELLER SHAFT 6 CYL | 1J03 |
| 594389 | BEARING-ROLLER-REVERSE GEAR | 1I09 |
| 594486 | DIFFERENTIAL CASE | 1J08 |
| 594487 | DIFFERENTIAL CASE | 1J08 |
| 594493 | CROWN WHEEL AND PINION | 1J08 |
| 594505 | OUTER COLUMN | 1K02 |
| 594506 | INNER COLUMN RH STG | 1K02 |
| 594507 | INNER COLUMN LH STG | 1K02 |
| 594594 | "TYRAP" STRAP | 2K14 |
| 594594 | "TYRAP" STRAP | 2L15 |

| PART NUMBER | DESCRIPTION | REF.NO. |
|-------------|------------------------------|---------|
| 594619 | PIPE-REAR BRAKE | 1L09 |
| 594664 | CHASSIS FRAME 4 CYL 1 TON | 2G02 |
| 594742 | BRACKET FOR SHUTTLE VALVE | 2L12 |
| 594747 | BRAKE PIPE, VALVE TO RR HOSE | 2L12 |
| 594748 | BRAKE PIPE, VALVE TO RR HOSE | 2L12 |
| 594752 | PIPE, VALVE TO LHF | 2L12 |
| 594753 | HOSE CLIP | 1N02 |
| 594753 | CLIP-AIR CLEANER PIPE | 1N03 |
| 594753 | HOSE CLIP-FUEL FILLER | 1N14 |
| 594753 | HOSE CLIP | 1N15 |
| 594753 | HOSE CLIP-FUEL FILLER | 1N16 |
| 594753 | HOSE CLIP-FUEL FILLER PIPE | 1N17 |
| 594774 | HEAT SHIELD MTG BRKT TOP | 2C09 |
| 594776 | BLEED PIPE | 1G05 |
| 594822 | ADAPTOR | 1G05 |
| 594938 | FIXING PLATE FOR 3 WAY PIPE | 1L09 |
| 594943 | FUEL PIPE TANK TO PUMP | 1N12 |
| 595119 | MOUNTING BRACKET | 1I05 |
| 595119 | BRACKET-GEARBOX MOUNTING | 1I05 |
| 595123 | STEERING DROP ARM | 1K02 |
| 595336 | WHEEL NUT WRENCH 1.0625 AF | 2L11 |
| 595339 | PIPE-FUEL | 1N08 |
| 595339 | FUEL PIPE PUMP TO FILTER | 1N12 |
| 595340 | FUEL PIPE | 1N08 |
| 595340 | PIPE-FUEL | 1N12 |
| 595396 | REMOTE BREATHER PIPE | 1J02 |
| 595396 | REMOTE BREATHER PIPE | 1J03 |
| 595469 | DRAG LINK DAMPER BRACKET | 1K07 |
| 595473 | REMOTE BREATHER PIPE | 1J12 |
| 595478 | BOLT-BANJO | 1I05 |
| 596000 | INLET MANIFOLD | 1C13 |
| 596000 | INLET MANIFOLD ASSEMBLY | 2L12 |
| 596069 | PLUG | 1C13 |
| 596097 | STUD | 1D13 |
| 596097 | STUD | 1E02 |
| 596097 | STUD FOR CYLINDER HEAD | 1E11 |
| 596225 | THERMOSTAT | 1C10 |
| 596225 | THERMOSTAT | 1E10 |
| 596384 | DIAPHRAGM UNIT | 1C14 |
| 596384 | DIAPHRAGM | 2L12 |
| 596385 | TRIGGER VALVE | 2L12 |
| 596387 | BANJO RING ASSEMBLY | 2L15 |
| 596438 | PIPE VALVE TO INLET PIPE | 2L12 |
| 596445 | ADAPTOR ASSEMBLY | 2L12 |
| 596490 | LOCKING PLATE EXH MANIFOLD | 1C13 |

| PART NUMBER | DESCRIPTION | REF. NO. |
|-------------|---------------------------------|----------|
| 596493 | CLIP-COLD START | 1M06 |
| 596495 | ELBOW | 1N02 |
| 596691 | CARBURETTER ELBOW | 2L12 |
| 596717 | ADAPTOR | 1N06 |
| 596955 | INLET MANIFOLD | 1C13 |
| 597563 | BANJO BOLT | 1C11 |
| 597563 | BOLT-BANJO | 1E11 |
| 597586 | CUP PLUG FOR CYLINDER BLOCK | 1C02 |
| 597586 | CUP PLUG | 1E02 |
| 597722 | ADAPTOR ASSY OIL FILTER | 1D13 |
| 598006 | BLANKING PLATE CYLINDER HEAD | 1C11 |
| 598006 | PLATE-CYLINDER HEAD | 1D11 |
| 598046 | CUP PLUG | 1D11 |
| 598056 | ENGINE STOP LEVER | 1N10 |
| 598064 | HUB FOR FAN | 1C10 |
| 598064 | HUB-FAN PULLEY | 1E09 |
| 598104 | EXHAUST MANIFOLD | 1E13 |
| 598110 | CARBURETTER COMPLETE | 1M05 |
| 598127 | CLIP REAR | 2L12 |
| 598128 | CLIP FRONT | 2L12 |
| 598197 | STUD | 1C13 |
| 598197 | STUD | 2L12 |
| 598214 | OIL PUMP SHAFT | 1D05 |
| 598231 | OIL FILLER CAP | 1C08 |
| 598231 | CAP-ENGINE OIL FILLER | 1D08 |
| 598231 | CAP-OIL FILLER | 1E09 |
| 598318 | PIPE MANIFOLD TO TRIGGER VALVE | 2L15 |
| 598354 | HOUSING-OIL FILTER | 1E12 |
| 598380 | PIPE | 1C14 |
| 598380 | PIPE TRIGGER VALVE TO DIAPHRAGM | 2L15 |
| 598473 | EXHAUST MANIFOLD | 1C13 |
| 598473 | EXHAUST-MANIFOLD | 2L12 |
| 598483 | WATER PUMP | 1D10 |
| 598483 | WATER PUMP AND VISCOUS DRIVE | 2L17 |
| 598486 | HUB VISCOUS DRIVE ASSY | 1D10 |
| 598486 | HUB VISCOUS DRIVE ASSEMBLY | 1D11 |
| 598486 | SPINDLE-WATER PUMP | 1E10 |
| 598491 | PULLEY-WATER PUMP | 1E10 |
| 598516 | SEALING PAD FOR CATCH TANK | 2K14 |
| 598517 | COVER FOR SEALING PAD | 2K14 |
| 598531 | OVERFLW BOTTLE SUPPORT-BRKT | 2D02 |
| 598536 | PLATE-BOTTOM-ROAD SPRING | 1J16 |
| 598539 | SILENCER AND TAIL PIPE | 2C07 |
| 598540 | EXHAUST SILENCER | 2C06 |
| 598540 | SILENCER AND TAIL PIPE | 2C07 |

| PART NUMBER | DESCRIPTION | REF. NO. |
|-------------|--|----------|
| 598575 | MOUNTING BRACKET-FUEL PUMP | 1N08 |
| 598652 | BELL CRANK LEVER | 1010 |
| 598654 | LOST MOTION LEVER | 1010 |
| 598792 | PLATE-EXHAUST MOUNTING | 2G02 |
| 598823 | BRACKET-ACCELERATOR SHAFT CONTROL | 1012 |
| 598844 | ACCELERATOR CONNECTING LEVER | 1N10 |
| 598848 | SPRING ANCHOR-ACCELERATOR CONTROL | 1012 |
| 598850 | ACCELERATOR LEVER | 1011 |
| 598851 | BRACKET-ACCELERATOR CABLE | 1012 |
| 598852 | ACCELERATOR CABLE ASSEMBLY | 1012 |
| 598853 | PLAIN WASHER | 1C14 |
| 598853 | PACKING PIECE | 1D15 |
| 598854 | CHECK STRAP | 2G02 |
| 598877 | FRONT EXHAUST PIPE | 2L13 |
| 598879 | EXHAUST BLEED PIPE | 2L13 |
| 598880 | NUT | 2L13 |
| 598882 | CLIP | 2L13 |
| 598899 | OLIVE | 2L13 |
| 599061 | TRACK ROD TUBE | 1K06 |
| 599063 | TRACK ROD ADJUSTER TUBE | 1K06 |
| 599102 | PIPE, VALVE TO LHF | 2L12 |
| 599224 | FUEL PIPE | 2L15 |
| 599225 | FUEL PIPE | 2L15 |
| 599233 | FUEL TANK | 1003 |
| 599233 | FUEL TANK | 1004 |
| 599234 | FUEL TANK | 1003 |
| 599234 | FUEL TANK | 1006 |
| 599312 | CHOKE PULL CONTROL ASSEMBLY | 1014 |
| 599313 | CHOKE PULL CONTROL ASSEMBLY | 1014 |
| 599314 | CHOKE PULL CONTROL ASSEMBLY | 1014 |
| 599336 | CHOKE PULL CONTROL ASSEMBLY | 1014 |
| 599337 | CHKE PULL CNTRL ASSY 2 6 PET- ϕ RHD | 1014 |
| 599338 | CHKE PULL CNTRL ASSY 2.250 PET- ϕ LHD | 1014 |
| 599339 | ENGINE STOP CNTRL DIESEL RHD | 1014 |
| 599340 | ENGINE STOP CNTRL DIESEL LHD | 1014 |
| 599343 | PIPE, VALVE TO RHF | 2L12 |
| 599378 | SILENCER AND TAILPIPE 109 4 CYL S/W | 2C08 |
| 599396 | SUPPORT BRACKET | 2F09 |
| 599443 | VALVE-PRESSURE DIFFERENTIAL | 1L12 |
| 599443 | SHUTTLE VALVE | 2L12 |
| 599447 | FUEL PIPE COMPL TANK TO PUMP | 1N11 |
| 599447 | PIPE-FUEL | 1N13 |
| 599447 | PIPE-FUEL | 1N13 |
| 599448 | FUEL PIPE TANK TO PUMP | 1N12 |
| 599552 | BOLT-SPECIAL | 1I04 |

| PART NUMBER | DESCRIPTION | REF. NO. |
|-------------|-------------------------------|----------|
| 599575 | JOINT WASHER | 1I05 |
| 599698 | DISTANCE PIECE FOR SWIVEL PIN | 1J06 |
| 599698 | SPACER-STUB AXLE | 1J12 |
| 599698 | SPACER STUB SHAFT | 1J13 |
| 599826 | STUB AXLE ASSEMBLY 88 | 1J06 |
| 599827 | STUB AXLE ASSEMBLY 109 | 1J06 |
| 599828 | SLEEVE-HUB BEARING | 1J13 |
| 599828 | REAR HUB SLEEVE | 1J12 |
| 599869 | ROLLER BEARING | 1H07 |
| 599945 | DIFFERENTIAL CROSS SHAFT | 1J08 |
| 599995 | HOUSING-SPEEDOMETER DRIVE | 1I11 |
| 600174 | THRUST WASHER | 1D04 |
| 600175 | THRUST WASHER | 1D04 |
| 600176 | THRUST WASHER | 1D04 |
| 600177 | THRUST WASHER | 1D04 |
| 600178 | THRUST WASHER | 1D04 |
| 600179 | THRUST WASHER | 1D04 |
| 600200 | WHL CYLINDER ASSY LH FRONT | 1L03 |
| 600201 | WHL CYLINDER ASSY RH FRONT | 1L03 |
| 600202 | ANCHOR PLATE | 1L03 |
| 600203 | ANCHOR PLATE | 1L03 |
| 600210 | OVERHAUL KIT-FRONT | 2L07 |
| 600210 | WHEEL CYLINDER KIT | 1L03 |
| 600212 | SPRING | 1L03 |
| 600226 | ADAPTOR & LEADS | 2F02 |
| 600243 | FLYWHEEL ASSEMBLY | 1G02 |
| 600245 | STUD KIT-CYLINDER BLOCK | 1C02 |
| 600245 | STUD-KIT-CYLINDER BLOCK | 1E02 |
| 600303 | 'LOCTITE'RETAINING COMPOUND- | 2L07 |
| 600310 | 2ND LEAF | 1J18 |
| 600311 | DOWEL FOR SPRING | 1J18 |
| 600329 | TERMINAL BUSH & LEAD | 2E02 |
| 600329 | TERMINAL AND LEAD-DISTRIBUTOR | 2E04 |
| 600401 | OIL CONTAINER-AIR CLEANER | 1N02 |
| 600423 | SCREW AND WASHER | 2F03 |
| 600423 | SPECIAL SCREW AND WASHER | 2F04 |
| 600476 | SPRINGS SET | 2E02 |
| 600538 | CROWN WHEEL & PINION | 1J08 |
| 600603 | GEARBOX GASKET KIT | 1H02 |
| 600603 | GEARBOX GASKET KIT | 2L07 |
| 600613 | FILTER-AIR CLEANER | 1N02 |
| 600613 | ELEMENT FOR AIR CLEANER | 1N02 |
| 600613 | FILTER-AIR CLEANER | 1N03 |
| 600656 | FLANGE | 1J02 |
| 600656 | FLANGE-PROPELLOR SHAFT | 1J03 |

| PART NUMBER | DESCRIPTION | REF. NO. |
|-------------|--------------------------------------|----------|
| 600656 | FLANGE-PROPELLER SHAFT | 1J14 |
| 601314 | BARSEAL SEALING PELLET | 2L07 |
| 601543 | GROMMET | 2F03 |
| 601717 | GASKET | 2F03 |
| 601721 | LENS | 2F04 |
| 601754 | SPRING SET | 2E07 |
| 601754 | SPRING SEAT-STARTER MOTOR BRUSHES | 2E08 |
| 601790 | SPLINED STUB SHAFT | 1J02 |
| 601790 | SPLINE-PROPELLOR SHAFT | 1J03 |
| 601790 | SPLINE-PROPELLER SHAFT | 1J14 |
| 601835 | THROTTLE SPINDLE | 1M02 |
| 601836 | THROTTLE LEVER | 1M02 |
| 601837 | THROTTLE STOP | 1M02 |
| 601838 | NUT-SPECIAL | 1M06 |
| 601838 | SPECIAL NUT | 1M02 |
| 601840 | RELAY LEVER | 1M02 |
| 601841 | SPLIT PIN | 1M02 |
| 601842 | LEVER | 1M02 |
| 601843 | PLAIN WASHER | 1M02 |
| 601844 | BUTTERFLY FOR THROTTLE | 1M02 |
| 601845 | SCREW-CARBURETTER THROTTLE | 1M07 |
| 601845 | SPECIAL SCREW | 1M10 |
| 601845 | SCREW FIXING THROTTLE VALVE | 2L17 |
| 601845 | SPECIAL SCREW | 1M02 |
| 601846 | SPECIAL SCREW | 1M02 |
| 601850 | 'O' RING | 1M03 |
| 601852 | BALL FOR PISTON | 1M03 |
| 601853 | CIRCLIP | 1M03 |
| 601854 | PLUG FOR PUMP JET | 1M03 |
| 601856 | ACCELERATOR PUMP | 1M03 |
| 601857 | SPECIAL WASHER | 1M03 |
| 601858 | FLOAT | 1M03 |
| 601859 | SPINDLE FOR FLOAT | 1M03 |
| 601860 | TOP COVER | 1M02 |
| 601861 | LEVER & SWIVEL | 1M03 |
| 601862 | SPRING | 1M03 |
| 601863 | CIRCLIP | 1M03 |
| 601864 | BOLT FOR CHOKE SPINDLE LEVER BRACKET | 1M03 |
| 601865 | CHOKE SPINDLE | 1M03 |
| 601866 | SPRING | 1M03 |
| 601867 | BUTTERFLY FOR CHOKE | 1M02 |
| 601869 | PLAIN WASHER | 1M03 |
| 601872 | SPECIAL SCREW | 1M03 |
| 601873 | SHAKEPROOF WASHER | 1M03 |
| 601874 | SPINDLE & LEVER | 1M03 |

| PART NUMBER | DESCRIPTION | REF. NO. |
|-------------|-------------------------------------|----------|
| 601875 | SPACING WASHER | 1M03 |
| 601876 | PUMP LEVER | 1M02 |
| 601877 | WASHER-STARLOCK | 1M06 |
| 601877 | WASHER | 1M02 |
| 601878 | RETAINING RING | 1M02 |
| 601879 | DIAPHRAGM | 1M02 |
| 601880 | GASKET | 1M02 |
| 601881 | SPRING | 1M02 |
| 601882 | COVER | 1M02 |
| 601883 | SCREW | 1M02 |
| 601884 | SPRING WASHER | 1M02 |
| 601886 | SPECIAL SCREW | 1M03 |
| 601887 | SPRING WASHER | 1M03 |
| 601888 | SCREW & WASHER | 1M02 |
| 601889 | SCREW AND WASHER FOR CARB TOP COVER | 1M02 |
| 601891 | SPLIT PIN | 1M03 |
| 601892 | PLAIN WASHER | 1M03 |
| 601893 | LINK | 1M02 |
| 601894 | SPLIT PIN | 1M02 |
| 601895 | MAIN JET | 1M03 |
| 601897 | SLOW RUNNING JET | 1M03 |
| 601899 | PUMP JET | 1M03 |
| 601900 | NEEDLE VALVE FOR CARBURETTER | 1M03 |
| 602040 | DOWEL | 1F09 |
| 602061 | NUT-CONNECTING ROD | 1F04 |
| 602067 | SPRING-OIL RELEASE | 1F05 |
| 602070 | STRAINER-ENGINE OIL | 1F03 |
| 602071 | PLUG-OIL PUMP | 1F05 |
| 602076 | RETAINER-INLET MANIFOLD GASKET SEAL | 1F07 |
| 602082 | CONNECTING ROD | 1F04 |
| 602087 | GASKET-ENGINE SUMP | 1F03 |
| 602097 | BOLT-SPECIAL | 1F05 |
| 602098 | WASHER-PLAIN | 1F09 |
| 602098 | WASHER-PLAIN | 1F09 |
| 602099 | SEAL-INLET MAINFOLD GASKET | 1F07 |
| 602123 | PLUG-CYLINDER HEAD | 1F09 |
| 602130 | BOLT-SPECIAL | 1F02 |
| 602141 | DOWEL | 1F02 |
| 602142 | SPRING-VALVE ROCKER | 1F05 |
| 602146 | CUP PLUG | 1F02 |
| 602147 | CUP PLUG | 1F02 |
| 602148 | WASHER-CONCAVE | 1F05 |
| 602152 | CUP PLUG | 1F02 |
| 602152 | CUP PLUG | 1F02 |
| 602152 | CUP-PLUG | 1F06 |

| PART NUMBER | DESCRIPTION | REF.NO. |
|-------------|-------------------------------------|---------|
| 602153 | ROCKER-VALVE R.H. | 1F05 |
| 602154 | ROCKER-VALVE L.H. | 1F05 |
| 602172 | BAFFLE-VALVE GEAR | 1F05 |
| 602186 | WASHER-PLAIN | 1F05 |
| 602191 | BOLT-SPECIAL | 1F09 |
| 602192 | BOLT SPECIAL | 1F09 |
| 602193 | BOLT-SPECIAL | 1F09 |
| 602199 | SCREW-SPECIAL | 1F03 |
| 602201 | DOWEL | 1F04 |
| 602212 | PLUG | 1F02 |
| 602212 | SCREWED PLUG FOR OIL FILTER ADAPTOR | 1D13 |
| 602227 | BOLT | 1F06 |
| 602236 | BOLT | 1F07 |
| 602289 | CUP PLUG FOR CYLINDER HEAD | 1E11 |
| 602289 | CUP-PLUG | 1F09 |
| 602388 | BOLT | 1F04 |
| 602411 | SPACING WASHER | 1F03 |
| 602505 | PULLEY-ALTERNATOR | 2E16 |
| 602512 | GASKET-ROCKER COVER | 1F10 |
| 602530 | SCREW-SPECIAL | 1F10 |
| 602539 | CLIP | 1D14 |
| 602539 | CLIP-HOSE TO ROCKER COVER | 2L17 |
| 602582 | FAN PULLEY | 1F11 |
| 602587 | RETAINER-CRANKSHAFT PULLEY | 1F03 |
| 602609 | BOLT-CONNECTING ROD | 1F04 |
| 602634 | 'O' RING | 1M11 |
| 602910 | BOLT SPECIAL 0.8750" LONG | 1F05 |
| 602912 | BOLT SPECIAL 1.25" LONG | 1F05 |
| 602913 | BOLT SPECIAL 1.5625" LONG | 1F05 |
| 602915 | DRAIN TAP | 1C02 |
| 602915 | TAP-WATER DRAIN | 1D03 |
| 602915 | TAP-WATER DRAIN | 1E02 |
| 603031 | BRACKET ENGINE LIFTING | 1F09 |
| 603069 | SEAL | 1N05 |
| 603127 | SCREW-SPECIAL | 1F10 |
| 603143 | PIPE-WATER | 1F02 |
| 603184 | CLIP-PIPE | 1F10 |
| 603224 | PLUG-INLET MANIFOLD | 1F06 |
| 603237 | ROLLER | 1M12 |
| 603277 | BANJO | 1F06 |
| 603301 | RIM BALANCING-CRANKSHAFT | 1F03 |
| 603330 | FLAME TRAP | 1D09 |
| 603330 | FLAME TRAP | 1M13 |
| 603330 | TRAP-FLAME-EVAPORATIVE | 2L12 |
| 603330 | FLAME-TRAP | 2L16 |

| PART NUMBER | DESCRIPTION | REF.NO. |
|-------------|----------------------------------|---------|
| 603376 | CLIP | 1M13 |
| 603378 | PUSH ROD-VALVE | 1F05 |
| 603428 | DOWEL | 1F11 |
| 603431 | UNION NUT FOR FUEL PIPE | 1N11 |
| 603431 | NUT-FUEL PIPE | 1N12 |
| 603431 | NUT-FUEL PIPE | 1N13 |
| 603431 | NUT-FUEL PIPE | 1N13 |
| 603441 | GASKET-WATER OUTLET PIPE | 1F06 |
| 603446 | SEALING WASHER-DISTRIBUTOR | 2E06 |
| 603521 | JOINT WASHER | 1F05 |
| 603535 | ROLL PIN | 1F03 |
| 603554 | GUIDE VALVE | 1F09 |
| 603561 | BRACKET | 1F06 |
| 603561 | ANCHOR BRACKET | 1M12 |
| 603622 | SPRING | 1M12 |
| 603659 | PLUG-ENGINE OIL DRAIN | 1F03 |
| 603672 | CLIP-PLUG LEADS | 1F10 |
| 603673 | CLIP-DISTRIBUTOR LEADS | 2E06 |
| 603675 | CLIP-PLUG LEADS | 1F10 |
| 603734 | PEDESTAL-VALVE ROCKER SHAFT | 1F05 |
| 603775 | GASKET-FRONT COVER | 1F04 |
| 603796 | GASKET-CYLINDER HEAD | 1F09 |
| 603851 | GROMMET | 1N04 |
| 603851 | GROMMET | 1N06 |
| 603887 | CLIP FIXING HOSE | 1N14 |
| 603887 | CLIP FIXING HOSE | 1N15 |
| 603887 | CLIP FIXING HOSE | 1N16 |
| 603887 | HOSE CLIP-FUEL TANK BALANCE PIPE | 1002 |
| 603887 | CLIP-FUEL TANK BREATHER HOSE | 1004 |
| 603887 | CLIP-HOSE | 2L16 |
| 603920 | ADAPTOR-AIR BLEED | 1F06 |
| 605011 | SEAL | 1N10 |
| 605012 | DRAIN PLUG | 1N10 |
| 605013 | SEAL | 1N10 |
| 605092 | OUPERHAUL KIT | 1M02 |
| 605092 | CARBURETTER OVERHAUL KIT | 2L07 |
| 605093 | CARBURETTER OVERHAUL KIT | 2L07 |
| 605093 | GASKET KIT | 1M02 |
| 605106 | GASKET KIT | 1D03 |
| 605106 | ENGINE OVERHAUL GASKET KIT | 2L07 |
| 605157 | CYLINDER BLOCK ASSEMBLY | 1D03 |
| 605169 | GASKET SMALL | 1D13 |
| 605190 | CAP-DRISTRIBUTOR | 2E06 |
| 605191 | ELEMENT | 1N05 |
| 605238 | PLASTIGAUGE STRIP-BOX OF 24 | 2L07 |

| PART NUMBER | DESCRIPTION | REF. NO. |
|-------------|----------------------------|----------|
| 605322 | SPRING WASHER | 1M07 |
| 605508 | END PLATE FOR STEERING BOX | 1K02 |
| 605544 | DISTRIBUTOR CAP | 2E04 |
| 605544 | CAP-DRISTRIBUTOR | 2E05 |
| 605544 | DISTRIBUTOR CAP | 2L17 |
| 605622 | SUNDRY PARTS | 2E09 |
| 605683 | MAIN JET | 1M03 |
| 605684 | MAIN JET | 1M03 |
| 605685 | MAIN JET | 1M03 |
| 605686 | MAIN JET | 1M03 |
| 605687 | SLOW RUNNING JET | 1M03 |
| 605705 | NUT | 2E09 |
| 605716 | OVERHAUL KIT | 1D09 |
| 605716 | WATER PUMP OVERHAUL KIT | 2L07 |
| 605765 | COOLANT INHIBITOR | 2L07 |
| 605793 | ADAPTOR | 1M05 |
| 605794 | SPINDLE | 1M06 |
| 605795 | LEVER | 1M06 |
| 605797 | WASHER | 1M06 |
| 605799 | NUT | 1M06 |
| 605800 | BUTTERFLY-CARBURETTER | 1M10 |
| 605800 | BUTTERFLY | 1M06 |
| 605801 | SCREW | 1M06 |
| 605803 | COVER | 1M06 |
| 605804 | SPINDLE | 1M06 |
| 605805 | SPRING | 1M06 |
| 605806 | WASHER | 1M06 |
| 605807 | SCREW | 1M06 |
| 605808 | LEVER | 1M06 |
| 605809 | RETURN SPRING | 1M06 |
| 605810 | WASHER | 1M06 |
| 605811 | SCREW | 1M06 |
| 605813 | BRACKET | 1M06 |
| 605815 | SCREW | 1M06 |
| 605816 | SCREW | 1M05 |
| 605817 | SPRING | 1M05 |
| 605820 | PIN | 1M05 |
| 605821 | SPRING | 1M05 |
| 605822 | CLIP | 1M05 |
| 605827 | JET ORIFICE | 1M06 |
| 605828 | SPRING | 1M06 |
| 605830 | CARRIER | 1M06 |
| 605833 | FLOAT-CARBURETTER | 1M07 |
| 605833 | FLOAT-CARBURETTER | 1M10 |
| 605833 | FLOAT AND ARM | 2L17 |

| PART NUMBER | DESCRIPTION | REF.NO. |
|-------------|------------------------------------|---------|
| 605833 | FLOAT | 1M06 |
| 605835 | GASKET | 1M05 |
| 605836 | FLOAT CHAMBER | 1M05 |
| 605837 | SCREW | 1M05 |
| 605838 | SCREW | 1M05 |
| 605842 | RETAINING RING-CARBURETTER | 1M05 |
| 605843 | SCREW | 1M05 |
| 605844 | AIR VALVE | 1M05 |
| 605845 | SCREW | 1M05 |
| 605846 | TOP COVER | 1M05 |
| 605847 | SCREW | 1M05 |
| 605848 | DAMPER & CAP | 1M05 |
| 605848 | DAMPER-CARBURETTER | 1M07 |
| 605848 | DAMPER-CARBURETTER | 1M10 |
| 605848 | DAMPER AND OIL CAP | 2L17 |
| 605857 | GASKET KIT | 1M05 |
| 605857 | CARBURETTER GASKET KIT | 2L07 |
| 605904 | SPINDLE & GEAR | 2F06 |
| 605925 | SOLENOID | 1M02 |
| 605997 | LINING PACKAGE FOR CLUTCH | 1G02 |
| 605997 | LINING-CLUTCH | 1G03 |
| 606098 | CARBURETTER KIT | 1M05 |
| 606098 | CARBURETTER OVERHAUL KIT | 2L07 |
| 606104 | ELEMENT | 1N04 |
| 606168 | BREATHER FILTER | 1M13 |
| 606168 | BREATHER FILTER | 1N04 |
| 606177 | LIGHT UNIT | 2F02 |
| 606178 | BULB | 2F02 |
| 606187 | UNIVERSAL WING MIRROR HEAD | 2G07 |
| 606207 | SEAL FOR CENTRE BOLT | 1N09 |
| 606211 | LENS-NUMBER PLATE | 2F04 |
| 606217 | GASKET FOR STOP TAIL LAMP | 2F03 |
| 606220 | CIRCLIP | 2E07 |
| 606220 | RETAINER-BENDIX SPRING STARTER | 2E08 |
| 606247 | CLIP | 1N04 |
| 606247 | CLIP | 1N05 |
| 606248 | VALVE-DISPOSAL | 1N04 |
| 606248 | DUMP VALVE | 1N05 |
| 606318 | CARBURETTER JET FOR EMULSION BLOCK | 1M03 |
| 606319 | EMULSION BLOCK | 1M03 |
| 606404 | SEALING WASHER | 1L07 |
| 606415 | KIT-BRAKE MASTER CYLINDER | 1L07 |
| 606415 | OVERHAUL KIT | 2L07 |
| 606474 | BEARING-BALL | 1I11 |
| 606487 | NEEDLE | 1M05 |

| PART NUMBER | DESCRIPTION | REF.NO. |
|-------------|-----------------------------------|---------|
| 606501 | BULB HOLDER | 2F04 |
| 606661 | SHAFT-ROCKER | 1F05 |
| 606679 | GASKET | 1M02 |
| 606731 | SPRING-CLUTCH CYLINDER | 1G05 |
| 606733 | SCREW-BLEED | 1G05 |
| 606737 | PLATE-ANCHOR-TRANSMISSION | 1L05 |
| 606739 | LEVER-TRANSMISSION BRAKE | 1L05 |
| 606740 | SHIM-SEALING-TRANSMISSION | 1L05 |
| 606741 | PIVOT-BRAKE SHOE | 1L05 |
| 606742 | ADJUSTER-TRANSMISSION BRAKE | 1L05 |
| 606743 | ADJUSTER-TRANSMISSION BRAKE | 1L05 |
| 606744 | PIVOT-BRAKE SHOE ADJUSTER | 1L05 |
| 606745 | WASHER-PLAIN-SPECIAL | 1L05 |
| 606746 | RETAINER-TRANSMISSION BRAKE | 1L05 |
| 606747 | SPRING-BRAKE SHOE RETAINING | 1L05 |
| 606749 | SPRING-BRAKE SHOE | 1L05 |
| 606750 | SPRING-TRANSMISSION BRAKE | 1L05 |
| 606754 | GASKET KIT-GEARBOX | 1I25 |
| 606819 | PIN FOR NEEDLE VALVE | 1M06 |
| 606835 | BOLT FOR ALTERNATOR | 2E10 |
| 606835 | BOLT | 2E12 |
| 606835 | BOLT-ALTERNATOR | 2E14 |
| 606835 | BOLT | 2E16 |
| 606880 | PRIMARY PINION | 1H04 |
| 606880 | GEARS-PRIMARY PINION AND CONSTANT | 1H05 |
| 606881 | GEAR BOX CASING | 1H03 |
| 606895 | BUSH | 2E02 |
| 606988 | EXHAUST MANIFOLD FIXING KIT | 1C13 |
| 607162 | GEAR CARRIER CASING | 1J12 |
| 607163 | BOLT | 1J03 |
| 607163 | BOLT | 1J12 |
| 607164 | CASE-DIFFERENTIAL | 1J13 |
| 607164 | DIFFERENTIAL CASE LESS GEARS | 1J09 |
| 607165 | BOLT FOR DIFFERENTIAL CROWN | 1J09 |
| 607165 | BOLT | 1J13 |
| 607168 | WASHER-CONCAVE-DIFFERENTIAL | 1J13 |
| 607168 | THRUST WASHER | 1J09 |
| 607169 | WASHER-DIFFERENTIAL WHEEL | 1J13 |
| 607169 | THRUST WASHER | 1J09 |
| 607172 | PLUG | 1J12 |
| 607173 | BOLT | 1J12 |
| 607173 | BOLT | 1J03 |
| 607177 | SHIM CROWN WHEEL PINION | 1J13 |
| 607177 | SHIM | 1J09 |
| 607178 | SHIM CROWN WHEEL PINION | 1J13 |

| PART NUMBER | DESCRIPTION | REF.NO. |
|-------------|-----------------------------------|---------|
| 607178 | SHIM FOR PINION BEARING | 1J09 |
| 607179 | SHIM CROWN WHEEL PINION | 1J13 |
| 607179 | SHIM | 1J09 |
| 607180 | BEARING-PINION | 1J13 |
| 607180 | PINION BEARING | 1J03 |
| 607180 | PINION BEARING | 1J09 |
| 607181 | BEARING-BALL | 1J12 |
| 607181 | PINION BEARING | 1J03 |
| 607182 | OIL THROWER | 1J12 |
| 607182 | OIL THROWER | 1J03 |
| 607183 | GASKET | 1J12 |
| 607183 | GASKET | 1J03 |
| 607185 | FLANGE | 1J03 |
| 607185 | FLANGE-REAR AXLE | 1J12 |
| 607186 | BRACKET | 1J12 |
| 607187 | BEARING-BALL | 1J13 |
| 607187 | BEARING | 1J09 |
| 607188 | SHIM-DIFFERENTIAL | 1J13 |
| 607188 | SHIM | 1J09 |
| 607189 | SHIM-DIFFERENTIAL | 1J13 |
| 607189 | SHIM | 1J09 |
| 607190 | SHIM-DIFFERENTIAL | 1J13 |
| 607190 | SHIM | 1J09 |
| 607191 | SHIM-DIFFERENTIAL | 1J13 |
| 607191 | SHIM | 1J09 |
| 607197 | SPACER-CROWN WHEEL PINION | 1J13 |
| 607197 | SPACER | 1J09 |
| 607247 | REAR AXLE ASSY LESS HUB | 1J12 |
| 607252 | RIVETS FOR BRAKE SHOE | 1L05 |
| 607357 | WASHER-PLAIN | 1J12 |
| 607357 | WASHER FOR PINION | 1J03 |
| 607605 | WASHER FOR NEEDLE VALVE | 1M06 |
| 607677 | NUT FOR VOLUME CONTROL SCREW | 1M02 |
| 607678 | PUMP DISCHARGE VALVE | 1M03 |
| 607753 | BOLT KIT FOR STARTER | 2E09 |
| 607754 | ARMATURE FOR STARTER MOTOR | 2E09 |
| 607808 | STEADY POST AND BUSH | 1L03 |
| 607814 | THROTTLE STOP AND FAST IDLE LEVER | 1M06 |
| 607815 | BUSH FOR JET ORIFICE | 1M06 |
| 607932 | PIN RETAINING KIT FOR STRTR MOTOR | 2E07 |
| 607932 | KIT-PINION RETAINING STARTER | 2E08 |
| 607965 | STEERING BOX ASSEMBLY RH STG | 1K02 |
| 607966 | STEERING BOX ASSEMBLY LH STG | 1K02 |
| 607968 | BUSH FOR RCKER SHFT-STG BOX | 1K02 |
| 607971 | TUBE HOUSING STEERING COLUMN | 1K02 |

| PART NUMBER | DESCRIPTION | REF. NO. |
|-------------|-----------------------------------|----------|
| 607972 | BOLT SPECIAL FOR STEERING | 1K02 |
| 607992 | BOLT SPECIAL FOR STEERING | 1K02 |
| 607993 | SPECIAL BOLT 0.3125UNC X 0.875 | 1K02 |
| 608004 | SCREW AND WASHER | 2F03 |
| 608004 | SCREW AND WASHER FOR FLASHER LAMP | 2F04 |
| 608005 | SCREW AND WASHER FOR SIDE LAMP | 2F03 |
| 608023 | STUB SHAFT FOR SWIVEL PIN | 1J05 |
| 608074 | SUPPRESSOR FOR ALTERNATOR | 2E10 |
| 608074 | SUPPRESSOR FOR ALTERNATOR | 2E12 |
| 608074 | SUPPRESSOR-ALTERNATOR | 2E14 |
| 608074 | SUPPRESSOR-ALTERNATOR | 2E16 |
| 608094 | BRUSH/SPRING DISTRIBUTOR CAP | 2E06 |
| 608111 | VACUUM UNIT FOR DISTRIBUTOR | 2E02 |
| 608118 | BRACKET-DRIVE END-ALTERNATOR | 2E16 |
| 608119 | REGULATOR-ALTERNATOR | 2E16 |
| 608124 | GASKET SET ENGINE OVERHAUL | 1C02 |
| 608124 | ENGINE OVERHAUL GASKET KIT | 2L07 |
| 608142 | BEVEL PINION AND SIDE GEAR | 1I10 |
| 608142 | BEVEL PINION AND SIDE GEARS | 1I11 |
| 608143 | SHAFT PINION-DIFFERENTIAL | 1I10 |
| 608152 | BUTTERFLY FOR THROTTLE | 1M02 |
| 608158 | CONTACT POINTS-DISTRIBUTOR | 2E06 |
| 608172 | BUSH KIT FOR STARTER MOTOR | 2E07 |
| 608172 | BUSHES-STARTER MOTOR | 2E08 |
| 608174 | STARTER MOTOR DRIVE END BRKT | 2E07 |
| 608174 | BRACKET-STARTER MOTOR END | 2E08 |
| 608194 | VACUUM UNIT-DISTRIBUTOR | 2E06 |
| 608197 | LEAD-LOW TENSION-DISTRIBUTOR | 2E06 |
| 608246 | PLUG | 1H03 |
| 608246 | PLUG-BOTTOM COVER | 1H09 |
| 608246 | PLUG-FILLER | 1J02 |
| 608246 | PLUG, FILLER | 1J03 |
| 608246 | PLUG-OIL LEVEL | 1J07 |
| 608246 | PLUG-REAR AXLE | 1J12 |
| 608246 | PLUG, DRAIN | 1J12 |
| 608246 | OIL FILLER PLUG | 1J03 |
| 608283 | INNER AND OUTER MEMBERS | 1H04 |
| 608296 | DRIVING LAMP | 2F02 |
| 608304 | BUSH KIT FOR STARTER MOTOR | 2E09 |
| 608327 | CYLINDER BLOCK 2.25 PETROL | 1C02 |
| 608327 | CYLINDER BLOCK | 1E02 |
| 608352 | BUSH KIT | 2E09 |
| 608417 | COVER PLATE-GEARBOX | 1I04 |
| 608464 | BALL JOINT ASSY RH THREAD | 1K06 |
| 608464 | BALL JOINT-STEERING LINKS | 1K07 |

| PART NUMBER | DESCRIPTION | REF. NO. |
|-------------|--------------------------------------|----------|
| 608465 | STEERING TRACK ROD ASSY | 1K06 |
| 610025 | BRACKET | 1M13 |
| 610178 | DOG-STARTING | 1F03 |
| 610289 | CHAINWHEEL-CRANKSHAFT | 1F06 |
| 610327 | JOINT WASHER | 1M11 |
| 610333 | THROTTLE LEVER | 1M12 |
| 610402 | CLIP-PLUG LEADS | 1F10 |
| 610489 | CLIP-OIL DIPSTICK TUBE | 1F02 |
| 610529 | DOWEL | 1D10 |
| 610529 | DOWEL FOR VISCOUS DRIVE HUB | 1D11 |
| 610529 | DOWEL-WATER PUMP SANDLE | 1E10 |
| 610529 | DOWEL | 1F11 |
| 610578 | HUB ASSEMBLY | 1F11 |
| 611015 | OLIVE | 1M09 |
| 611019 | PULLEY-CRANKSHAFT | 1F03 |
| 611022 | BRACKET-ALTERNATOR | 2E16 |
| 611089 | SEAL-REAR MAIN BEARING CAP | 1F02 |
| 611109 | HOSE | 1M13 |
| 611110 | HOSE | 1M13 |
| 611110 | CONNECTION-RUBBER-PIPE TO | 2L15 |
| 611110 | RUBBER CONNECTION PIPE TO CATCH TANK | 2K14 |
| 611113 | HOSE | 1M13 |
| 611114 | HOSE | 1M13 |
| 611185 | LOCATING PLATE FOR VACUUM SWITCH | 2L15 |
| 611323 | RING GEAR-FLYWHEEL | 1G03 |
| 611324 | FLYWHEEL ASSEMBLY | 1G03 |
| 611351 | BRACKET | 1M13 |
| 611409 | SEAL-OIL-REAR MAIN BEARING | 1F02 |
| 611514 | UNION-OIL PUMP | 1F05 |
| 611786 | GASKET-WATER OUTLET PIPE | 1F07 |
| 612093 | RIVET | 2G08 |
| 612320 | ADJUSTING LEVER | 1M12 |
| 612326 | GASKET-WATER PUMP | 1F10 |
| 612326 | GASKET-WATER PUMP | 1F11 |
| 612505 | PETROL FEED PIPE | 1M09 |
| 612689 | LOCK WASHER | 1F08 |
| 612710 | HOUSING-ENGINE OIL STRAINER | 1F03 |
| 612871 | BRACKET | 1F04 |
| 612898 | CUP PLUG | 1F02 |
| 612980 | SUMP-ENGINE OIL | 1F03 |
| 612989 | CRANKSHAFT | 1F03 |
| 613087 | FAN BLADE | 1F11 |
| 613187 | CLIP | 1D14 |
| 613187 | CLIP-HOSE TO AIR PUMP | 2L17 |
| 613244 | COWL-ALTERNATOR | 2E16 |

| PART NUMBER | DESCRIPTION | REF. NO. |
|-------------|------------------------------------|----------|
| 613514 | CHOKE PIPE | 1M09 |
| 613519 | AIR INTAKE HOSE | 1N06 |
| 613538 | VACUUM PIPE | 2L15 |
| 613602 | FAN BELT | 1F11 |
| 613602 | BELT-FAN | 1F12 |
| 613620 | BRACKET-ALTERNATOR | 2E16 |
| 613669 | DAMPER-VIBRATION | 1F03 |
| 613671 | DEFLECTOR-CRANKSHAFT | 1F03 |
| 613805 | CLIP | 1M13 |
| 613805 | CLIP | 1N04 |
| 613857 | RETAINER-DISTRIBUTOR | 2E06 |
| 614037 | GEAR-OIL PUMP | 1F05 |
| 614088 | DOWEL-INLET | 1F09 |
| 614089 | VALVE-EXHAUST | 1F09 |
| 614188 | GEAR-DISTRIBUTOR DRIVE | 1F06 |
| 614202 | FILTER-OIL PUMP | 1F05 |
| 614361 | VACUUM SWITCH | 2L15 |
| 614443 | BOLT-SPECIAL | 1F08 |
| 614555 | OLIVE | 1M09 |
| 614585 | CLAMP-DIPSTICK PIPE | 1F02 |
| 614737 | PULLEY-FAN | 1F12 |
| 614739 | FAN ASSY | 1D10 |
| 614739 | FAN ASSEMBLY | 1D11 |
| 614739 | FAN BLADE | 1E10 |
| 614739 | FAN BLADE | 1F12 |
| 614739 | FAN ASSEMBLY | 2L17 |
| 614866 | CONNECTOR | 1N05 |
| 614890 | CLIP | 1N06 |
| 614891 | PLASTIC PIPE | 1M09 |
| 614891 | TUBE | 1M09 |
| 614891 | PIPE | 1N05 |
| 614908 | SPINDLE-FAN PULLEY | 1F11 |
| 614920 | HOT AIR HOSE | 1N06 |
| 614938 | LINK-ADJUSTER-ALTERNATOR | 2E16 |
| 614939 | LINK ADJUSTER-ALTERNATOR | 2E16 |
| 622042 | OIL SEAL FOR SPEEDO DRIVE | 1H08 |
| 622045 | GASKET-GEAR BOX BELL HOUSING | 1H02 |
| 622046 | JOINT WSHR-TRANSFER BOX TO GEARBOX | 1H09 |
| 622047 | JOINT WASHER FOR BEARING HOUSING | 1H09 |
| 622048 | JOINT WASHER-OUTPUT SHAFT | 1H10 |
| 622141 | VALVE-VACUUM CONTROL | 1I13 |
| 622155 | SELECTOR FORK | 1H12 |
| 622281 | BOLT 0.25 BSF X 0.40625 cLONG | 1H11 |
| 622324 | CLIP-PIPE | 1I05 |
| 622388 | PAD-SELECTOR-LEVER | 1I12 |

| PART NUMBER | DESCRIPTION | REF. NO. |
|-------------|--------------------------------------|----------|
| 622538 | BEARING | 1I06 |
| 623036 | PANEL AND INTERIOR SWITCH | 2F09 |
| 623037 | PANEL LIGHT SWITCH | 2F09 |
| 623055 | SPEEDOMETER CABLE LH STG | 2F08 |
| 623087 | CABLE ENGINE HARNESS | 2F10 |
| 623088 | CABLE ENGINE HARNESS | 2F11 |
| 623089 | CABLE ENGINE HARNESS | 2F10 |
| 623097 | FUEL GAUGE UNIT | 1003 |
| 623097 | GAUGE-FUEL TANK | 1004 |
| 623097 | GAUGE-FUEL TANK | 1006 |
| 623098 | FUEL GAUGE UNIT | 1003 |
| 623100 | EARTH LEAD | 2F10 |
| 623100 | LEAD-EARTH | 2F11 |
| 623192 | TEE PIECE | 2F15 |
| 623210 | BATTERY TERMINAL LEAD | 2F12 |
| 623213 | HEAVY CABLE BATTERY-STARTER SOLENOID | 2F12 |
| 624021 | CLIP FOR AIR CLEANER | 1N03 |
| 624027 | 'U' BOLT | 1J15 |
| 624028 | 'U' BOLT | 1J15 |
| 624034 | 'U' BOLT | 1J15 |
| 624055 | SUPPORT BRACKET | 2F09 |
| 624077 | BOTTOM PLATE LH | 1J15 |
| 624078 | BOTTOM PLATE RH | 1J15 |
| 624079 | BOTTOM PLATE LH | 1J15 |
| 624080 | BOTTOM PLATE RH | 1J15 |
| 624084 | BOTTOM PLATE RH | 1J17 |
| 624170 | FLEXIBLE MOUNTING PLATE | 2C03 |
| 624196 | FRONT EXHAUST PIPE DIESEL | 2C03 |
| 624251 | WASHER-HANDBRAKE RELEASE | 1L14 |
| 624252 | HANDBRAKE LEVER ASSY RHD | 1L14 |
| 624262 | HANDBRAKE LEVER ASSY LHD | 1L14 |
| 624341 | TAIL PIPE COMPLETE | 2C10 |
| 624363 | HOSE FOR RADIATOR TOP | 2D02 |
| 624364 | HOSE FOR RADIATOR TOP | 2D02 |
| 624430 | BATTERY TRAY | 2G04 |
| 624434 | SEAL-OIL | 1K05 |
| 624452 | DRAIN TUBE | 2G04 |
| 625038 | CAP ENGINE OIL FILLER | 1C12 |
| 625038 | CAP-ENGINE OIL FILLER | 1F10 |
| 625580 | SPECIAL WASHER | 2F03 |
| 850641 | PLAIN WASHER | 1C14 |
| 850641 | WASHER-PLAIN | 1D15 |
| 850641 | WASHER-PLAIN | 1E13 |
| 851041 | PLAIN WASHER | 2G05 |
| 851041 | PLAIN WASHER | 2G06 |

| PART NUMBER | DESCRIPTION | REF.NO. |
|-------------|--------------------------------------|---------|
| 889861 | BOLT | 2E13 |
| 10802070 | WASHER JOINT | 1E11 |
| 90212104 | STUD FOR BOTTOM COVER | 1H09 |
| 90213636 | SHAFT FOR SELECTOR FORK | 1H11 |
| 90214684 | SPRING RING FIXING COVER | 1K06 |
| 90214684 | SPRING-STEERING BALL JOINT | 1K07 |
| 90214684 | SPRING RING | 1K08 |
| 90215593 | BOLT 0.25 WHIT X 0.65625 LONG | 1H02 |
| 90215593 | BOLT | 1H11 |
| 90215647 | BOLT 0.3125WHIT X 0.6875cLONG | 1H11 |
| 90215758 | SET BOLT-0.25WHIT X 0.50 LONG | 1H09 |
| 90215758 | BOLT | 1H10 |
| 90215758 | BOLT | 1H11 |
| 90215769 | BOLT | 1H10 |
| 90215769 | BOLT 0.25 WHIT X 0.4375 cLONG | 1H11 |
| 90217355 | NUT FOR REAR HUB | 1J10 |
| 90217355 | NUT FOR HUB | 1J11 |
| 90217355 | NUT-REAR HUB | 1J13 |
| 90217398 | THRUST SLEEVE | 1J05 |
| 90217488 | THRUST WASHER | 1H07 |
| 90217512 | ROLLER BEARING-SPEEDO DRIVE | 1H08 |
| 90217521 | BUSH FOR SELECTOR SHAFT | 1H12 |
| 90217526 | CIRCLIP | 1H07 |
| 90217526 | CIRCLIP | 1I10 |
| 90217584 | SELECTOR FORK | 1H13 |
| 90217636 | CLIP-RESERVOIR TANK | 1L07 |
| 90217636 | CLIP-RESERVOIR TANK | 1L07 |
| 90217843 | BUSH FOR MAINSHAFT BEARING | 1H09 |
| 90217976 | STUD-GEARBOX TRANSFER CASING | 1H09 |
| 90217983 | BEARING HOUSING-HANDBRAKE | 1L14 |
| 90217983 | RETAINER-HANDBRAKE CROSS | 1L15 |
| 90217984 | SPHERICAL BEARING-HANDBRAKE | 1L14 |
| 90217984 | BEARING HANDBRAKE | 1L15 |
| 90218408 | PIN FOR HANDBRAKE CROSS SHAFT | 1L15 |
| 90218410 | DISTANCE PIECE HANDBRAKE CROSS SHAFT | 1L15 |
| 90306199 | SUPPORT TUBE BEARING | 2K06 |
| 90306200 | SUPPORT TUBE | 2K06 |
| 90306465 | RUBBER BUFFER RADIATOR | 2G05 |
| 90500610 | SPRING FOR EXHAUST VALVE ROCKER | 1D08 |
| 90502209 | SPINDLE FOR OIL PUMP | 1C04 |
| 90502209 | SPINDLE-OIL PUMP | 1D05 |
| 90502209 | SPINDLE-OIL PUMP | 1E04 |
| 90508035 | CLIP FOR REAR BODY FIXING | 2H02 |
| 90508035 | CLIP | 2H04 |
| 90508035 | CLIP | 2K03 |

| PART NUMBER | DESCRIPTION | REF.NO. |
|-------------|-----------------------------------|---------|
| 90508035 | CLIP | 2K04 |
| 90508339 | BRACKET | 1D15 |
| 90508544 | DISTANCE PIECE FUEL TANK MTGS | 1002 |
| 90508544 | DISTANCE PIECE-FUEL TANK MOUNTING | 1003 |
| 90508544 | DISTANCE PIECE-FUEL TANK MTG | 1005 |
| 90508544 | TUBE-DISTANCE-FUEL TANK MOUNTING | 1006 |
| 90508545 | MOUNTING RUBBER FUEL TANK | 1002 |
| 90508545 | MOUNTING-RUBBER-FUEL TANK | 1003 |
| 90508545 | MOUNTING RUBBER-FUEL TANK | 1005 |
| 90508545 | RUBBER-FUEL TANK MOUNTING | 1006 |
| 90509730 | CONNECTION FOR AIR CLEANER | 1N03 |
| 90509970 | GROMMET | 1L06 |
| 90510730 | SIDE COVER AND OIL FILLER PIPE | 1C08 |
| 90510912 | WASHER-SHAKEPROOF | 2G18 |
| 90510912 | FAN DISC WASHER | 2H02 |
| 90510912 | WASHER-SHAKEPROOF | 2H04 |
| 90510912 | WASHER-SHAKEPROOF | 2H07 |
| 90510912 | WASHER-STARLOCK | 2H08 |
| 90511833 | VALVE GUIDE | 1D03 |
| 90511958 | JOINT WASHER | 1C10 |
| 90511958 | GASKET-THERMOSTAT | 1E10 |
| 90512142 | COTTER HALVES-VALVE SPRINGS | 2L12 |
| 90512142 | VALVE COLLET | 1D07 |
| 90512143 | SLEEVE-LOCKING-VALVE SPRING | 2L12 |
| 90512143 | VALVE LOCKING SLEEVE EXHAUST | 1D07 |
| 90512144 | CAP-VALVE SPRING | 2L12 |
| 90512144 | VALVE SPRING CAP EXHAUST VALVES | 1D07 |
| 90512205 | INLET VALVE ROCKER ASSEMBLY | 1C06 |
| 90512208 | EXHAUST VALVE ROCKER ASSY | 1C06 |
| 90512305 | FAN DISC WASHER | 1E11 |
| 90512413 | CORE PLUG FOR CYLINDER HEAD | 1E11 |
| 90512651 | SHAKEPROOF WASHER | 1G04 |
| 90512701 | BOLT 0.375 UNF X 1.1875 LONG | 1H08 |
| 90513171 | DOUBLE ENDED UNION | 1D11 |
| 90513171 | ADAPTOR-BRAKE SERVO PIPE | 1L07 |
| 90513454 | WASHER FOR FLANGE | 1J07 |
| 90513591 | OIL FILTER | 1D13 |
| 90513940 | CLIP-BRAKE PIPE | 1L07 |
| 90514721 | CABLE CLIP | 1M09 |
| 90515086 | FLYWHEEL HOUSING ASSEMBLY | 1G03 |
| 90515090 | FAN BLADE ASSEMBLY | 1E09 |
| 90515323 | PISTON ASSEMBLY-TIMING CHAIN | 1C04 |
| 90515855 | BUSH FOR HIGH GEAR WHEEL | 1H07 |
| 90516028 | OIL SEAL FOR FRONT COVER | 1D09 |
| 90517429 | ROLLER FOLLOWER | 1C06 |

| PART NUMBER | DESCRIPTION | REF. NO. |
|-------------|-----------------------------------|----------|
| 90517429 | BUSH-ROCKER SHAFT | 1D08 |
| 90517429 | ROLLER TAPPET | 1E06 |
| 90517567 | BRACKET-EXHAUST MOUNTING | 2C07 |
| 90517567 | BRACKET-EXHAUST MOUNTING TO PIPE | 2C08 |
| 90517705 | COVER-OIL PUMP | 1I03 |
| 90517706 | GASKET-OIL PUMP COVER | 1I03 |
| 90517711 | ELEMENT FOR FUEL FILTER | 1N10 |
| 90518100 | BOLT FOR CONNECTING ROD | 1D04 |
| 90518362 | BOLT | 2L03 |
| 90518466 | STUD CYLINDER HEAD TO BLOCK | 1E11 |
| 90518719 | TOP ROCKER COVER ASSEMBLY | 1E12 |
| 90519054 | CAMSHAFT BEARING FRONT | 1C05 |
| 90519054 | BEARING-CAMSHAFT | 1E05 |
| 90519055 | CAMSHAFT BEARING INTER/REAR | 1C05 |
| 90519055 | BEARING-CAMSHAFT | 1E05 |
| 90519064 | DOWEL LOWER | 1C03 |
| 90519064 | DOWEL | 1D04 |
| 90519064 | DOWEL | 1E03 |
| 90519206 | LOCATION STOP FOR JACK | 1J05 |
| 90519602 | CLIP | 2F15 |
| 90519864 | OIL PRESSURE SWITCH | 1C12 |
| 90519864 | SWITCH-OIL WARNING | 1D11 |
| 90519864 | SWITCH-OIL PRESSURE | 1E12 |
| 90555649 | LUCAR BLADE WIPER MOTOR EARTH | 2F06 |
| 90560612 | FUEL GAUGE UNIT | 1004 |
| 90562714 | ACCELERATOR PEDAL SHAFT | 1009 |
| 90564216 | EXTENSION PIECE OIL STRAINER | 1D05 |
| 90564217 | STUD-OIL STRAINER 0.25 UNF | 1D05 |
| 90564334 | OIL PUMP ASSEMBLY 2.6 | 1D05 |
| 90564812 | PIN FIXING SERVO TO BRAKE PEDAL | 1L06 |
| 90564812 | PIN | 2L13 |
| 90564832 | GASKET BRAKE PEDAL BOX TO TOE BOX | 1L06 |
| 90564832 | GASKET-PLUG PEDAL-BRACKET | 2L13 |
| 90566617 | PIPE CONNECTION AT | 1N10 |
| 90568054 | JOINT WASHER | 1F07 |
| 90568489 | BANJO BOLT FIXING FUEL PIPE | 1N10 |
| 90568525 | STOP LEVER ASSEMBLY | 1N10 |
| 90569017 | CROSSMEMBER NO 4 1 TON | 2G02 |
| 90569126 | CYLINDER-BRAKE MASTER | 1L07 |
| 90569128 | CYLINDER-BRAKE MASTER | 1L07 |
| 90569214 | TAIL PIPE COMPLETE | 2C10 |
| 90569611 | BRAKE PEDAL ASSEMBLY | 1L06 |
| 90569612 | GASKET STOP LIGHT MOUNTING PLATE | 1L06 |
| 90569612 | GASKET-MOUNTING PLATE BRAKES | 2L12 |
| 90571010 | GEAR-MAIN SHAFT TRANSFER | 1I06 |

| PART NUMBER | DESCRIPTION | REF.NO. |
|-------------|------------------------------------|---------|
| 90571030 | PIN-SELECTOR SHAFT | 1I12 |
| 90571086 | GEAR-OIL PUMP | 1I03 |
| 90571091 | CIRCLIP | 1I06 |
| 90571104 | PLUG-GEARBOX OIL FILTER | 1I04 |
| 90571451 | SHIM | 1I06 |
| 90574103 | SET BOLT 0.4375UNF X 2.531 | 1D12 |
| 90574104 | SET BOLT 0.4375UNF X 4.906 | 1D12 |
| 90574655 | HOSE BREATHER TO MANIFOLD | 1E12 |
| 90575015 | NUT FOR SOLEN 010 TERMINAL POST | 2F12 |
| 90575150 | NUMBER PLATE LAMP | 2F04 |
| 90575153 | KNOB WIPER WASHER SWITCH | 2F09 |
| 90575153 | KNOB FOR SWITCH | 2F15 |
| 90575183 | LEAD STARTER MOTOR TO EARTH | 2F12 |
| 90575478 | CLAMP PLATE | 2C11 |
| 90575511 | CLAMP | 2C11 |
| 90575585 | BRACKET-GEARBOX MOUNTING | 1I05 |
| 90575585 | MOUNTING BRACKET | 1I05 |
| 90575977 | HOSE TO PENTHOUSE | 2D04 |
| 90576510 | BOLT 0.375 BSF X 1.25 LONG | 1J05 |
| 90576624 | BRAKE DRUM TRANSMISSION | 1L05 |
| 90576626 | BOLT | 1I11 |
| 90576631 | HOUSING-GEARBOX | 1I05 |
| 90576632 | BUSH-OUTPUT SHAFT | 1I11 |
| 90576658 | BOLT | 1I12 |
| 90577082 | CLIP OVERFLOW BOTTLE OUTLET | 2D02 |
| 90577082 | CLIP-HOSE | 2L12 |
| 90577119 | SHFT AND LEVER FOR HAND-CONTROL | 1014 |
| 90577143 | SUPPORT PLATE FOR NO. PLATE | 2G02 |
| 90577144 | FRONT SUPPORT PLATE-NUMBER PLATE | 2G02 |
| 90577264 | STG BOX STIFFENER BRACKET | 1K04 |
| 90577434 | BUSH-FRONT SPRING SHACKLE | 1J15 |
| 90577434 | BUSH-ROAD SPRING SHACKLE | 1J16 |
| 90577449 | TRUNNION-ACCELERATOR SHAFT CONTROL | 1012 |
| 90577473 | NUT-ROAD WHEEL | 1J18 |
| 90577473 | NUT | 2H16 |
| 90577473 | NUT | 2I02 |
| 90577508 | FUEL FILTER COMPLETE | 1N09 |
| 90577508 | FILTER ASSEMBLY-FUEL | 2L15 |
| 90577611 | PLUG-BRAKE SERVO | 1L07 |
| 90577611 | PLUG | 2F13 |
| 90577611 | PLUG | 2L13 |
| 90577636 | MASTER CYLINDER | 1L07 |
| 90577636 | TANK-BRAKE FLUID SUPPLY | 1L07 |
| 90577716 | SHACKLE PLATE INNER | 1J16 |
| 90577718 | SHACKLE PLATE OUTER | 1J16 |

| PART NUMBER | DESCRIPTION | REF.NO. |
|-------------|------------------------------------|---------|
| 90577721 | FRONT SPRING SHACKLE PLATE | 1J15 |
| 90577723 | SHACKLE PLATE OUTER PLAIN | 1J15 |
| 90600400 | OIL CONTAINER | 1N02 |
| 90600400 | CONTAINER-OIL-AIR CLEANER | 1N03 |
| 90601848 | VOLUME CONTROL SCREW | 1M02 |
| 90601849 | SPRING | 1M02 |
| 90601890 | PIN FOR CHOKE SPINDLE | 1M03 |
| 90601898 | VENTILATION SCREW | 1M02 |
| 90602025 | KEY-WOODRUFF | 1F03 |
| 90602064 | PLUGER-OIL PRESSURE | 1F05 |
| 90602068 | GASKET-ENGINE OIL STRAINER | 1F03 |
| 90602072 | GASKET-OIL PUMP | 1F05 |
| 90602202 | DOWEL | 1F04 |
| 90602372 | CHAINWHEEL-CRANKSHAFT | 1F03 |
| 90605617 | BRACKET FOR STARTER MOTOR | 2E09 |
| 90605812 | SHAKEPROOF WASHER | 1M06 |
| 90606023 | KIT-BRAKE MASTER CYLINDER | 1L07 |
| 90606023 | KIT,BRAKE MASTER CYLINDER | 1L07 |
| 90606023 | OVERHAUL KIT | 2L07 |
| 90606261 | GASKET FOR PETROL PUMP | 1N08 |
| 90606261 | GASKET | 1N08 |
| 90606262 | FILTER | 1N08 |
| 90606262 | FILTER FOR PETROL PUMP | 1N08 |
| 90606664 | SPACER | 1J05 |
| 90607170 | CROSS SHAFT-DIFFERENTIAL | 1J13 |
| 90607170 | CROSS SHAFT | 1J09 |
| 90607193 | BOLT FIXING DIFF CASE | 1J13 |
| 90607607 | CONTACT BREAKER BASE PLATE | 2E02 |
| 90607607 | PLATE-DRISTRIBUTOR-BASE | 2E04 |
| 90607676 | LOCKNUT FOR THROTTLE STOP SCREW | 1M02 |
| 90607679 | BRACKET FOR CHOKE SPINDLE LEVER | 1M03 |
| 90607743 | BRACKET-SLIP RING END- | 2E16 |
| 90607816 | WASHER FOR CARBURETTER JET ORIFICE | 1M06 |
| 90607973 | JOINT WASHER FOR STG COL | 1K02 |
| 90608178 | SUNDRY PARTS KIT FOR STARTER MOTOR | 2E07 |
| 90608178 | KIT-SUNDRY PARTS-STARTER MOTOR | 2E08 |
| 90608178 | KIT-SUNDRY PARTS-STARTER MOTOR | 2E09 |
| 90608241 | ROLLER-FUEL PUMP DIAPHRAGM | 1N07 |
| 90608271 | TEMPERATURE COMPENSATOR | 1M10 |
| 90608297 | PROTECTIVE COVER | 2F02 |
| 90608330 | WINDSCREEN WASHER VALVE | 2F15 |
| 90608462 | LONGTITUDINAL TUBE ASSY | 1K06 |
| 90608462 | LONGTITUDINAL TUBE-STEERING | 1K07 |
| 90608545 | LOCKNUT | 1J12 |
| 90608545 | LOCK NUT | 1J03 |

| PART NUMBER | DESCRIPTION | REF.NO. |
|-------------|------------------------------|---------|
| 90611014 | NUT | 1M09 |
| 90611112 | HOSE | 1M13 |
| 90611504 | BOLT | 1F07 |
| 90614584 | BOLT-SPECIAL | 1F09 |
| 90622182 | BANJO SLAVE CYLINDER BLEED | 1G05 |
| 90622240 | SEAL-OIL | 1I11 |
| 90623054 | SPEEDOMETER CABLE RH STG | 2F08 |
| 90624031 | U BOLT | 1J17 |
| 90624033 | 'U' BOLT FRONT SPRING | 1J15 |
| 90624083 | BOTTOM PLATE LH | 1J17 |
| 90624131 | FRONT EXHAUST PIPE DIESEL | 2C03 |
| 90624214 | DOUBLE LIFT JACK | 2L11 |
| 90624431 | BATTERY TRAY | 2G04 |
| 90624433 | RETAINER-OIL SEAL STG RELAY | 1K05 |
| 90624436 | JOINT WASHER-OIL SEAL | 1K05 |
| AAU 1053 | LEVER-DISTRIBUTOR PUMP | 1N10 |
| AAU 1405 | BRUSH KIT FOR STARTER MOTOR | 2E07 |
| AAU 1405 | BRUSHES-STARTER MOTOR | 2E08 |
| AAU 1484 | NEEDLE VALVE | 1M06 |
| AAU 1582 | FLUID-CLEANING BRAKE PARTS | 2L07 |
| AAU 1700 | SWITCH | 1L11 |
| AAU 1700 | P.D.W.A.SWITCH | 1L12 |
| AAU 1700 | SWITCH | 1L13 |
| AAU 1979 | CLIP | 1C09 |
| AAU 1979 | HOSE CLIP | 2D04 |
| AAU 1979 | HOSE CLIP | 2D04 |
| AAU 1981 | CLIP | 1C08 |
| AAU 1983 | CLIP | 1C09 |
| AAU 1983 | HOSE CLIP | 2D02 |
| AAU 2003 | BALL JOINT-ACCELERATOR ROD | 1010 |
| AAU 2003 | BALL JOINT FOR CONTROL ROD | 1012 |
| AAU 2053 | ROTOR FOR ALTERNATOR | 2E10 |
| AAU 2053 | ROTOR-ALTERNATOR | 2E12 |
| AAU 2053 | ROTOR-ALTERNATOR | 2E14 |
| AAU 2367 | RETAINER | 2L04 |
| AAU 2825 | WASHER-SPRING | 1J12 |
| AAU 2825 | SPRING WASHER | 1J03 |
| AAU 2967 | OVERHAUL KIT | 1M11 |
| AAU 3381 | OIL SEAL FOR DIFF PINION | 1J03 |
| AAU 3686 | CABLE STRAP | 1G04 |
| AAU 3686 | CABLE STRAP | 2L09 |
| AAU 3956 | FAN FOR ALTERNATOR | 2E10 |
| AAU 3956 | FAN-ALTERNATOR | 2E12 |
| AAU 3956 | FAN-ALTERNATOR | 2E14 |
| AAU 4813 | DRIVE ASSY FOR STARTER MOTOR | 2E09 |

| PART NUMBER | DESCRIPTION | REF. NO. |
|-------------|------------------------------------|----------|
| AAU 6248 | LEAD-LOW TENSION-DISTRIBUTOR | 2E06 |
| AAU 6564 | THROTTLE VALVE ASSEMBLY | 1M07 |
| AAU 6564 | THROTTLE VALVE | 2L17 |
| AAU 6565 | VACUUM UNIT | 2L17 |
| AAU 6565 | VACUUM UNIT FOR DISTRIBUTOR | 2E05 |
| AAU 6714 | HALFSHAFT RH | 1J05 |
| AAU 6715 | HALFSHAFT LH | 1J05 |
| AAU 6774 | COLLAR | 2H09 |
| AAU 6774 | COLLER | 2H11 |
| AAU 6774 | COLLAR | 2H13 |
| AAU 6838 | BRAKE M/CYL SERVICE KIT 88 | 2L13 |
| AAU 6919 | AVDELOK BOLT | 2H09 |
| AAU 6920 | RIVET | 2H11 |
| AAU 7090 | THROTTLE VALVE | 1M10 |
| AAU 7219 | EMISSION PACK | 1M11 |
| AAU 7803 | PIPE CLIP | 1L11 |
| AAU 7803 | CLIP FOR PIPES | 1L12 |
| AAU 7803 | PIPE CLIP | 1L13 |
| AAU 7803 | PIPE CLIP | 2L12 |
| AAU 7965 | CAP | 1L08 |
| AAU 7965 | FILLER CAP FOR MASTER CYL | 2L13 |
| AAU 7967 | CABLE TIE-VENT PIPES | 1M11 |
| AAU 8182 | RIVET | 2H11 |
| AAU 8469 | BRAKE LINING WITH RIVETS | 1L03 |
| AAU 8470 | BRAKE LINING WITH RIVETS | 1L04 |
| AAU 8471 | BRAKE LINING WITH RIVETS | 1L03 |
| AAU 8600 | SURGE PROTECTION DEVICE- | 2E10 |
| AAU 8600 | SURGE PROTECTION DEVICE | 2E12 |
| AAU 8600 | SURGE PROTECTION DEVICE-ALTERNATOR | 2E14 |
| AAU 8781 | TAPERPROOF PARTS KIT | 1M05 |
| AAU 8782 | TAMPERPROOF PARTS KIT | 1M02 |
| AAU 9902 | SEAL-FUEL FILTER CONTAINER | 1N10 |
| AAU 9903 | SEAL-FUEL FILTER CONTAINER | 1N10 |
| AAU 9942 | BRAKE LINING SET | 11.04 |
| AAU 9942 | BRAKE LINING WITH RIVETS | 1L02 |
| AB 604031 | L DRIVE SCREW | 2G10 |
| AB 604031 | L DRIVE SCREW | 2H16 |
| AB 606021 | L SCREW | 1C07 |
| AB 606021 | L DRIVE SCREW | 1C11 |
| AB 606021 | L DRIVE SCREW | 1C12 |
| AB 606021 | L DRIVE SCREW | 1E08 |
| AB 606021 | L DRIVE SCREW | 1E12 |
| AB 606021 | L SCREW FOR LIGHT UNIT | 2F02 |
| AB 606021 | L DRIVE SCREW | 2J03 |
| AB 606031 | L DRIVE SCREW | 1014 |