

PART NUMBER	DESCRIPTION	REF.NO.
AB 606031	L SCREW	2F13
AB 606031	L DRIVE SCREW	2G14
AB 606031	L DRIVE SCREW	2G16
AB 606031	L DRIVE SCREW	2G17
AB 606031	L SCREW	2H02
AB 606031	L SCREW	2H13
AB 606031	L DRIVE SCREW	2H18
AB 606031	L SCREW	2J03
AB 606031	L SCREW	2J04
AB 606031	L SCREW	2K08
AB 606031	L DRIVE SCREW	2L12
AB 606041	L SCREW	1014
AB 606041	L DRIVE SCREW	2F03
AB 606041	L DRIVE SCREW	2F04
AB 606041	L SCREW	2F05
AB 606041	L SCREW	2F06
AB 606041	L DRIVE SCREW	2G11
AB 606041	L DRIVE SCREW	2H03
AB 606041	L DRIVE SCREW	2H06
AB 606041	L DRIVE SCREW	2H17
AB 606041	L DRIVE SCREW	2H18
AB 606041	L SCREW	2J04
AB 606041	L DRIVE SCREW	2J06
AB 606041	L DRIVE SCREW	2J07
AB 606041	L DRIVE SCREW	2J08
AB 606041	L SCREW	2K02
AB 606041	L DRIVE SCREW	2K03
AB 606041	L DRIVE SCREW	2K04
AB 606051	L SCREW	2F13
AB 606051	L SCREW	2G05
AB 606051	L DRIVE SCREW	2L12
AB 606061	L DRIVE SCREW NO.6 X 0.75 cLONG	2G05
AB 606061	L SCREW	2J02
AB 606071	L SCREW	2G14
AB 606071	L DRIVE SCREW	2G17
AB 606081	L DRIVE SCREW NO 6 X 1" LONG	2K03
AB 606081	L DRIVE SCREW	2K04
AB 608031	L DRIVE SCREW	2H02
AB 608031	L DRIVE SCREW	2H05
AB 608031	L DRIVE SCREW	2H07
AB 608031	L DRIVE SCREW	2I15
AB 608031	L DRIVE SCREW	2J16
AB 608041	L SELF TAPPING SCREW	1L09
AB 608041	L DRIVE SCREW	2D04
AB 608041	L DRIVE SCREW	2G07

PART NUMBER	DESCRIPTION	REF. NO.
AB 608041	L DRIVE SCREW	2I02
AB 608041	L DRIVE SCREW	2J05
AB 608051	L DRIVE SCREW	2I03
AB 608061	L SELF TAPPING SCREW	2I02
AB 608081	L SCREW	2F05
AB 610031	L SCREW	1M13
AB 610031	L DRIVE SCREW	1N06
AB 610041	L SCREW	1014
AB 610041	L SCREW	2H11
AB 610041	L DRIVE SCREW	2J09
AB 610041	L SCREW	2J11
AB 610041	L DRIVE SCREW	2J13
AB 610051	L DRIVE SCREW	1N13
AB 610051	L DRIVE SCREW	1N13
AB 610051	L DRVE SCRW NO 10 X 0.625"LONG	2D02
AB 610051	L DRIVE SCREW	2F10
AB 610051	L DRIVE SCREW	2F11
AB 610051	L DRIVE SCREW	2G11
AB 610051	L DRIVE SCREW	2G12
AB 610051	L SCREW	2J08
AB 610051	L DRIVE SCREW	2K03
AB 610051	L DRIVE SCREW	2K04
AB 610051	L DRIVE SCREW	2L17
AB 610061	L SCREW	2J09
AB 610081	L DRIVE SCREW	2J09
AB 610081	L SCREW	2J13
AB 610124	L SCREW	2J02
AB 614061	L DRIVE SCREW NO.14 X 0.75 LONG	2G10
AB 614061	L SCREW	2G11
AB 614061	L SCREW	2G11
AB 614061	L SCREW	2J14
ABU 1361	WASHER	1N10
AC 606041	L DRIVE SCREW	2G14
AC 606041	L SCREW	2H03
AC 606041	L DRIVE SCREW	2H16
AC 606051	L DRIVE SCREW NO.6 X 0.625	2G17
AC 610121	L DRIVE SCREW NO.10 X 1.5	2G05
ACU 1161	AVDELOK BOLT	2H11
ACU 1762	MONOBOLT	2H11
ACU 2063	RIVET	2H11
ACU 3530	AVDELOK BOLT	2H11
ACU 3530	AUDELOK BOLT	2H13
ACU 3777	MONOBOLT	2H09
AD 604031	L SCREW NO.4 X 0.375 LONG	2H04
AD 606041	L SCREW	2I03

PART NUMBER		DESCRIPTION	REF.NO.
AD 606051	L	POZIDRIVE SCREW	2J02
ADU 1402	L	NON RETURN VALVE	1F07
AE 606051		SCREW	2K05
AE 606051		SCREW	2L05
AEU 1034		VACUUM UNIT	2E03
AEU 1043		SERVO UNIT-BRAKE	1L07
AEU 1043		SERVO UNIT	1L08
AEU 1043		SERVO UNIT	2L13
AEU 1044		ROLL PIN	1L08
AEU 1044		ROLL PIN BRAKE MASTER CYL	2L13
AEU 1045		RESERVOIR	1L08
AEU 1045		FLUID RESERVOIR KIT FOR MASTER CYL	2L13
AEU 1046		ADAPTOR-SERVO	1L07
AEU 1046		NON RETURN VALVE KIT	1L08
AEU 1046		NON-RETURN VALVE KIT	2L13
AEU 1047		REPAIR KIT, BRAKE M/CYL	1L08
AEU 1047		BRKE MASTER CYL SERVICE KIT 109	2L13
AEU 1058		LENS FLASHER LAMP REAR	2F04
AEU 1061		HEADLAMP COMPLETE	2F02
AEU 1124		DISTRIBUTOR ASSEMBLY	2E04
AEU 1147	L	CENTRE SEAL LOWER	1N09
AEU 1169		KNOB FOR SWITCH	2F09
AEU 1355		HEADLAMP COMPLETE	2F02
AEU 1367		RETAINER-STARTER-BENDIX SPRING	2E07
AEU 1367		RETAINER-BENDIX SPRING STARTER	2E08
AEU 1421		LEAD-LOW TENSION-DISTRIBUTOR	2E06
AEU 1422		VACUUM UNIT-DISTRIBUTOR	2E06
AEU 1428		BRUSH AND SPRING-DISTRIBUTOR	2E03
AEU 1447		CLIP	2G04
AEU 1448		CLIP	1L06
AEU 1448		CLIP-FUEL PIPE	1N13
AEU 1448		CLIP-FUEL PIPE	1N13
AEU 1448		CLIP-FUEL PIPE	1N17
AEU 1448		CLIP	2L08
AEU 1448		CLIP	2L12
AEU 1448		CLIP	2L14
AEU 1448		CLIP	2L15
AEU 1449		CLIP	1N11
AEU 1449		CLIP-FUEL PIPE	1N13
AEU 1449		CLIP-FUEL PIPE	1N13
AEU 1449		CLIP	2L08
AEU 1449		CLIP	2L15
AEU 1450		CABLE CLIP	1L16
AEU 1450		CABLE CLIP	2L08
AEU 1450		CLIP-'P' TYPE	2L16

PART NUMBER	DESCRIPTION	REF. NO.
AEU 1451	CLIP	2L08
AEU 1476	METERING NEEDLE	1M10
AEU 1487	CASING-REAR AXLE	1J12
AEU 1488	CROWN WHEEL AND PINION	1J13
AEU 1489	CASE-DIFFERENTIAL	1J13
AEU 1565	ARMATURE-ALTERNATOR	2E10
AEU 1565	ARMATURE-ALTERNATOR	2E12
AEU 1565	ARMATURE	2E14
AEU 1581	CLIP	2D02
AEU 1581	CLIP	2L08
AEU 1582	SLIDING JOINT	1J14
AEU 1583	SLIDING JOINT	1J04
AEU 1584	RUBBER GAITER	1J04
AEU 1586	CVER BRKT FOR STARTER MOTOR	2E07
AEU 1586	CAP-STARTER MOTOR END	2E08
AEU 1589	GASKET KIT	1M11
AEU 1613	SOLENOID LEVER AND PINION	2E09
AEU 1649	SOLENOID FOR STARTER MOTOR	2E09
AEU 1652	LAMP-NUMBER PLATE	2F04
AEU 1684	VACUUM UNIT-DISTRIBUTOR	2E03
AEU 1750	LINING CLUTCH	1G03
AEU 1804	NEEDLE METERING	1M07
AEU 1827	STUB SHAFT	1J05
AEU 1828	CV JOINT	1J05
AEU 1829	SHAFT RH	1J05
AEU 1830	SHAFT LH	1J05
AEU 1846	SPECIAL SCREW-THROTTLE STOP	1M02
AEU 1880	BRAKE LINING SET	1L04
AEU 1945	THERMAL SENSOR	1N05
AEU 1977	LOCKNUT-THROTTLE STOP	1M02
AEU 1978	THROTTLE SPINDLE	1M02
AEU 1979	SOLENOID	1M02
AEU 1980	VOLUME CONTROL SCREW	1M02
AEU 1983	MAIN JET	1M03
AEU 1985	CARB JET-EMULSION BLOCK	1M03
AEU 1994	VACUUM UNIT-DISTRIBUTOR	2E03
AEU 1997	UNIVERSAL JOINT(DOUBLE)	1J04
AEU 1998	CENTREING DEVICE	1J04
AEU 2515	OIL SEAL	1J12
AEU 2597	NUT AND GASKET ASSEMBLY	1N04
AEU 2760	REPAIR KIT FOR FUEL PUMP	1N06
AEU 2760	REPAIR KIT FOR FUEL PUMP	1N10
AEU 2760	REPAIR KIT FOR FUEL PUMP	2L07
AEU 2792	DRIVE ASSEMBLY FOR STARTER	2E09
AEU 3079	SURGE-PROTECTION DEVICE-	2E16

PART NUMBER		DESCRIPTION	REF.NO.
AEU	3080	EMULSION BLOCK	1M03
AEU	3081	ADJUSTING TOOL-THROTTLE STOP	1M02
AEU	3082	NEEDLE VALVE	1M03
AEU	3083	RELAY LEVER	1M02
AEU	4003	OVERHAUL KIT-CARBURETTER	1M02
AFU	1003	SPANNER BOX	2L11
AFU	1004	SPANNER-DOUBLE END	2L11
AFU	1005	SPANNER-DOUBLE END	2L11
AFU	1024	L COMBINATION PLIERS	2L11
AFU	1035	SCREW	2G18
AFU	1036	SCREW	2G18
AFU	1068	BOLT	1L04
AFU	1069	WASHER	1013
AFU	1069	WASHER-PLAIN	1007
AFU	1069	WASHER-PLAIN	1011
AFU	1070	PLAIN WASHER	2K07
AFU	1071	WASHER-PLAIN	2I04
AFU	1078	WASHER PLAIN	2I02
AFU	1079	WASHER PLAIN	2C11
AFU	1079	WASHER-PLAIN	2I15
AFU	1080	WASHER-PLAIN	2K05
AFU	1088	SCREW	2F09
AFU	1174	BLANKING PLUG	1L16
AFU	1202	AIR INJECTION PUMP	2L17
AFU	1203	BOLT	2G06
AFU	1248	WASHER-PLAIN	2J02
AFU	1248	WASHER-PLAIN	2J03
AFU	1256	WASHER-PLAIN	2H17
AFU	1263	WASHER-PLAIN	2K05
AFU	1302	BATTERY-15 PLATE	2F12
AFU	1303	BATTERY-15 PLATE	2F12
AFU	1331	AIR INJECTION PUMP	2L18
AFU	1497	DISTANCE PIECE	2I04
AFU	1841	MONOBOLT	2H11
AFU	1844	MONOBOLT	2H13
AFU	1882	JOINT WASHER	1C02
AFU	1882	L WASHER-JOINT	1E02
AFU	1887	WASHER JOINT	1C11
AFU	1887	L WASHER JOINT	1E11
AFU	1890	WASHER JOINT	1C11
AFU	1890	L WASHER JOINT	1E11
AFU	1900	SCREW	2K09
AFU	2501	PLUG	2K05
AFU	2501	PLUG	2L05
AFU	2503	TURN BUCKLE	2L04

PART NUMBER		DESCRIPTION	REF. NO.
AFU 2504		CATCH PLATE	2L04
AFU 2651		WASHER-PLAIN	2K07
AFU 2651		WASHER-PLAIN	2K08
AFU 2679		SCREW	2J14
AFU 2679		SCREW	2J14
AFU 2879		CLIP	2F14
AJ 614041		SPIRE NUT	2G10
AK 608041	L	CAPTIVE NUT	1014
AK 610021	L	SPRING NUT	2H03
AK 610021	L	SPRING NUT	2H06
AK 610021	L	SPRING NUT	2H08
AK 616011		SPIRE NUT	2G07
AM 605061		BOLT SPECIAL-WING TO DASH	2G08
AR 606031	L	SCREW	2H12
AR 608041	L	DRIVE SCREW NO 8 X 0.500	1014
AR 608041	L	SCREW NO 8 X 0.500 cLONG	2F07
AR 608047		SCREW	2F07
AR 608061		SCREW	2I04
AR 610051	L	SELF TAPPING SCREW	2H03
AR 610051	L	SCREW	2H06
AR 610051	L	SCREW	2H08
AR 610051	L	SCREW	2H13
ARA 1501	L	LOCKING RING FOR FUEL GAUGE	1003
ARA 1501	L	RETAINER-FUEL TANK GAUGE	1004
ARA 1501	L	LOCKING RING-FUEL GAUGE	1006
ARA 1502	L	SEALING RING FOR FUEL GAUGE	1003
ARA 1502	L	GASKET-FUEL TANK GAUGE	1004
ARA 1502	L	SEALING RING-FUEL GAUGE	1006
ARA 2404	L	FILLER PLUG	2D03
ASU 1302		BATTERY	2F12
AUA 573	L	JOINT WASHER-DISHED COVER	1N07
AUB 654	L	WASHER	1N07
AUB 656	L	DIAPHRAGM FOR AIR BOTTLE	1N07
AUB 657	L	SEALING RING-AIR BOTTLE COVER	1N07
AUB 676	L	SEALING WASHER-VALVE ASSY	1N07
AUB 795	L	JOINT WASHER AIR BOTTLE	1N07
AUB 809	L	JOINT WASHER DIAPHRAGM TO BODY	1N07
AUB 6106		CONTACT SET FUEL PUMP	1N07
AUB 9011	L	COVER FOR FUEL PUMP	1N07
AUD 2437	L	LEVER	1M12
AZX 1500		FUEL PUMP COMPLETE	1N07
BAU 1689		CLIP	1N11
BAU 1689		CLIP	2L08
BAU 1689		CLIP	2L15
BD 44001	L	PLUG	1L06

PART NUMBER		DESCRIPTION	REF.NO.
BD 44001	L	SEALING PLUG	2L09
BD 44001	L	PLUG-BLANKING	2L12
BD 155888	L	SEALING PLUG	2L09
BH 106051	L	BOLT	1F02
BH 106051	L	BOLT	1G04
BH 106051	L	BOLT	1K04
BH 106061	L	BOLT	1L09
BH 106061	L	BOLT	1L10
BH 106061	L	BOLT	1L11
BH 106061	L	BOLT	1L12
BH 106061	L	BOLT	1L13
BH 106061	L	BOLT	2C11
BH 106071		BOLT	1013
BH 106071		BOLT	2J14
BH 106071	L	BOLT	1007
BH 106071	L	BOLT	1011
BH 106071	L	BOLT	2I02
BH 106081	L	BOLT	2H05
BH 106081	L	BOLT	2L14
BH 106081	L	BOLT	2L15
BH 106091	L	BOLT FIXING BRACKET	2L12
BH 106101		BOLT	1L11
BH 106101		BOLT	1L13
BH 106111	L	BOLT	2H13
BH 106121		BOLT	2H13
BH 106131	L	BOLT	1C10
BH 106131	L	BOLT	1E10
BH 106141	L	BOLT	1C10
BH 106161	L	BOLT	1014
BH 108061	L	BOLT	1C04
BH 108061	L	BOLT	1E05
BH 108061	L	BOLT	1I03
BH 108061	L	BOLT	1I12
BH 108081	L	BOLT	2C03
BH 108081	L	BOLT	2C11
BH 108091	L	BOLT	1E08
BH 108091	L	BOLT	2C11
BH 108101	L	BOLT	1C07
BH 108101	L	BOLT	1C13
BH 108101	L	BOLT	1E08
BH 108111	L	BOLT	1E06
BH 108111	L	BOLT	2H10
BH 108141	L	BOLT	1C13
BH 108141	L	BOLT	1E08
BH 108151	L	SET BOLT	1C06

PART NUMBER		DESCRIPTION	REF.NO.
BH 108151	L	BOLT	1C07
BH 108151	L	BOLT	1E08
BH 108161	L	BOLT	1C07
BH 108161	L	BOLT	1E08
BH 108161	L	BOLT	2E11
BH 108161	L	BOLT	2E15
BH 108171	L	BOLT	1C07
BH 108171	L	BOLT	1E08
BH 108181	L	BOLT	1C07
BH 108201	L	BOLT	1I05
BH 108201	L	BOLT	1I05
BH 108201	L	BOLT	1I05
BH 108251	L	BOLT	1E09
BH 108351		BOLT	2H13
BH 110071	L	BOLT	1G02
BH 110071	L	BOLT	1I11
BH 110081	L	BOLT	1K05
BH 110091	L	BOLT	1G03
BH 110091	L	BOLT	2E09
BH 110101	L	BOLT	2L03
BH 110121	L	BOLT	1I10
BH 110121	L	BOLT	1I11
BH 110121	L	BOLT	2L02
BH 110161	L	BOLT	2L02
BH 110241	L	BOLT	2L03
BH 112101	L	BOLT	1J07
BH 112121	L	BOLT	1I02
BH 116161	L	BOLT	1I02
BH 116261		BOLT	2L03
BH 408181		BOLT	2L02
BH 504101	L	BOLT	1F10
BH 504101	L	BOLT	1F11
BH 504121	L	BOLT	1D14
BH 504121	L	BOLT (0.25"UNC X 1.50"LONG)	2L17
BH 504161	L	BOLT	1F10
BH 504161	L	BOLT	1F11
BH 505111	L	BOLT	1M11
BH 505111	L	BOLT	2E16
BH 505121	L	BOLT	1F10
BH 505121	L	BOLT	1F11
BH 505201	L	BOLT 0.3125 UNC X 2.5 LONG	1N02
BH 505241	L	BOLT	1F04
BH 505241	L	BOLT(0.3125" UNC X 3")	1N02
BH 505381	L	BOLT	1F10
BH 505381	L	BOLT	1F11

PART NUMBER		DESCRIPTION	REF.NO.
BH 505401	L	BOLT	1F10
BH 505401	L	BOLT	1F11
BH 506111	L	BOLT	2E16
BH 506121	L	BOLT	1F07
BH 506161	L	BOLT	1F07
BH 506161	L	BOLT	1I02
BH 506201	L	BOLT	2E16
BH 506221	L	BOLT	1F08
BH 604081		BOLT	2H12
BH 604081	L	BOLT(0.25"UNF X 1")	1D10
BH 604091	L	BOLT(0.25"UNF X 1.25")	1D10
BH 604091	L	BOLT	1E10
BH 604091	L	BOLT	1F12
BH 604091	L	BOLT	2L13
BH 604101	L	BOLT	1D10
BH 604101	L	BOLT	1L09
BH 604101	L	BOLT	1007
BH 604101	L	BOLT	1009
BH 604101	L	BOLT	1010
BH 604101	L	BOLT	1011
BH 604101	L	BOLT	1014
BH 604101	L	BOLT 0.25 UNF X 1.25"	2L17
BH 604111	L	BOLT(0.25" UNF X 1.375")	1D06
BH 604121	L	BOLT 0.25 UNF X 1.50 LONG	2H05
BH 604141	L	BOLT(0.25"UNF X 1.625")	1D10
BH 604141	L	BOLT	1L12
BH 604161	L	BOLT(0.25" UNF X 1.875")	1K06
BH 604161	L	BOLT	1K07
BH 604161	L	BOLT	1K08
BH 604161	L	BOLT	2K04
BH 604161	L	BOLT	2K05
BH 604181	L	BOLT(0.25"UNF X 1.125")	1D10
BH 604181	L	BOLT	2H13
BH 604201	L	BOLT	1C10
BH 604201	L	BOLT	1E10
BH 605101	L	BOLT	1C04
BH 605101	L	BOLT	1E05
BH 605111	L	BOLT	2K06
BH 605121	L	BOLT	1D15
BH 605121	L	BOLT	1F03
BH 605121	L	BOLT	1H13
BH 605121	L	BOLT	1L07
BH 605121	L	BOLT	2C03
BH 605121	L	BOLT	2C10
BH 605121	L	BOLT(0.3125"UNF X 1.50")	2E11

PART NUMBER		DESCRIPTION	REF. NO.
BH 605121	L	BOLT	2E13
BH 605121	L	BOLT	2E15
BH 605121	L	BOLT	2E16
BH 605141	L	BOLT	1E08
BH 605161	L	BOLT	1C07
BH 605161	L	BOLT(0.3125"UNF X 2")	1C13
BH 605161	L	BOLT	1D09
BH 605161	L	BOLT	1D13
BH 605161	L	BOLT	1E06
BH 605161	L	BOLT	1E08
BH 605161	L	BOLT(0.3125"UNF X 1.875")	2E11
BH 605161	L	BOLT	2E15
BH 605161	L	BOLT	2H16
BH 605161	L	BOLT	2I02
BH 605201	L	BOLT	2E16
BH 605221	L	BOLT(0.3125" UNF X 2.75")	1C13
BH 605241	L	SET BOLT	1C07
BH 605241	L	BOLT	1E08
BH 605261	L	BOLT	1C07
BH 605261	L	BOLT	1E08
BH 605261	L	BOLT	2E11
BH 605261	L	BOLT	2E15
BH 605281	L	BOLT	1C07
BH 605317		BOLT 0.3125 X 3.875"	1K04
BH 605321	L	BOLT	1E08
BH 605321	L	BOLT	1E09
BH 605381		BOLT 0.3125 UNF X 4.75"	2L17
BH 605381	L	BOLT	1D14
BH 606111	L	BOLT	1006
BH 606121	L	BOLT	1002
BH 606121	L	BOLT	1003
BH 606121	L	BOLT	1005
BH 606121	L	BOLT	1006
BH 606141	L	BOLT 0.375" UNF X 1.75"	1G03
BH 606181	L	BOLT 0.375 UNF X 2.25"	1L14
BH 606181	L	BOLT	2C05
BH 606201	L	BOLT(0.375"UNF X 2.50")	1002
BH 606201	L	BOLT	1003
BH 606201	L	BOLT	1005
BH 606201	L	BOLT	1006
BH 606281	L	BOLT	1D15
BH 606281	L	BOLT	2G02
BH 607141	L	BOLT (0.437" UNF X 2")	2E09
BH 607241	L	BOLT(0.4375"UNF X 3")	1D13
BH 607281	L	BOLT(0.4375"UNF X 3.50")	1D13

PART NUMBER		DESCRIPTION	REF.NO.
BH 608241	L	BOLT	2L02
BHA 4790	L	STRAP	2F06
BHM 1067	L	NEEDLE VALVE PACK	1M03
BHM 1079	L	CARB NEEDLE VALVE PACK	1M08
BHM 1079	L	NEEDLE VALVE PACK	1M11
BHM 1082	L	EMISSION PACK	1M07
BHM 1082	L	EMISSION PACK	1M08
BHM 7063	L	GROMMET-CLUTCH CYLINDER	1G05
BHM 7196	L	HEADLAMP COMPLETE	2F02
BLS 108	L	BALL-STEEL	1H04
BLS 108	L	BALL-STEEL	1H06
BLS 108	L	BALL-STEEL	1I03
BLS 108	L	BALL-STEERING	1I06
BLS 109	L	STEEL BALL	1K02
BLS 112	L	STEEL BALL	1K02
BMK 1903		NUT	1L06
BMK 1903		LOCKNUT	2L13
BTB 657	L	TEE PIECE	1L09
BTB 657	L	TEE PIECE	1L12
BX 406121		BOLT	1L03
BX 604221	L	BOLT 0.25 UNF X 2.75	1C10
BX 604221	L	BOLT(0.25"UNF X 2.75")	1D10
BX 605281		BOLT(0.3125" UNF X 3.50")	1K05
BX 607181		BOLT(0.4375" UNF X 2.25")	1K05
C 3964	L	CIRCLIP FOR GUDGEON PIN	1D04
C 36617	L	TENSIONER	1D06
C 37222	L	FAN-ALTERNATOR	2E16
C 41866	L	EXHST GAS RECIRULATING VLVE	2L12
C 43640	L	CABLE TIE	2F14
C 45099	L	RATCHET STRAP	1N08
CA 600424		CLIP,TUBE TO AIR CLEANER AND	1N04
CCN 110	L	CIRCLIP FOR CROSS SHAFT	1J08
CCN 112	L	CIRCLIP	1L15
CCN 122		CIRCLIP	1H07
CCN 260		CIRCLIP	1I06
CD 31709	B	KEY BLANK	2G15
CD 31709	C	KEY CUT	2G15
CD 31726	B	KEY-BLANK-REAR DOOR LOCK	2H18
CD 31726	C	KEY CUT	2F09
CD 31726	C	KEY-CUT-REAR DOOR LOCK	2H18
CJ 600144	L	HOSE CLIP	1F08
CJ 600384	L	CLIP	1J04
CN 100208	L	CLIP	1C14
CN 100408	L	CLIP	1C10
CN 100408	L	HOSE CLIP	1E10

PART NUMBER	DESCRIPTION	REF. NO.
CN 100508	CLIP	1J04
CN 100508	HOSE CLIP	1N06
CN 100508	HOSE CLIP-FUEL FILLER	1N14
CN 100508	HOSE CLIP-FUEL FILLER	1N15
CN 100508	HOSE CLIP-FUEL FILLER	1N16
CN 100508	HOSE CLIP-FUEL FILLER PIPE	1N17
CN 100508	HOSE CLIP	2D02
CN 100508	HOSE CLIP	2D04
CN 100508	L CLIP	1D10
CP 105161	L CLIP	1013
CP 105161	L CLIP-EXPANSION HOSE	2D04
CP 106101	CLIP	2D04
CRC 1226	CLIP-PIPE	1F06
CRC 1226	CLIP	1N12
CRC 1250	PIPE CLIP	1L09
CRC 1250	PIPE CLIP	1L10
CRC 1250	PIPE CLIP	1L11
CRC 1250	PIPE CLIP-SINGLE	1L12
CRC 1250	PIPE CLIP	1L13
CRC 2131	VACUUM HOSE	1L07
CRC 2131	VACUUM HOSE	2L17
CZK 9845	L INTERIOR DRIVING MIRROR	2I03
CZX 1004	DIODE RESISTOR SUPPRESSOR	1N07
DRC 1596	TRANSMITTER-OIL PRESSURE	1F05
DRC 1820	RELAY	2F02
DRC 2479	TRANSMITTER-OIL PRESSURE	1F05
ERC 210	SEAT-VALVE EXHAUST STANDARD	1F09
ERC 211	SEAT-VALVE EXHAUST 0.010" O/S	1F09
ERC 215	CYLINDER HEAD	1F09
ERC 224	SEAT-VALVE INLET STANDARD	1F09
ERC 225	SEAT-VALVE INLET 0.010" O/S	1F09
ERC 256	CUP PLUG	1D11
ERC 256	CUP-PLUG	1F06
ERC 298	HOSE	1C09
ERC 416	WASHER	1F03
ERC 417	BOLT	1F03
ERC 573	RETAINER-VALVE SPRING	1F05
ERC 614	BRACKET-ENGINE LIFTING	1F10
ERC 676	CYLINDER HEAD	1F09
ERC 783	SCREEN COVER FOR DISTRIBUTOR	2E04
ERC 783	COVER-DISTRIBUTOR SUPPRESSION	2E05
ERC 783	SCREEN COVER FOR DISTRIBUTOR	2L17
ERC 1027	CONNECTING ROD NUT	1D04
ERC 1029	NUT-CONNECTING ROD	1E03
ERC 1351	SHAFT AND GEAR-OIL PUMP	1F05

PART NUMBER	DESCRIPTION	REF.NO.
ERC 1353	DOG-DISTRIBUTOR DRIVING	2E06
ERC 1373	VISCOUS FAN	1E10
ERC 1454	AIR TUBE ASSEMBLY	1D14
ERC 1454	AIR TUBE ASSEMBLY	2L17
ERC 1456	MANIFOLD ADAPTOR	1D14
ERC 1456	EXHAUST MANIFOLD ADAPTOR-FRT	2L17
ERC 1460	MANIFOLD ADAPTOR	1D14
ERC 1460	EXHAUST MANIFOLD ADAPTOR-RR	2L17
ERC 1469	HEAT SHIELD FOR DISTRIBUTOR	2L17
ERC 1469	HEAT SHIELD FOR DISTRIBUTOR	2E05
ERC 1561	CAMSHAFT THRUST PLATE	1C05
ERC 1561	PLATE-RETAINING CAMSHAFT	1E05
ERC 1637	SPLIT CONE-VALVE HALVES	1F05
ERC 1742	FAN AND ALTERNATOR BELT	1D10
ERC 1742	FAN AND ALTERNATOR BELT	2L17
ERC 1837	DISTRIBUTOR	2L17
ERC 1837	DISTRIBUTOR COMPLETE	2E05
ERC 1935	ADAPTOR CARB TO CYLINDER HEAD	1M07
ERC 1935	ADAPTOR-CARBURETTER TO	2L17
ERC 1936	SUPPORT PLATE SOLENOID	1M07
ERC 1936	SUPPORT PLATE FOR SOLENOID	2L17
ERC 2003	CAMSHAFT	1F06
ERC 2042	FUEL TRAP	1M08
ERC 2042	FUEL TRAP	2L17
ERC 2069	COVER FRONT-ENGINE	1F04
ERC 2139	PIPE-WATER OUTLET	1F07
ERC 2143	OUTLET PIPE	1F07
ERC 2144	SPACER-SECURING H.T. LEAD	2L18
ERC 2151	STUD-SPECIAL	1E07
ERC 2194	VACUUM PIPE	1M09
ERC 2209	SUMP-ENGINE OIL	1E07
ERC 2210	NUT-SPECIAL	1E07
ERC 2250	TIMING POINTER	1G03
ERC 2254	ENGINE LIFTING BRACKET FRONT	1C11
ERC 2254	BRACKET-ENGINE LIFTING-FRONT	1E11
ERC 2275	ENGINE LIFTING BRKT REAR-SIDE	1D12
ERC 2280	ENGINE LIFTING BRACKET FRONT	1D12
ERC 2297	CONNECTION	1F06
ERC 2319	HOSE-WATER	1F07
ERC 2320	HOSE	1F07
ERC 2337	S PISTON ASSY STD	1D04
ERC 2339	S PISTON ASSY STD	1D04
ERC 2363	MOUNTING BRACKET FRONT	2E13
ERC 2363	MOUNTING BRACKET-FRONT	2L17
ERC 2364	MOUNTING BRACKET REAR	2E13

PART NUMBER	DESCRIPTION	REF. NO.
ERC 2364	MOUNTING BRACKET-REAR	2L17
ERC 2369	DISTANCE PIECE	1D14
ERC 2369	DISTANCE PIECE FOR AIR PUMP	2L17
ERC 2370	FAN PULLEY	1D10
ERC 2370	FAN PULLEY	1D11
ERC 2370	FAN PULLEY	2L17
ERC 2429	BAFFLE-SUMP	1E07
ERC 2429	BAFFLE SUMP	1E08
ERC 2434	JOINT WASHER-ENGINE OIL SUMP	1E07
ERC 2435	RETAINER-ENGINE OIL SUMP	1E07
ERC 2436	RETAINER-ENGINE OIL SUMP	1E07
ERC 2437	RETAINER-ENGINE OIL SUMP	1E07
ERC 2443	PUMP ASSEMBLY-OIL	1F05
ERC 2446	COUNTERSHAFT AND LEVER	1M12
ERC 2456	HOSE	1D14
ERC 2456	HOSE-AIR PUMP TO CHECK VALVE	2L17
ERC 2523	HT LEAD SET	2E04
ERC 2523	LEADS-DISTRIBUTOR-HIGH TENSION	2E05
ERC 2600	EXHAUST GAS DAMPER ASSEMBLY	2L12
ERC 2604	HOSE EGR VALVE TO CARBURETTER	2L12
ERC 2605	MOUNTING BRACKET EGR VALVE	2L12
ERC 2607	HOSE ELBOW TO FLAME TRAP	2L12
ERC 2653	PULLEY	2L18
ERC 2657	AIR INJECTOR PUMP	1D14
ERC 2657	AIR INJECTION PUMP	2L17
ERC 2658	BRACKET	1D14
ERC 2658	ADJUSTING BRACKET FOR AIR	2L17
ERC 2659	BRACKET	1D14
ERC 2659	ADJUSTING BRACKET FOR AIR	2L17
ERC 2660	BRACKET	1D14
ERC 2660	ANCHOR BRACKET FOR AIR PUMP	2L17
ERC 2661	BRACKET	1D14
ERC 2661	SUPPORT BRACKET FOR AIR PUMP	2L17
ERC 2662	FAN BELT	1D14
ERC 2662	DRIVING BELT FOR AIR PUMP	2L17
ERC 2690	TUBE-DIPSTICK	1F02
ERC 2695	AIR INLET ELBOW	2L16
ERC 2696	PLATE-ROCKER SHAFT	1C06
ERC 2735	TEE PIECE	1C14
ERC 2735	T PIECE	1M09
ERC 2838	KEY-WOODRUFF	1F06
ERC 2839	SPACER-CAMSHAFT CHAINWHEEL	1F06
ERC 2849	VISCOUS COUPLING UNIT	1D10
ERC 2849	VISCOUS COUPLING UNIT FOR FAN	1D11
ERC 2849	VISCOUS DRIVE UNIT	1F12

PART NUMBER	DESCRIPTION	REF. NO.
ERC 2849	VISCOUS COUPLING FOR FAN	2L17
ERC 2866	TOP ROCKER COVER	1C12
ERC 2867	BREATHER-TOP ROCKER	1C12
ERC 2869	BLANKING PLATE	1C08
ERC 2869	SIDE COVER	1C09
ERC 2870	HOSE	1C09
ERC 2871	HOSE	1C09
ERC 2875	PLUG	1C09
ERC 2876	CARBURETTER ELBOW	1C09
ERC 2886	CARBURETTER COMPLETE	1M02
ERC 2915	VACUUM PIPE	2L15
ERC 2974	ADAPTOR ASSEMBLY	1C09
ERC 3093	AIR PIPE CARBURETTER TO DISTRIBUTOR	1M07
ERC 3093	AIR PIPE-CARBURETTER TO	2L17
ERC 3094	FUEL PIPE	1M08
ERC 3094	VACUUM PIPE	2L15
ERC 3094	AIR PIPE-FUEL TRAP TO	2L17
ERC 3095	AIR PIPE	1M08
ERC 3095	AIR PIPE-CARBURETTER TO	2L17
ERC 3101	EXHAUST MANIFOLD RH	1F08
ERC 3163	CLIP	1F06
ERC 3163	BRACKET	1M12
ERC 3179	TUBE-ENGINE OIL FILTER	1F10
ERC 3192	ADAPTOR CARBURETTER TO EGR VALVE	2L12
ERC 3233	TEE PIECE	1C09
ERC 3251	DISTRIBUTOR COMPLETE	2L12
ERC 3256	IGNITION LEAD SET	2E02
ERC 3256	LEADS-DISTRIBUTOR-HIGH TENSION	2E03
ERC 3305	CARB COMPL WITH THROTTLE JACK	1M07
ERC 3315	BOLT-SPECIAL	1E07
ERC 3315	PLUG	1E08
ERC 3316	BOLT-SPECIAL	1E07
ERC 3316	PLUG	1E08
ERC 3324	CLIP	1D12
ERC 3324	CLIP FIXING HOSE TO STUD ON	2L17
ERC 3325	ROCKER COVER	1D12
ERC 3342	DISTRIBUTOR ASSEMBLY	2E06
ERC 3343	HOSE	1D12
ERC 3343	HOSE-ROCKER COVER BREATHER	2L17
ERC 3458	STUD	1F09
ERC 3482	EXHAUST MANIFOLD LH	1F08
ERC 3489	HOSE WATER	1F07
ERC 3493	RESTRICTOR	1F07
ERC 3525	AIR MANIFOLD	1D14
ERC 3525	AIR MANIFOLD ASSEMBLY	2L17

PART NUMBER	DESCRIPTION	REF.NO.
ERC 3561	PIPE-WATER OUTLET	1F06
ERC 3562	HOSE WATER	1F07
ERC 3563	CONNECTING WATER PIPE	1F07
ERC 3588	AIR TUBE	1M12
ERC 3600	PULLEY CRANKSHAFT	1C03
ERC 3600	PULLEY-CRANKSHAFT	1E03
ERC 3690	STUD	1F08
ERC 3690	STUD	1F09
ERC 3699	WASHER PLAIN	1F08
ERC 3729	CLIP	1F07
ERC 3788	NON-RETURN VALVE	1N10
ERC 3892	SUPPORT BRACKET ASSEMBLY-çLH-FOR	1N04
ERC 3893	SUPPORT BRACKET ASSEMBLY-çRH-FOR	1N04
ERC 3895	AIR CLEANER 'CYCLONE'	1N04
ERC 3896	BAFFLE ASSEMBLY	1N04
ERC 3897	RETAINING STRAP	1N04
ERC 3899	AIR SEAL	1N04
ERC 3930	HOSE	1M13
ERC 3931	HOSE	1M13
ERC 3946	RETAINING STRAP	1N04
ERC 3954	HOSE-BREATHER TO FILTER	1N04
ERC 3955	HOSE-FILTER TO AIR CLEANER	1N04
ERC 3978	SPINDLE WATER PUMP	1D09
ERC 3980	SUPPORT BRACKET FOR JUMP HOSE	1G04
ERC 3990	GASKET-INLET MANIFOLD	1F07
ERC 4181	INTAKE ELBOW	1N05
ERC 4182	VIBRATION DAMPER	1D04
ERC 4199	OIL LEVEL ROD	1C07
ERC 4199	DIPSTICK	1E07
ERC 4199	DIPSTICK	1E08
ERC 4203	AIR TUBE	1M12
ERC 4204	AIR TUBE	1M12
ERC 4374	INSULATOR	1M09
ERC 4375	WASHER JOINT	1M09
ERC 4383	INLET-MANIFOLD	1F06
ERC 4387	ENGINE LIFTING BRACKET REAR	1D12
ERC 4397	DEFLECTOR	1N06
ERC 4400	AIR CONTROL VALVE	1N06
ERC 4419	CARBURETTER COMPLETE	1M02
ERC 4480	FUEL LEAK OFF PIPE	1N13
ERC 4480	FUEL LEAK OFF PIPE	1N13
ERC 4484	GASKET-HOT AIR HOUSING	1F08
ERC 4494	HOUSING-HOT AIR	1F08
ERC 4506	HEATSHIELD	1F09
ERC 4558	DIPSTICK	1F02

PART NUMBER	DESCRIPTION	REF.NO.
ERC 4571	AIR CLEANER	1N05
ERC 4644	DOWEL FLYWHEEL HOUSING	1C02
ERC 4644	DOWEL	1E02
ERC 4650	DOWEL	1C03
ERC 4650	DOWEL	1E03
ERC 4658	PLATE-REFORCING-FLYWHEEL	1G02
ERC 4658	PLATE-REINFORCING-FLYWHEEL	1G03
ERC 4670	BRACKET	1M13
ERC 4672	STARTING DOG	1C03
ERC 4672	STARTING DOG	1E03
ERC 4702	CARBURETTER LH	2L18
ERC 4703	CARBURETTER RH	2L18
ERC 4707	CYLINDER HEAD	1D11
ERC 4709	CUP PLUG	1D11
ERC 4720	EXHAUST MANIFOLD RH	1F08
ERC 4794	HEAT SHIELD CARBURETTER RH	2L18
ERC 4809	ADAPTOR	1F07
ERC 4809	ADAPTOR-VACUUM NON-RETURN	2L18
ERC 4819	INLET-MANIFOLD	1F06
ERC 4819	INLET MANIFOLD ASSEMBLY	2L18
ERC 4820	ADAPTOR-AIR BLEED	1F06
ERC 4820	ADAPTOR-INLET MANIFOLD	2L18
ERC 4823	DISTRIBUTOR COMPLETE	2L18
ERC 4825	LOCKNUT-ELBOW-INLET MANIFOLD	2L18
ERC 4848	CARBURETTER COMPLETE	2L17
ERC 4877	WEIGHT BALANCE-CRANKSHAFT	1F03
ERC 4878	WEIGHT BALANCE-CRANKSHAFT	1F03
ERC 4879	WEIGHT BALANCE-CRANKSHAFT	1F03
ERC 4880	WEIGHT BALANCE-CRANKSHAFT	1F03
ERC 4935	INSERT-EXHAUST VALVE SEAT	1D03
ERC 4935	INSERT-EXHAUST VALVE SEAT	2L17
ERC 4949	TAPPET-VALVE	1F05
ERC 4970	TOP ROCKER COVER ASSEMBLY	2L17
ERC 4989	GASKET-HOT AIR HOUSING	1F08
ERC 4996	PLUG	1C02
ERC 4996	CUP PLUG	1E02
ERC 5014	CRANKSHAFT STD	1C03
ERC 5014	CRANKSHAFT	1E03
ERC 5037	HOUSING-FLYWHEEL	1G03
ERC 5052	HOSE-AIR INLET DUCT TO ELBOW	1N04
ERC 5086	SEAL-MAIN BEARING	1C02
ERC 5086	SEALING-REAR MAIN BEARING	1E02
ERC 5088	DISTRIBUTOR ASSEMBLY	2E06
ERC 5169	PULLEY	1D14
ERC 5169	PULLEY FOR AIR PUMP	2L17

PART NUMBER	DESCRIPTION	REF.NO.
ERC 5247	AIR INTAKE ELBOW	1N04
ERC 5263	N ENGINE COMPLETE ASSY DIESEL	1E02
ERC 5266	CYLINDER HEAD 8:1 CR	1C11
ERC 5329	CARBURETTER COMPLETE	1M09
ERC 5330	CARBURETTER COMPLETE	1M09
ERC 5349	CRANKSHAFT PULLEY	1C03
ERC 5349	PULLEY-CRANKSHAFT	1E03
ERC 5361	TIMING POINTER AT FRONT COVER	1C07
ERC 5400	ADAPTOR,AIR CLEANER	1N04
ERC 5401	CONNECTING TUBE	1N04
ERC 5453	AIR INLET DUCT	1N04
ERC 5475	CAMSHAFT	1E05
ERC 5477	AIR MANIFOLD LH ASSEMBLY	2L18
ERC 5491	CARBURETTER COMPLETE	1M09
ERC 5492	CARBURETTER COMPLETE	1M09
ERC 5494	ADAPTOR-AIR INTAKE	1M11
ERC 5504	PETROL PIPE	1M09
ERC 5504	PETROL PIPE ASSEMBLY	2L18
ERC 5505	IGNITION LEAD SET	2L18
ERC 5511	Y CONNECTION	2L18
ERC 5512	RETAINER-SPARK PLUG CABLES	2L18
ERC 5513	ADAPTOR ASSEMBLY-AIR CLEANER	2L18
ERC 5536	VENT PIPE RH	1M11
ERC 5537	VENT PIPE LH	1M11
ERC 5547	CONNECTING TUBE	2L18
ERC 5548	VENT PIPE RH-ADAPTOR Y PIECE	2L18
ERC 5549	VENT PIPE LH-ADAPTOR Y PIECE	2L18
ERC 5550	VENT PIPE-Y CONNECTION-	2L18
ERC 5551	VACUUM PIPE-EGR VALVE-TO TEE	2L18
ERC 5552	VACUUM PIPE-LH CARBURETTER	2L18
ERC 5558	CLIP-ROCKER COVER LH	2L18
ERC 5560	AIR INLET DUCT ASSEMBLY	2L18
ERC 5603	AIR INTAKE ELBOW	2L18
ERC 5610	CHOKE PIPE	1M09
ERC 5610	CHOKE CONNECTING PIPE ASSY	2L18
ERC 5761	CRANKCASE BREATHER	1F02
ERC 5761	CRANKCASE BREATHER ASSEMBLY	2L18
ERC 5786	HEATSHIELD	1F09
ERC 5869	BLANKING PLUG-AIR CLEANER	2L18
ERC 5875	HEATSHIELD	1F09
ERC 5900	CYLINDER HEAD 7:1 CR	1C11
ERC 5925	EXHAUST MANIFOLD RH	1F08
ERC 5956	HOSE-BREATHER-CRANKCASE	2L18
ERC 5957	HOSE-BREATHER FILTER-TO	2L18
ERC 5958	BRACKET BREATHER CLIP	2L18

PART NUMBER	DESCRIPTION	REF.NO.
ERC 5996	EXHAUST MANIFOLD	1C13
ERC 5998	PIPE	1N05
ERC 6081	ADAPTOR ASSEMBLY	1C09
ERC 6083	PIPE	1C14
ERC 6090	ADAPTOR	1C09
ERC 6091	BRACKET	1C14
ERC 6094	PIPE	1C14
ERC 6095	CLIP	1C14
ERC 6096	SUCTION PIPE	1C14
ERC 6112	E.G.R.VALVE	1C14
ERC 6318	VACUUM PIPE-TEE PIECE TO	2L18
ERC 6337	PLUG FOR ROCKER SHAFT END	1C06
ERC 6337	PLUG-SHAFT	1E06
ERC 6341	ROCKER SHAFT	1C06
ERC 6341	ROCKER SHAFT	1E06
ERC 6353	ELBOW	1F07
ERC 6353	ELBOW INTAKE MANIFOLD	2L18
ERC 6354	E.G.R.PIPE ASSEMBLY	1F08
ERC 6354	PIPE ASSEMBLY-EGR TO INLET	2L18
ERC 6373	HOUSING HOT AIR	1F08
ERC 6380	GASKET-CYLINDER HEAD	1C11
ERC 6392	FLYWHEEL ASSEMBLY	1G02
ERC 6432	SEAL-RING-FLYWHEEL HOUSING	1G02
ERC 6432	O RING	1G03
ERC 6551	BOLT	1G02
ERC 6551	BOLT	1G03
ERC 6552	WASHER-PLAIN	1F06
ERC 6572	CARBURETTER COMPLETE	1M02
ERC 6573	CARBURETTER ELBOW	1C09
ERC 6604	DISTRIBUTOR PUMP	1N10
ERC 6673	N ENGINE ASSEMBLY 2.25 PETROL	1C02
ERC 6691	BANJO RING AND PIPE	1C13
ERC 6794	EXHAUST VALVE	1E06
ERC 6795	INLET VALVE	1E06
ERC 6821	WASHER	1C11
ERC 6821	WASHER	1E11
ERC 6877	AIR RAIL ASSEMBLY	1M12
ERC 6878	CHECK VALVE	1M12
ERC 6881	CONNECTION HOSE	1M12
ERC 6909	CONNECTION PIPE	1M12
ERC 6910	CONNECTION TUBE	1M12
ERC 6934	CYLINDER BLOCK	1F02
ERC 6934	CYLINDER BLOCK ASSEMBLY	2L18
ERC 6935	CYLINDER BLOCK	1F02
ERC 6996	SUCTION PIPE	1M04

PART NUMBER	DESCRIPTION	REF.NO.
ERC 6997	VALVE	1M09
ERC 6998	CARBURETTER COMPLETE	1M09
ERC 6999	CARBURETTER COMPLETE	1M09
ERC 7000	AIR CLEANER	1N05
ERC 7075	ADAPTOR	1N06
ERC 7076	AIR INTAKE HOSE	1N06
ERC 7079	DEFLECTOR	1N06
ERC 7085	HOSE	1C14
ERC 7101	ADAPTOR	1C14
ERC 7150	INLET VALVE	1C06
ERC 7151	EXHAUST VALVE	1C06
ERC 7166	HOSE	1M13
ERC 7174	EXHAUST MANIFOLD RH	1F08
ERC 7176	EXHAUST MANIFOLD RH	1F08
ERC 7295	PLUG-FLYWHEEL HOUSING	1G03
ERC 7321	WASHER LOCK	1F08
ERC 7341	HOUSING FLYWHEEL	1G02
ERC 7343	CONTROL VALVE	1C14
ERC 7530	OIL FILTER OIL PUMP	1C04
ERC 7530	STRAINER-OIL PUMP	1E04
ERC 7744	THROTTLE LINK	1M12
ERC 7865	SEALING RING	1F09
ERC 7929	CHAIN-TIMING	1F06
ERC 7940	SUPPORT BRACKET	1C04
ERC 7940	BRACKET-SUPPORT	1E04
ERC 7951	JOINT WASHER	1C10
ERC 7951	GASKET-THERMOSTAT HOUSING	1E10
ERC 7987	OIL SEAL	1C07
ERC 7987	SEAL-OIL-FRONT COVER	1E08
ERC 7987	SEAL OIL-FRONT COVER	1F04
ERC 7988	CONNECTING HOSE	1N03
ERC 7990	RESONATOR	1N03
ERC 8049	SEALING RING	1E12
ERC 8051	TOP ROCKER COVER ASSY	1E12
ERC 8119	VALVE	1M04
ERC 8154	SUMP	1E08
ERC 8155	STUD	1E08
ERC 8408	WASHER JOINT	1C04
ERC 8408	JOINT WASHER	1E04
ERC 8450	GLOWPLUG	1E11
ERC 8505	AIR CLEANER ASSEMBLY	1N04
ERC 8634	CARBURETTER COMPLETE	1M02
ERC 8663	TUBE	1E11
ERC 8751	SPECIAL BOLT	1C03
ERC 8964	BOLT	1C07

PART NUMBER	DESCRIPTION	REF. NO.
ERC 8964	BOLT	1E08
ERC 8973	ADAPTOR	1C11
ERC 8975	SPECIAL BOLT	1C04
ERC 8975	SPRING-TIMING CHAIN TENSIONER	1E05
ERC 8976	SCREW-SPECIAL	1E04
ERC 8980	TUBE	1C07
ERC 8980	TUBE-DIPSTICK	1E07
ERC 8980	TUBE-DIPSTICK	1E08
ERC 9054	ADJUSTING SCREW	1C06
ERC 9054	SCREW-TAPPET ADJUSTING	1E06
ERC 9055	ROCKER	1E06
ERC 9056	ROCKER	1E06
ERC 9059	ROCKER	1E06
ERC 9060	ROCKER	1E06
ERC 9073	SIDE COVER ASSEMBLY	1C08
ERC 9073	BLANKING PLATE	1E09
ERC 9099	CYLINDER HEAD	1C11
ERC 9102	VALVE ROCKER LH EXHAUST	1C06
ERC 9103	VALVE ROCKER RH EXHAUST	1C06
ERC 9106	VALVE ROCKER LH INLET	1C06
ERC 9107	VALVE ROCKER RH INLET	1C06
ERC 9137	BRACKET	1E06
ERC 9138	ROCKER BRACKET	1C06
ERC 9178	WATER PUMP ASSEMBLY	1C10
ERC 9178	PUMP-WATER	1E09
ERC 9188	LINER-CYLINDER	1C02
ERC 9188	LINER CYLINDER	1E02
ERC 9200	WATER PUMP ASSEMBLY	1E10
ERC 9220	SPECIAL NUT	1C12
ERC 9220	DOME NUT	1E12
ERC 9240	STUD	1G03
ERC 9278	PLATE ROCKER SHAFT	1C06
ERC 9335	CONNECTING HOSE	1N03
ERC 9359	CYLINDER HEAD	1E11
ERC 9410	PLUG-DRAIN WATER	1C02
ERC 9410	PLUG	1E02
ERC 9432	ADAPTOR	1E11
ERC 9446	COVER ASSEMBLY	1C07
ERC 9446	FRONT COVER	1E08
ERC 9448	PLUG	1C11
ERC 9448	PLUG	1E11
ERC 9469	TUBE-E.G.R. VALVE	1C14
ERC 9543	CAMSHAFT	1C05
ERC 9615	LEADS-DISTRIBUTOR-HIGH TENSION	2E06
ERC 9727	COVER	1E09

PART NUMBER	DESCRIPTION	REF. NO.
ERC 9728	HOSE-BREATHER	1E12
ERC 9738	EXHAUST VALVE	1E06
ERC 9739	INLET VALVE	1E06
ERC 9787	STUD	1E08
ETC 4066	VALVE-EXHAUST	1C06
ETC 4067	VALVE-INLET	1C06
ETC 4068	VALVE-SPRING CAP	1C06
ETC 4068	RETAINER-VALVE COLLET	1E06
ETC 4069	SPLIT CONE	1C06
ETC 4069	VALVE COLLET	1E06
ETC 4115	SUCTION PIPE	1M04
ETC 4140	WASHER	1C05
ETC 4140	PLATE-RETAINING CAMSHAFT	1E05
ETC 4141	BOLT	1C05
ETC 4141	BOLT	1E05
ETC 4146	HOSE-BREATHER	1E12
ETC 4246	SPECIAL SET BOLT	1C06
ETC 4246	BOLT SPECIAL	1E06
ETC 4301	CYLINDER HEAD	1E11
ETC 4357	MOUNTING BRACKET	2E11
ETC 4357	BRACKET-ALTERNATOR	2E15
ETC 4460	SCREW	1C06
ETC 4460	BOLT-SPECIAL	1E06
ETC 4464	PUMP BODY	1C04
ETC 4464	BODY-OIL PUMP	1E04
ETC 4466	ADAPTOR	2E03
ETC 4498	BOLT-BANJO	1C11
ETC 4498	BOLT-BANJO	1E11
ETC 4499	TIMING CHAIN	1E05
ETC 4666	PISTON ASSY	1E03
ETC 4667	PISTON ASSY	1E03
ETC 4709	SEALING RING	1C11
ETC 4709	'O'RING-VALVE GUIDE	1E11
ETC 4749	PISTON ASSY	1E03
ETC 4751	SEAL ASSEMBLY	1C11
ETC 4751	'O'RING-VALVE GUIDE	1E11
ETC 4763	THERMOSTAT	1F07
ETC 4765	THERMOSTAT	1F07
ETC 4953	FILTER-ENGINE OIL	1F05
ETC 5057	TAPPET	1C06
ETC 5057	TAPPET	1E06
ETC 5155	CONNECTING ROD NUT	1C03
ETC 5155	BOLT-CONNECTING ROD	1E03
ETC 5156	CON ROD ASSY	1E03
ETC 5157	CONNECTING ROD ASSEMBLY	1C03

PART NUMBER	DESCRIPTION	REF.NO.
ETC 5178	FLYWHEEL HOUSING	1G03
ETC 5276	WASHER JOINT	1C12
ETC 5276	JOINT WASHER	1D13
ETC 5276	WASHER JOINT	1E12
ETC 5297	BREATHER-FILTER	1E12
ETC 5301	CYLINDER HEAD GASKET	1E11
ETC 5312	MANIFOLD GASKET	1E13
ETC 5369	OIL SEAL	1C03
ETC 5369	SEAL-OIL-REAR MAIN BEARING	1E03
ETC 5780	FLYWHEEL ASSEMBLY	1G03
ETC 5816	BRACKET ENGINE LIFTING	1C11
ETC 5816	BRACKET-ENGINE LIFTING	1E11
ETC 5927	FLYWHEEL HOUSING	1G02
ETC 5932	FLYWHEEL HOUSING	1G03
ETC 6137	THRUST WASHER	1C04
ETC 6138	LOCKNUT	1C04
ETC 6139	GEAR-DISTRIBUTOR DRIVE	1C04
ETC 6139	GEAR-DISTRIBUTOR DRIVE	1E04
ETC 9188	PISTON LINER	1C03
FAM 3162	BRAKE HOSE FRONT	1L09
FAM 3162	BRAKE HOSE	1L12
FAM 3658	L NUT	1L10
FAM 3658	L NUT	1L11
FAM 3658	L NUT	1L13
FAM 8881	L SWITCH	1014
FRC 167	PIPE-OIL-GEARBOX	1I05
FRC 168	PIPE-OIL-GEARBOX	1I05
FRC 1034	WASHER-REVERSE IDLER GEAR	1H05
FRC 1035	CIRCLIP-REVERSE IDLER GEAR	1H05
FRC 1185	GEAR-3RD SPEED	1I06
FRC 1193	SHIM	1J07
FRC 1195	SHIM	1J07
FRC 1197	SHIM	1J07
FRC 1199	SHIM	1J07
FRC 1201	SHIM	1J07
FRC 1203	SHIM	1J07
FRC 1336	BLOCK	1I06
FRC 1337	BLOCK	1I06
FRC 1339	PRIMARY PINION	1I06
FRC 1343	GEAR-2ND SPEED	1I06
FRC 1344	GEAR-1ST SPEED MAIN SHAFT	1I06
FRC 1387	O RING FOR GEAR LEVER	1H11
FRC 1511	JOINT WASHER-OIL SEAL RETAINER	1H10
FRC 1516	JOINT WASHER	1H09
FRC 1536	SPEEDOMETER PINION	1H08

PART NUMBER		DESCRIPTION	REF. NO.
FRC 1644		HALF SHAFT	1J13
FRC 1645		HALF SHAFT	1J13
FRC 1691		LAYSHAFT CLUSTER	1H05
FRC 1691		LAYSHAFT CLUSTER	1H06
FRC 1743		SHAFT-REVERSE GEAR	1I09
FRC 1758		SYNCRO CLUTCH	1H04
FRC 1778		CASING-GEARBOX	1I04
FRC 1780		SEAL	1H08
FRC 1780		SEAL-OIL	1H10
FRC 1810		REVERSE IDLER GEAR ASSEMBLY	1H05
FRC 1812		NEEDLE ROLLER BEARING	1H05
FRC 1813		REVERSE GEAR SHAFT	1H05
FRC 1815		REVERSE SELECTOR FORK	1H11
FRC 1893		REVERSE IDLER GEAR ASSEMBLY	1H06
FRC 1921		PROPELLER SHAFT	1J14
FRC 1930		BEARING-SWIVEL PIN	1J06
FRC 1931		HOUSING-SWIVEL PIN	1J05
FRC 1938		LEVER-RH STEERING-RHD	1J06
FRC 1939		LEVER-LH STEERING-RHD	1J06
FRC 1940		LEVER-RH STEERING-LHD	1J06
FRC 1941		LEVER-LH STEERING-LHD	1J06
FRC 1942		SWIVEL PIN UPPER	1J06
FRC 1956		HOUSING-RH-SWIVEL PIN	1J06
FRC 1957		HOUSING-LH-SWIVEL PIN	1J06
FRC 1962	N	GEARBOX ASSEMBLY-NEW	1I02
FRC 1962	R	GEARBOX ASSEMBLY-REBUILT	1I02
FRC 1977		SHIM	1J11
FRC 1978		SHIM	1J11
FRC 1979		SHIM	1J11
FRC 1980		SHIM	1J11
FRC 1981		SHIM	1J11
FRC 1982		SHIM	1J11
FRC 1983		SHIM	1J11
FRC 1984		SHIM	1J11
FRC 1985		SHIM	1J11
FRC 1986		SHIM	1J11
FRC 1987		SHIM	1J11
FRC 1988		SHIM	1J11
FRC 1989		SHIM	1J11
FRC 1990		SHIM	1J11
FRC 1996		SLEEVE-HUB BEARING	1J13
FRC 2000	R	GEARBOX ASSEMBLY REBUILT	1H02
FRC 2001	N	GEARBOX ASSEMBLY NEW	1H02
FRC 2001	R	GEARBOX ASSEMBLY REBUILT	1H02
FRC 2002	N	GEARBOX ASSEMBLY NEW	1H02

PART NUMBER	DESCRIPTION	REF.NO.
FRC 2003	N GEARBOX ASSEMBLY NEW	1H02
FRC 2007	THRUST WASHER-REVERSE IDLER GEAR	1H05
FRC 2008	SPACER-REVERSE IDLER SHAFT	1H05
FRC 2046	GEAR LEVER RH STG 4 CYLINDER	1H11
FRC 2047	GEAR LEVER LH STG 4 CYLINDER	1H11
FRC 2053	SELECTOR SHAFT	1H11
FRC 2055	BRACKET	1H11
FRC 2056	GEAR 1ST SPEED MAINSHAFT	1H04
FRC 2074	HOUSING ASSY-SWIVEL PIN RH	1J06
FRC 2075	HOUSING ASSY-SWIVEL PIN LH	1J06
FRC 2080	SWIVEL PIN & STG LEVER RH	1J06
FRC 2081	SWIVEL PIN & STG LEVER LH	1J06
FRC 2082	SWIVEL PIN & STG LEVER RH	1J06
FRC 2083	SWIVEL PIN & STG LEVER LH	1J06
FRC 2084	LAYSHAFT CLUSTER	1H05
FRC 2137	REAR AXLE ASSEMBLY	1J12
FRC 2175	PROPELLOR SHAFT ASSY	1J04
FRC 2186	SHAFT-FRONT OUTPUT	1I10
FRC 2216	HOUSING-DIFFERENTIAL	1J07
FRC 2240	GEAR-HIGH RANGE	1I09
FRC 2241	GEAR-HIGH RANGE	1I10
FRC 2256	FLANGE-OUTPUT SHAFT	1I10
FRC 2257	COVER-FRONT-GEARBOX	1I05
FRC 2258	BRACKET	1I10
FRC 2273	PIPE-VACUUM CONTROL	1I13
FRC 2274	PIPE-VACUUM CONTROL	1I13
FRC 2275	PIPE-VACUUM CONTROL	1I13
FRC 2283	SPEEDO WORM	1I11
FRC 2284	PINION-SPEEDOMETER DRIVE	1I11
FRC 2297	CLUTCH PLATE	1G02
FRC 2297	CLUTCH PLATE	1G03
FRC 2402	PLATE-CLUTCH CYLINDER	1G05
FRC 2469	LOCKER	1H11
FRC 2552	RETAINER-OIL SEAL-AXLE SHAFT	1J05
FRC 2673	2ND SPEED GEAR	1H04
FRC 2716	EXTENSION-GEAR CHANGE LEVER	1I12
FRC 2717	EXTENSION-GEAR CHANGE LEVER	1I12
FRC 2718	LEVER-GEAR CHANGE RH	1I12
FRC 2719	LEVER-GEAR CHANGE LH	1I12
FRC 2858	HOUSING-BELL	1I02
FRC 2859	COVER-BELL HOUSING	1I03
FRC 2863	SELECTOR	1I12
FRC 2872	GROMMET-RUBBER-TRANSMISSION	1L05
FRC 2928	BUSH-STUB AXLE	1J06
FRC 2930	HALFSHAFT-FRONT AXLE	1J05

PART NUMBER	DESCRIPTION	REF. NO.
FRC 2931	HALF SHAFT-FRONT AXLE	1J05
FRC 2933	DIFFERENTIAL CASE	1J08
FRC 2963	GEAR-INPUT	1I09
FRC 3099	SEAL-OIL-STUB AXLE	1J06
FRC 3100	STUB AXLE	1J06
FRC 3127	OIL CATCHER	1L03
FRC 3127	OIL CATCHER	1L04
FRC 3201	GEAR-1ST SPEED MAINSHAFT	1H04
FRC 3234	SPRING-BRAKE SHOE	1L05
FRC 3264	SHIM	1H09
FRC 3267	SHIM	1H09
FRC 3268	SHIM	1H09
FRC 3355	BAFFLE-TRANSFER BOX	1I05
FRC 3366	FRONT AXLE CASING	1J02
FRC 3366	FRONT AXLE CASE	1J03
FRC 3367	REAR AXLE CASING	1J12
FRC 3370	CASING-FRONT AXLE	1J02
FRC 3396	FRONT AXLE ASSEMBLY RH STG	1J02
FRC 3397	FRONT AXLE ASSEMBLY LH STG	1J02
FRC 3398	FRONT AXLE ASSEMBLY RH STG	1J03
FRC 3398	FRONT AXLE ASSEMBLY RH STG	1J03
FRC 3399	FRONT AXLE ASSEMBLY LH STG	1J03
FRC 3399	FRONT AXLE ASSEMBLY LH STG	1J03
FRC 3500	WASHER-THRUST	1I09
FRC 3507	SHAFT-INTERIM GEARS	1I09
FRC 3508	COVER-TOP	1I05
FRC 3517	BUSH-RR MAIN BEARING HOUSING	1I04
FRC 3517	HOUSING-ROLLER BEARING	1I06
FRC 3518	HOUSING REAR MAIN BEARING	1I04
FRC 3530	GEAR LEVER RH STG 6 CYLINDER	1H11
FRC 3531	GEAR LEVER LH STG 6 CYLINDER	1H11
FRC 3642	SHIM	1I09
FRC 3643	SHIM	1I09
FRC 3644	SHIM	1I09
FRC 3645	SHIM	1I09
FRC 3646	SHIM	1I09
FRC 3647	SHIM	1I09
FRC 3648	SHIM	1I09
FRC 3649	SHIM	1I09
FRC 3650	SHIM	1I09
FRC 3651	SHIM	1I09
FRC 3652	SHIM	1I09
FRC 3653	SHIM	1I09
FRC 3654	SHIM	1I09
FRC 3655	SHIM	1I09

PART NUMBER	DESCRIPTION	REF. NO.
FRC 3656	SHIM	1I09
FRC 3657	SHIM	1I09
FRC 3658	SHIM	1I09
FRC 3659	SHIM	1I09
FRC 3660	SHIM	1I09
FRC 3702	LOCKER	1H11
FRC 3776	GASKET-COVERPLATE	1H03
FRC 3875	HUB-FRONT	1J10
FRC 3875	FRONT HUB	1J11
FRC 3875	HUB REAR	1J13
FRC 3906	HALFSHAFT COMPLETE RH	1J05
FRC 3907	HALFSHAFT COMPLETE LH	1J05
FRC 3917	STUB AXLE	1J06
FRC 3924	STUB AXLE	1J13
FRC 3925	STUB AXLE	1J06
FRC 3942	LEVER-MAIN GEARBOX-RH STG	1I13
FRC 3943	LEVER-MAIN GEARBOX-LH STG	1I13
FRC 3947	HINGE	1H11
FRC 3991	HUB CAP	1J10
FRC 4007	COVER PLATE	1H03
FRC 4076	BUSH	1H04
FRC 4077	BUSH	1H04
FRC 4377	HUB CAP	1J11
FRC 4377	HUB CAP	1J13
FRC 4396	FRONT AXLE ASSEMBLY RH STG	1J02
FRC 4397	FRONT AXLE ASSEMBLY LH STG	1J02
FRC 4398	REAR AXLE ASSEMBLY	1J12
FRC 4406	AXLE-FRONT ASSEMBLY	1J02
FRC 4407	AXLE-FRONT ASSEMBLY	1J02
FRC 4408	AXLE-REAR ASSY	1J12
FRC 4572	SHAFT-SELECTOR	1I12
FRC 4586	OIL SEAL	1J07
FRC 4622	DIFFERENTIAL CASE	1J08
FRC 4808	JOINT WASHER	1I04
FRC 4809	SEALING WASHER	1H03
FRC 4809	JOINT WASHER	1H09
FRC 4810	JOINT WASHER	1I04
FRC 4810	JOINT WASHER	1I04
FRC 4835	WASHER-JOINT	1I04
FRC 4835	JOINT WASHER	1I05
FRC 4907	PROP SHAFT REAR 88	1J14
FRC 5091	KNOB-MAIN GEAR LEVER ASSY	1I13
FRC 5115	BEARING HOUSING	1H04
FRC 5116	OIL THROWER	1H04
FRC 5204	LOCKING RING	1J07

PART NUMBER	DESCRIPTION	REF. NO.
FRC 5318	SELECTOR FORK	1I12
FRC 5567	CASING ASSEMBLY	1H09
FRC 5597	SHAFT-SELECTOR	1I12
FRC 5598	SELECTOR	1I12
FRC 5600	SELECTOR FORK	1I12
FRC 5618	SHAFT-SELECTOR	1I12
FRC 5620	RETAINER-OIL SEAL-AXLE SHAFT	1J05
FRC 5629	COVER-TOP-GEARBOX	1I04
FRC 5648	SELECTOR	1I12
FRC 5661	LOCK TAB	1J07
FRC 5674	SHIM	1I10
FRC 5688	DIFFERENTIAL ASSEMBLY	1J07
FRC 5690	HOUSING-DIFFERENTIAL	1J07
FRC 5801	STUD	1I04
FRC 5882	SHAFT-GEAR SELECTOR	1I12
FRC 5897	SELECTOR SHAFT	1H11
FRC 5931	CONE-SYNCHROME	1I06
FRC 5931	CONE-SYNCHROME	1I06
FRC 6126	KNOB-TRANSFER GR LEVER ASSY	1I12
FRC 6284	THRUST WASHER	1I09
FRC 6285	THRUST WASHER	1I09
FRC 6286	THRUST WASHER	1I09
FRC 6287	THRUST WASHER	1I09
FRC 6288	THRUST WASHER	1I09
FRC 6461	WASHER PLAIN	1H08
FRC 6461	WASHER-PLAIN	1H10
FRC 6468	SEAL	1H11
FRC 6468	SEAL-OIL	1I12
FRC 6631	PLATE-CLUTCH	1G03
FRC 6738	PLATE	1H09
FRC 6938	WASHER	1H11
FRC 6956	THRUST WASHER	1I11
FRC 6958	THRUST WASHER	1I11
FRC 6960	THRUST WASHER	1I11
FRC 6962	THRUST WASHER	1I11
FRC 6964	THRUST WASHER	1I11
FRC 6968	THRUST WASHER	1I11
FRC 6996	SYNCHRO CLUTCH	1H04
FRC 6998	TRANSFER GEAR CHANGE LEVER	1H13
FRC 7007	JOINT WASHER	1H09
FRC 7013	HUB-DRIVING MEMBER	1J10
FRC 7013	HUB-DRIVING MEMBER	1J11
FRC 7013	HUB-DRIVING MEMBER	1J13
FRC 7104	GASKET-BOTTOM COVER TRANSFER CASING	1I04
FRC 7148	BOTTOM COVER	1H09

PART NUMBER	DESCRIPTION	REF.NO.
FRC 7298	AXLE-REAR ASSY	1J12
FRC 7740	DIFFERENTIAL ASSEMBLY	1I11
FRC 7745	OIL RETAINING RING	1I11
FRC 7778	DIFFERENTIAL ASSEMBLY	1J07
FRC 7871	BEARING-ROLLER	1I10
FRC 7967	GEARBOX CASING	1H03
FRC 8179	3RD SPEED GEAR	1H04
8G 8600	L CLUTCH SLAVE CYLINDER	1G05
8G 8600	L OVERHAUL KIT	2L07
8G 8837	L KIT-CLUTCH MASTER CYLINDER	1G04
8G 8837	L KIT-BRAKE MASTER CYLINDER	1L07
8G 8837	L KIT, BRAKE MASTER CYLINDER	1L07
8G 8837	L OVERHAUL KIT	2L07
8G 8845	L OVERHAUL KIT FOR FUEL PUMP	1N10
8G 8845	L OVERHAUL KIT FOR FUEL PUMP	2L07
18G 8246	L KIT FUEL PUMP OVERHAUL	1N06
18G 8246	L OVERHAUL KIT FOR FUEL PUMP	2L07
18G 8619	L DRIVE END BEARING KIT	2E10
18G 8619	L BEARING KIT-DRIVE END-	2E12
18G 8619	L BEARING KIT-ALTERNATOR-DRIVE END	2E14
18G 8619	L BEARING KIT-DRIVE END-	2E16
18G 8620	L BEARING KIT FOR SLIP RING END	2E10
18G 8620	L BEARING KIT-SLIP RING END-	2E12
18G 8620	L BEARING KIT-SLIP RING END-ALTERNATOR	2E14
18G 8620	L BEARING KIT-SLIP RING END-	2E16
18G 8951	L KIT-BRAKE SERVO OVERHAUL	1L07
18G 8951	L REPAIR KIT, SERVO	1L08
18G 8951	L BRAKE SERVO MINOR REPAIR KIT	2L13
18G 8953	L ADAPTOR-SERVO	1L07
22G 1941	BREATHER-COVER PLATE	1H03
24G 1345	L BARREL LOCK	2F09

PART NUMBER	DESCRIPTION	REF.NO.
1H 9077	L SWITCH-HEATER AND LAMPS	2F09
3H 822	L GROMMET	2H09
3H 822	L GROMMET	2H13
7H 5007	SPRING-BENDIX STARTER MOTOR	2E07
7H 5007	SPRING-BENDIX STARTER	2E08
12H 220	L JOINT WASHER	1N10
13H 1515	L BOLT-BANJO	1N10
13H 3735	L STOP LIGHT SWITCH	1L06
13H 5952	L SOLENOID-STARTER	2F12
13H 8702	L PIPE CLIP	2D04
13H 8953	L PIPE CLIP	1L11
13H 8953	L PIPE CLIP	1L13
13H 9205	L TRIP RESET CABLE	2F08
17H 2475	L KEY-IGNITION	2F09
17H 7971	L RETAINER-BRAKE SHOE SPRING	1L05
27H 1330	L GASKET-FUEL PUMP BOWL	1N06
27H 5932	L SPRING SET FOR STARTER MOTOR	2E09
27H 6481	L LAMP UNIT SEATING RIM	2F02
27H 7946	BLUE BRAKE GREASE-TUBE	2L07
27H 8207	L HEADLAMP COMPLETE	2F02
37H 575	L SEAL	1N10
37H 770	L O RING	1N10
37H 2736	L SHAFT AND GEAR FOR WIPER MOTOR	2F06
37H 3694	L NUT-SPECIAL WIPER CABLE	2F06
37H 4702	BUSH-STARTER MOTOR	2E09
37H 5452	L BULB HOLDER	2F04
37H 6109	L LENS FOR STOP TAIL LAMP	2F03
37H 6111	L LENS FOR FLASHER LAMP	2F04
37H 6134	L ADJUSTER UNIT ASSY	1L05
37H 7618	L SEALING RING KIT FOR STARTER MOTOR	2E09
37H 7841	L REGULATOR BOX-ALTERNATOR	2E10
37H 7841	L REGULATOR BOX-ALTERNATOR	2E12
37H 7841	L REGULATOR BOX-ALTERNATOR	2E14
37H 7920	DRAIN PLUG	1N10
37H 8119	L SPECIAL BOLT	1N10
37H 8531	L BRKT FOR STARTER COMMUTATOR END	2E09

PART NUMBER	DESCRIPTION	REF. NO.
HN 2005	L NUT	1F10
HN 2005	L NUT	1L07
HN 2005	L NUT	1L11
HN 2005	L NUT	1L13
HN 2005	L NUT	1M12
HN 2005	L NUT	1N13
HN 2005	L NUT	1N13
HN 2005	L NUT	1N17
HN 2005	L NUT	1O10
HN 2005	L NUT	1O12
HN 2005	L NUT	1O14
HN 2005	L NUT	2C09
HN 2005	L NUT	2D02
HN 2005	L NUT	2D04
HN 2005	L NUT	2F02
HN 2005	L NUT	2F04
HN 2005	L NUT	2F12
HN 2005	L NUT	2F13
HN 2005	L NUT	2F14
HN 2005	L NUT	2F15
HN 2005	L NUT	2G09
HN 2005	L NUT	2H06
HN 2005	L NUT	2H14
HN 2005	L NUT	2I03
HN 2005	L NUT	2J02
HN 2005	L NUT	2J03
HN 2005	L NUT	2J05
HN 2005	L NUT	2J06
HN 2005	L NUT	2L12
HN 2005	L NUT	2L13
HN 2005	L NUT	2L15
HZA 5413	L LOCK ASSY	2K05
HZA 5413	L LOCK ASSEMBLY	2L05
JS 370	L COVER FOR STARTER COMMUTATOR END	2E09
JS 487	L DRIVE END BRACKET-ALTERNATOR	2E10
JS 487	L BRACKET-DRIVE END-ALTERNATOR	2E12
JS 487	L BRKT-DRIVE END-ALTERNATOR	2E14
JS 495	L SUNDRY PARTS KIT-ALTERNATOR	2E10
JS 495	L BEARING KIT-ALTERNATOR	2E12
JS 495	L KIT-SUNDRY PARTS-ALTERNATOR	2E14
JS 495	L KIT-SUNDRY PARTS-ALTERNATOR	2E16
JS 499	L DIAPHRAGM FOR CARBURETTER	1M05
JS 499	L DIAPHRAGM-AIR VALVE	1M10
JS 499	L DIAPHRAGM	2L17
JS 657	L CENTRE SEAL UPPER	1N09

PART NUMBER	DESCRIPTION	REF. NO.
JS 660	L ELEMENT & SEAL FOR FILTER	1N09
53K 2852	L WING NUT	1N05
MR 106300	CAPTIVE NUT	2H12
MRC 305	FRONT PLATE UPPER CRASH	2G09
MRC 306	FRONT PLATE UPPER CRASH	2G09
MRC 1149	BACKING PLATE	2G09
MRC 1151	SEAL RH STG	2G09
MRC 1152	SEAL LH STG	2G09
MRC 1201	STRAP FOR CENTRE SEAT	2K02
MRC 1210	U BOLT FOR SPARE WHEEL CARRIER	2H16
MRC 1210	'U' BOLT	2I02
MRC 1232	WAIST MOULDING REAR SIDE	2G17
MRC 1233	WAIST MOULDING REAR SIDE	2G17
MRC 1300	PLUG	2G09
MRC 1300	PLUG-PLASTIC	2L09
MRC 1765	INTERIOR SUN VISOR	2J05
MRC 1978	NYLON WASHER	2J02
MRC 1979	NYLON WASHER	2I03
MRC 1980	NYLON WASHER	2G16
MRC 1980	WASHER-DOOR HINGES	2G18
MRC 1980	WASHER-DOOR HINGES	2H16
MRC 1980	WASHER	2I02
MRC 2164	PROTECTIVE COVER-GRAB RAIL	2K03
MRC 2178	CAPTIVE NUT	2G16
MRC 2237	BRACKET & ANTILUCE COTTER ASSY- ϕ RH	2H03
MRC 2237	BRACKET RH-TAILBOARD RETAINER	2H06
MRC 2238	BRACKET & ANTILUCE COTTER ASSY- ϕ LH	2H03
MRC 2238	BRACKET LH-TAILBOARD RETAINER	2H06
MRC 2244	COVER PANEL RH REAR LAMPS	2H02
MRC 2244	PANEL RH-REAR LAMP COVER	2H05
MRC 2244	PANEL ϕ RH-STOPTAIL LAMP COVER-	2H07
MRC 2245	COVER PANEL LH REAR LAMPS	2H02
MRC 2245	PANEL LH-REAR LAMP COVER	2H05
MRC 2245	PANEL ϕ RH-STOPTAIL LAMP COVER-	2H07
MRC 2363	SEAL RETAINER RH	2H17
MRC 2364	SEAL RETAINER LH	2H17
MRC 2381	SEAL RETAINER RH	2G17
MRC 2382	SEAL RETAINER LH	2G17
MRC 2416	WINDSCREEN CLAMP ASSEMBLY	2G10
MRC 2440	BONNET COMPLETE	2G06
MRC 2479	BONNET COMPLETE	2G06
MRC 2481	BOLT PLATE	2G13
MRC 2595	FRT WING TOP/VALANCE ASSY-LH	2G07
MRC 2660	DRIVE SCREW	2G15
MRC 2660	SCREW	2G18

PART NUMBER	DESCRIPTION	REF.NO.
MRC 2660	DRIVE SCREW	2H18
MRC 2744	FRT WING TOP/VALANCE ASSY-LH	2G07
MRC 2762	SCREW	2G16
MRC 2762	SCREW	2G18
MRC 2797	SIDE STIFFENER WHEELARCH BOX	2L15
MRC 2868	STEERING COLUMN SHROUD SEAL	1014
MRC 3037	DOOR HINGE UPPER RH	2I03
MRC 3038	DOOR HINGE UPPER LH	2I03
MRC 3045	SCREW 0.250 UNF X 0.500 ϕ LONG	2F07
MRC 3047	SCREW	2J02
MRC 3051	WASHER-PLAIN	2J02
MRC 3052	WASHER-PLAIN	2G09
MRC 3053	DRIVE SCREW	2J02
MRC 3054	DRIVE SCREW	2J02
MRC 3055	WASHER-PLAIN	2J02
MRC 3056	DRIVE SCREW	2G09
MRC 3056	DRIVE SCREW	2G12
MRC 3058	WASHER	2F07
MRC 3084	RUBBER-WING VALANCE-ANTI NOISE	2I04
MRC 3085	RUBBER-WING VALANCE-ANTI NOISE	2I04
MRC 3093	CORNER PROTECTOR	2H17
MRC 3117	FRONT SUPPORT LINK SQUAB	2K02
MRC 3117	FRONT SUPPORT LINK SQUAB	2K03
MRC 3179	CENTRE SEAT	2K02
MRC 3293	REAR LOWER VALANCE ASSY-LH	2G07
MRC 3556	PANEL-RADIATOR GRILLE	2G05
MRC 3574	PLATE-FRONT FLOOR RH	2G11
MRC 3575	PLATE-FRONT FLOOR LH	2G11
MRC 3592	FRONT MAT-RH	2J08
MRC 3593	FRONT MAT-LH	2J08
MRC 3598	MOTIF-FRONT GRILLE PANEL	2G05
MRC 3598	NAME PLATE LAND-ROVER	2H13
MRC 3609	SEAL-TUNNEL FRONT	2G11
MRC 3610	SEAL-TUNNEL REAR	2G11
MRC 3611	SEAL-TUNNEL SIDE	2G11
MRC 3613	SEAL-TRANSFER LEVER	2G11
MRC 3873	CRASH PADDING-UPPER DASH	2J02
MRC 4034	SEAT SQUAB	2J09
MRC 4037	SHIM-WING TO VALANCE	2G08
MRC 4135	BRIDGE PLATE	2G10
MRC 4165	SIDE PANEL-WARNING LIGHT	2L12
MRC 4237	STRIP-CLAMPING GRILLE PANEL	2G05
MRC 4238	STRIP-BONNET REST	2G05
MRC 4266	BRACKET-FIXING GRILLE MESH	2G05
MRC 4367	PAINT REMOVING SCREW	2G08

PART NUMBER	DESCRIPTION	REF. NO.
MRC 4411	FRONT PANEL	2G07
MRC 4412	FRONT PANEL	2G07
MRC 4426	AUXILIARY PANEL	2F13
MRC 4427	AUXILIARY PANEL	2F13
MRC 4447	COVER DASH CENTRE	2J04
MRC 4462	CLAMP-BATTERY	2G04
MRC 4516	AUXILIARY PANEL	2F13
MRC 4516	INNER SIDE PANEL	2L12
MRC 4517	AUXILIARY PANEL	2F13
MRC 4570	COVER-STEERING RELAY	2G08
MRC 4571	PLATE-WING VALANCE PANEL	2G08
MRC 4583	MIRROR ARM	2I03
MRC 4612	SIDE PANEL ASSY RH	2H15
MRC 4613	SIDE PANEL ASSY LH	2H15
MRC 4753	RETAINER RH-DOOR CHECK STRAP	2G18
MRC 4754	RETAINER LH-DOOR CHECK STRAP	2G18
MRC 4798	BOLT-SHOULDER	2K05
MRC 4846	STRENGTHENING PLATE	2H05
MRC 4857	SEAL-MAIN GEAR LEVER	2G11
MRC 4858	PLAIN WASHER 0.250/9 X 20 SWG	2F07
MRC 4859	DRIVE SCREW	2J03
MRC 4860	WASHER-PLAIN	2J02
MRC 4863	DRIVE SCREW	2J02
MRC 5016	STOP-BONNET BUFFER	2G06
MRC 5016	BUFFER	2J14
MRC 5243	CENTRE LOCKER LID	2G12
MRC 5244	CENTRE LOCKER LID	2G12
MRC 5355	TUNNEL-GEARBOX	2G11
MRC 5356	COVER-TRANSFER CASE TUNNEL	2G11
MRC 5357	GEARBOX DIAPHRAGM PANEL	2G11
MRC 5504	BRACKET	2G08
MRC 5505	BRACKET	2G08
MRC 5509	BOLT PLATE	2J09
MRC 5509	STUD PLATE	2J10
MRC 5509	STUD PLATE	2J11
MRC 5511	NUT PLATE	2G08
MRC 5513	HORN PROTECTOR PLATE	2G05
MRC 5515	CLIP	1K03
MRC 5517	NUT PLATE	2F06
MRC 5519	FIXING PLATE	2G07
MRC 5520	FIXING PLATE	2G07
MRC 5524	WASHER-PLAIN	2H15
MRC 5525	WASHER PLAIN	2C11
MRC 5525	WASHER-PLAIN	2D02
MRC 5525	PLAIN WASHER	2G06

PART NUMBER	DESCRIPTION	REF. NO.
MRC 5525	WASHER-PLAIN	2G08
MRC 5525	WASHER PLAIN	2G12
MRC 5525	WASHER-PLAIN	2G13
MRC 5525	WASHER PLAIN	2G15
MRC 5525	WASHER PLAIN	2H02
MRC 5525	WASHER-PLAIN	2H03
MRC 5525	WASHER PLAIN	2H06
MRC 5525	WASHER-PLAIN	2H08
MRC 5525	WASHER PLAIN	2H14
MRC 5525	WASHER PLAIN	2H15
MRC 5525	WASHER-PLAIN	2H17
MRC 5525	WASHER PLAIN	2I02
MRC 5525	WASHER PLAIN	2J09
MRC 5525	WASHER PLAIN	2J10
MRC 5525	WASHER PLAIN	2J11
MRC 5525	WASHER-PLAIN	2J13
MRC 5525	WASHER-PLAIN	2J14
MRC 5526	WASHER PLAIN	2G10
MRC 5526	WASHER-PLAIN	2H05
MRC 5526	WASHER-PLAIN	2H07
MRC 5526	WASHER PLAIN	2J10
MRC 5526	WASHER PLAIN	2J11
MRC 5526	WASHER PLAIN	2J13
MRC 5527	WASHER-PLAIN	2F09
MRC 5527	WASHER-PLAIN	2G05
MRC 5527	WASHER PLAIN	2G10
MRC 5527	PLAIN-WASHER	2G10
MRC 5527	WASHER PLAIN	2H02
MRC 5527	WASHER PLAIN	2H15
MRC 5528	WASHER PLAIN	2G13
MRC 5528	WASHER PLAIN	2H13
MRC 5528	WASHER-PLAIN	2I15
MRC 5528	WASHER PLAIN	2J16
MRC 5528	WASHER-PLAIN	2K07
MRC 5529	WASHER-PLAIN	2G07
MRC 5529	WASHER-PLAIN	2G08
MRC 5529	WASHER PLAIN	2I04
MRC 5568	CLIP	2F08
MRC 5568	BRACKET-RETAINER-UPPER	2G09
MRC 5589	BONNET LOCK	2G05
MRC 5640	RUBBER-BONNET SIDE-ANTI NOISE	2I04
MRC 5695	WASHER PLAIN	1K04
MRC 5695	WASHER PLAIN	2H02
MRC 5695	WASHER-PLAIN	2L14
MRC 5695	WASHER-PLAIN	2L16

PART NUMBER		DESCRIPTION	REF. NO.
MRC	5695	PLAIN WASHER MOUNTING	2L18
MRC	5695	L WASHER-PLAIN	2L15
MRC	5698	GAITER HAND BRAKE	1L16
MRC	5740	SEAL FOR DOOR	2G13
MRC	5741	SEAL FOR DOOR	2G13
MRC	5932	BONNET ASSEMBLY	2G06
MRC	6001	FRONT WING TOP & VALANCE-LH	2G07
MRC	6006	STIFFENER-FRT WING VALANCE-RH	2G08
MRC	6007	STIFFENER-FRT WING VALANCE-LH	2G08
MRC	6074	BOLT	2G10
MRC	6080	DASH COMP ASSY 4CYL & 109V8	2G09
MRC	6080	DASH ASSY	2G10
MRC	6081	PANEL FRONT WING RH-RHD	2G08
MRC	6082	PANEL FRONT WING LH-RHD	2G08
MRC	6083	PANEL FRONT WING RH-LHD	2G08
MRC	6084	PANEL FRONT WING LH-LHD	2G08
MRC	6262	KEY BLANK	2G05
MRC	6270	BUFFER-BONNET	2G06
MRC	6270	RUBBER BUFFER	2G09
MRC	6493	GLASS	2H16
MRC	6499	SIDE LIGHT	2H17
MRC	6511	GLASS-FIXED-SIDE SCREEN	2G14
MRC	6512	GLASS-SLINDING-SIDE SCREEN	2G14
MRC	6530	WINDSCREEN GLASS LAMINATED	2G10
MRC	6532	STRIKER PIN	2G06
MRC	6620	GRILLE-RADIATOR	2G05
MRC	6908	PLATE CARB VENT PIPES	2G08
MRC	6963	CHANNEL-CROSS BRACES	2G05
MRC	6969	LID-LOCKER-SIDE RH	2G12
MRC	6977	CATCH-BONNET	2G06
MRC	6978	WASHER PLATE-BONNET CATCH	2G06
MRC	6980	CUSHION	2J13
MRC	6982	SQUAB	2J13
MRC	6985	SEAT CUSHION	2J13
MRC	6987	SEAT SQUAB	2J13
MRC	7000	FRONT WING TOP & VALANCE-RH	2G07
MRC	7044	COVER-GEARBOX TUNNEL	2G11
MRC	7044	COVER GEARBOX TUNNEL	2I04
MRC	7044	COVER GEARBOX TUNNEL	2J04
MRC	7116	BONNET PROP COMPLETE	2G06
MRC	7173	SEAT BASE ASSEMBLY	2G12
MRC	7174	SEAT BASE	2G12
MRC	7175	BASE-BATTERY	2G04
MRC	7175	BATTERY BASE	2G12
MRC	7217	DOOR-RH-REAR SIDE	2G17

PART NUMBER	DESCRIPTION	REF. NO.
MRC 7218	DOOR-LH-REAR SIDE	2G17
MRC 7233	GLASS	2H16
MRC 7234	GLASS-REAR DOOR STATION WAGON	2H18
MRC 7255	ROOF ASSEMBLY	2H17
MRC 7343	CUSHION	2J12
MRC 7353	FRONT SEAT SQUAB	2J13
MRC 7365	COVER-SPARE WHEEL 109"	2H16
MRC 7365	COVER SPARE WHEEL	2I02
MRC 7375	'J' BOLT	2G04
MRC 7376	ROOF ASSEMBLY	2H17
MRC 7425	BADGE"LAND ROVER V8"BODYSIDE	2H04
MRC 7425	BADGE'LAND ROVER V8'BODYSIDE	2H07
MRC 7493	CROSS BRACE-RH	2G05
MRC 7494	CROSS BRACE-LH	2G05
MRC 7495	FRONT WING STIFFENER-NOSE	2G08
MRC 7496	FRONT WING STIFFENER-NOSE	2G08
MRC 7537	BADGE-"V8" REAR END PANEL	2H06
MRC 7537	BADGE 'V8'REAR END PANEL	2H07
MRC 7542	BODYSIDE COMPLETE RH	2H04
MRC 7543	BODYSIDE COMPLETE LH	2H04
MRC 7547	REAR END PANEL LH	2H02
MRC 7547	REAR END PANEL LH	2H04
MRC 7547	REAR END PANEL LH	2H07
MRC 8094	PANEL PROTECTION SHIELD	2H06
MRC 8094	PANEL PROTECTION SHIELD	2H08
MRC 8100	BODYSIDE COMPLETE RH	2H02
MRC 8101	BODYSIDE COMPLETE LH	2H02
MRC 8130	BODYSIDE COMPLETE RH	2H07
MRC 8131	BODYSIDE COMPLETE LH	2H07
MRC 8135	LOCATING ANGLE	2G12
MRC 8172	LABEL	2F09
MRC 8276	MIRROR HEAD	2I03
MRC 8316	HEADLAMP BEZEL	2G07
MRC 8317	HEADLAMP BEZEL	2G07
MRC 8356	RUBBER-BONNET-ANTI NOISE	2I04
MRC 8388	OVER CENTRE CATCH	2G12
MRC 8524	MOUNTING BRACKET	2J16
MRC 8570	BRACKET	2I04
MRC 8666	PAD-BATTERY TRAY	2G04
MRC 8960	PANEL-RADIATOR GRILLE	2G05
MRC 9191	BONNET PROP	2G06
MRC 9244	BONNET HINGE	2G06
MRC 9397	RUBBER SEAL	2G17
MRC 9417	NUT RETAINER	2G15
MRC 9417	RETAINER-REAR DOOR LOCK	2H18

PART NUMBER	DESCRIPTION	REF.NO.
MRC 9451	CENTRE LOCKER LID	2G12
MRC 9477	SEAL	2G12
MRC 9481	FRONT SEAT SLIDE	2J10
MRC 9481	FRONT SEAT SLIDE	2J11
MRC 9481	FRONT SEAT SLIDE	2J13
MRC 9492	FRONT SEAT SLIDE	2J10
MRC 9492	FRONT SEAT SLIDE	2J11
MRC 9492	FRONT SEAT SLIDE	2J13
MRC 9493	FRONT SEAT SLIDE	2J10
MRC 9493	FRONT SEAT SLIDE	2J11
MRC 9493	FRONT SEAT SLIDE	2J13
MRC 9562	WINDSCREEN-COMplete	2G10
MRC 9586	GRILLE TOP PANEL	2G05
MRC 9678	DASH COMPLETE ASSY 6 CYL	2G09
MRC 9914	COVER PLATE	2H07
MRC 9915	COVER PLATE	2H07
MRC 9995	BONNET STRIKER	2G06
MTC 1002	CENTRE SEAT SQUAB	2K02
MTC 1003	CENTRE SEAT CUSHION	2K03
MTC 1039	MOUNTING ANGLE	2H04
MTC 1039	MOUNTING ANGLE-REAR BODY	2H07
MTC 1074	REAR FLOOR	2H07
MTC 1409	BULKHEAD PANEL	2H09
MTC 1416	CAPPING	2H12
MTC 1423	BRACKET ASSEMBLY	2H12
MTC 1439	HOOK LASHING	2H11
MTC 1439	LASHING HOOK	2H13
MTC 1448	GASKET-MOUNTING PLATE	2H11
MTC 1449	LADDER RACK	2H14
MTC 1454	WHEEL GUARD RH	2H14
MTC 1455	WHEEL GUARD LH	2H14
MTC 1461	COVER PANEL	2H12
MTC 1462	GASKET	2H12
MTC 1479	REAR CENTRE PILLAR	2H11
MTC 1481	REAR LOWER PILLAR RH	2H11
MTC 1482	REAR LOWER PILLAR LH	2H11
MTC 1485	SPACER	2H12
MTC 1490	RUBBING STRIP	2H12
MTC 1508	PANEL VALANCE FRONT	2H11
MTC 1509	PANEL VALANCE FRONT	2H11
MTC 1512	REINF FRONT VALANCE	2H11
MTC 1516	BRACKET	2H14
MTC 1531	BUFFER STOP	2H13
MTC 1579	TAP PLATE	2H09
MTC 1584	SPARE WHEEL MTG ASSY	2H12

PART NUMBER	DESCRIPTION	REF. NO.
MTC 1592	PLATE	2H12
MTC 1594	PLUG	2H10
MTC 1594	PLUG	2H11
MTC 1595	PAD BODY MTG	2H09
MTC 1606	SEAT BELT ASSY	2J16
MTC 1607	SEAT BELT ASSY	2J16
MTC 1610	SEAT BELT (AUDIBLE WARNING) RH	2I15
MTC 1614	SAFETY HARNESS RH	2I15
MTC 1615	SAFETY HARNESS LH	2I15
MTC 1827	CHAIN	2H03
MTC 1827	CHAIN-TAILBOARD	2H06
MTC 1902	STIFFENER-FRT WING VALANCE-LH	2G08
MTC 1903	STIFFENER-FRT WING VALANCE-RH	2G08
MTC 1904	FRONT PANEL-RH	2G07
MTC 1905	FRONT PANEL-LH	2G07
MTC 1908	FRONT WING TOP & VALANCE-RH	2G07
MTC 1909	FRONT WING TOP & VALANCE-LH	2G07
MTC 1918	CUSHION ASSY-BLACK AMBLA	2J14
MTC 1919	HEAD RESTRAINT-BLACK AMBLA	2J14
MTC 1920	SQUAB ASSY-BLACK AMBLA	2J14
MTC 1921	SQUAB ASSY-BLACK AMBLA	2J14
MTC 1922	CUSHION COVER-BLACK AMBLA	2J14
MTC 1923	SQUAB COVER-BLACK/AMBLA	2J14
MTC 1928 RD	CUSHION ASSY-BRUSHWOOD/BERBER	2J14
MTC 1928 RE	CUSHION ASSY-GREY/BLACK	2J14
MTC 1929 RD	HEAD RESTRAINT-BRUSHWOOD/BERBER	2J14
MTC 1929 RE	HEAD RESTRAINT-GREY/BLACK	2J14
MTC 1930 RD	SQUAB ASSY-BRUSHWOOD/BERBER	2J14
MTC 1930 RE	SQUAB ASSY-GREY/BLACK	2J14
MTC 1931 RD	SQUAB ASSY-BRUSHWOOD/BERBER	2J14
MTC 1931 RE	SQUAB ASSY-GREY/BLACK	2J14
MTC 1932 RD	CUSHION COVER-BRUSHWOOD/BERBER	2J14
MTC 1932 RE	CUSHION COVER-GREY/BLACK	2J14
MTC 1933 RD	SQUAB COVER-BRUSHWOOD/BERBER	2J14
MTC 1933 RE	SQUAB COVER-GREY/BLACK	2J14
MTC 1938	SUB FRAME C/W SLIDES	2J14
MTC 1940 AV	BACK PANEL-BRUSHWOOD	2J14
MTC 1940 PB	BACK PANEL-BLACK	2J14
MTC 1941	CUSHION ASSY-BLACK AMBLA	2J14
MTC 1942	SQUAB ASSY-BLACK AMBLA	2J14
MTC 1943	CUSHION COVER-BLACK AMBLA	2J14
MTC 1944	SQUAB COVER-BLACK AMBLA	2J14
MTC 1947 RD	CUSHION ASSY-BRUSHWOOD/BERBER	2J14
MTC 1947 RE	CUSHION ASSY-GREY/BLACK	2J14
MTC 1948 RD	SQUAB ASSY-BRUSHWOOD/BERBER	2J14

PART NUMBER		DESCRIPTION	REF. NO.
MTC	1948	RE SQUAB ASSY-GREY/BLACK	2J14
MTC	1949	RD CUSHION COVER-BRUSHWOOD/BERBER	2J14
MTC	1949	RE CUSHION COVER-GREY/BLACK	2J14
MTC	1950	RD SQUAB COVER-BRUSHWOOD/BERBER	2J14
MTC	1950	RE SQUAB COVER-GREY/BLACK	2J14
MTC	1953	AV BACK PANEL-BRUSHWOOD	2J14
MTC	1953	PB BACK PANEL-BLACK	2J14
MTC	2134	PROTECTION ANGLE RH	2H03
MTC	2134	PROTECTION ANGLE RH	2H06
MTC	2134	PROTECTION ANGLE RH	2H08
MTC	2135	PROTECTION ANGLE LH	2H03
MTC	2135	PROTECTION ANGLE LH	2H06
MTC	2135	PROTECTION ANGLE LH	2H08
MTC	2238	REAR END PANEL RH	2H02
MTC	2238	REAR END PANEL RH	2H04
MTC	2238	REAR END PANEL RH	2H07
MTC	2568	HOOD STICK	2L04
MTC	2569	HOOD STICK	2L04
MTC	2574	AE HOOD ASSY-PLAIN SIDES	2L04
MTC	2574	AG HOOD ASSY-PLAIN SIDES	2L04
MTC	2575	AE HOOD ASSY-SIDE WINDOWS	2L04
MTC	2575	AG HOOD ASSY-SIDE WINDOWS	2L04
MTC	2657	CONSOLE UNIT	2K05
MTC	2657	CONSOLE UNIT	2L05
MTC	3118	SEAL-WINDOW CATCH	2G15
MTC	3118	SEAL-WINDOW CATCH	2G17
MTC	3126	BRACKET	2H10
MTC	3127	BRACKET	2H10
MTC	3140	EXTENTION BRACKET RH	2H14
MTC	3141	EXTENTION BRACKET LH	2H14
MTC	3165	COVER TOOLS	2L05
MTC	3166	PLATE RETAINING COVER	2L05
MTC	3180	FILLER (LOWER)	2G14
MTC	3181	FRONT SEAT SQUAB	2J13
MTC	3182	FRONT SEAT SQUAB	2J13
MTC	3183	SEAT SQUAB	2J09
MTC	3333	ASSY REINF PLATE CAB	2H11
MTC	3336	MAT FLOOR	2J05
MTC	3337	MAT FLOOR	2J05
MTC	3338	INSULATION	2J05
MTC	3350	PLATE-MOUNTING	2H11
MTC	3469	GLASS REAR DOOR	2H18
MTC	3474	ROOF SIDE LIGHT-SUNDYM	2H17
MTC	3476	GLASS	2H16
MTC	3481	BRACKET FRONT MTG.	2H10

PART NUMBER	DESCRIPTION	REF.NO.
MTC 3482	BRACKET FRONT MTG.	2H10
MTC 3486	BRACKET ANCHOR FRONT	2H10
MTC 3508	MUDSHIELD	2H03
MTC 3508	MUDSHIELD	2H06
MTC 3508	MUDSHIELD	2H08
MTC 3509	FIXING CHANNEL	2H03
MTC 3509	FIXING CHANNEL	2H06
MTC 3509	CHANNEL	2H08
MTC 3515	PLATE-MOUNTING	2H11
MTC 3521	REAR CROSSMEMBER	2H09
MTC 3527	PANEL VALANCE REAR	2H11
MTC 3528	PANEL VALANCE REAR	2H11
MTC 3533	PANEL-INNER BODYSIDE-RH	2H11
MTC 3534	PANEL-INNER BODYSIDE-LH	2H11
MTC 3539	FLOOR PANEL	2H09
MTC 3556	HINGE-TAILGATE	2H13
MTC 3557	TEE BOLT	2H13
MTC 3558	TEE BOLT	2H09
MTC 3569	FUEL FILLER COWL ASSEMBLY	2H12
MTC 3763	FRONT PORTION ROOF TRIM	2J06
MTC 3763	FRONT PORTION ROOF TRIM	2J07
MTC 3764	REAR HEAD LINING	2J07
MTC 3765	HEADCLOTH	2J07
MTC 3904	REAR BODY COMPLETE ASSY	2H09
MTC 3906	BODYSIDE	2H11
MTC 3907	BODYSIDE	2H11
MTC 3908	TAILGATE	2H13
MTC 3917	LATCH ASSEMBLY	2H13
MTC 3923	SEAL-TAILGATE	2H13
MTC 4002	BRACKET	2H09
MTC 4003	BRACKET	2H09
MTC 4039	TAP PLATE	2H09
MTC 4043	CROSSMEMBER	2H09
MTC 4054	RETAINING BAR	2L04
MTC 4056	HOOD STICK	2L04
MTC 4090	MOUNTING BRACKET	2J16
MTC 4111	DOOR SEAL	2H18
MTC 4112	DOOR SEAL RH	2G13
MTC 4113	DOOR SEAL LH	2G13
MTC 4114	DOOR SEAL RH	2G17
MTC 4115	DOOR SEAL LH	2G17
MTC 4117	WHEEL GUARD LH	2H14
MTC 4126	CANOPY TRIM PANEL	2J06
MTC 4126	CANOPY TRIM PANEL	2J07
MTC 4132	PAD ROOF LAMP	2J06

PART NUMBER		DESCRIPTION	REF.NO.
MTC	4132	PAD ROOF LAMP	2J07
MTC	4134	REAR HEAD LINING	2J06
MTC	4156	REINFORCING ANGLE	2H09
MTC	4164	SEAL RUBBER TAILBOARD RH	2H06
MTC	4165	SEAL RUBBER TAILBOARD LH	2H06
MTC	4187	PLATE	2K09
MTC	4188	CABLE TAILGATE RETAINING	2H13
MTC	4195	STRIKING PLATE	2G15
MTC	4195	STRIKER PLATE	2G18
MTC	4197	MOUNTING PLATE	2K05
MTC	4197	CENTRE LOCKER COVER	2L05
MTC	4290	RETAINER	2H18
MTC	4320	LABEL-'DIESEL FUEL'	2H12
MTC	4327	END PANEL	2H02
MTC	4327	PANEL RH-REAR BODY	2H04
MTC	4327	PANEL-REAR	2H07
MTC	4328	END PANEL	2H02
MTC	4328	PANEL LH-REAR BODY	2H04
MTC	4328	PANEL LH-REAR BODY	2H07
MTC	4387	PANEL	2K09
MTC	4391	INSULATION	2J05
MTC	4392	INSULATION	2J05
MTC	4460	BADGE 'LAND ROVER'	2H03
MTC	4460	BADGE 'LAND ROVER'	2H06
MTC	4460	BADGE 'LAND ROVER'	2H07
MTC	4460	LOGO	2H13
MTC	4472	BRACKET	2K09
MTC	4480	INSULATION	2J05
MTC	4483	RD CUSHION-CENTRE FRONT SEAT	2K05
MTC	4483	RD SEAT CUSHION ASSY	2K06
MTC	4483	RE CUSHION CENTRE FRONT SEAT	2K05
MTC	4483	RE SEAT CUSHION ASSEMBLY	2K06
MTC	4484	RD SEAT BACKREST	2K06
MTC	4484	RE SEAT BACKREST	2K06
MTC	4485	RD CENTRE SEAT CUSHION	2K04
MTC	4485	RE CENTRE SEAT CUSHION	2K04
MTC	4486	RD SQUAB-CENTRE SEAT	2K03
MTC	4486	RE SQUAB CENTRE SEAT	2K03
MTC	4487	RD REAR SEAT CUSHION	2K07
MTC	4487	RE REAR SEAT CUSHION	2K07
MTC	4488	RD REAR SEAT SQUAB	2K07
MTC	4488	RE REAR SEAT SQUAB	2K07
MTC	4489	RD SQUAB ASSY-CENTRE FRONT SEAT	2K05
MTC	4489	RE SQUAB ASSY CENTRE F/SEAT	2K05
MTC	4490	RD REAR SEAT SQUAB	2K08

PART NUMBER	DESCRIPTION	REF.NO.
MTC 4490 RE	REAR SEAT SQUAB	2K08
MTC 4491 RD	REAR SEAT BACKREST ASSY	2K08
MTC 4491 RE	REAR SEAT BACKREST ASSEMBLY	2K08
MTC 4496	ROOF TRIM	2J06
MTC 4497	ROOF TRIM	2J07
MTC 4520	TRAY	2K05
MTC 4520	TRAY FOR CONSOLE UNIT	2L05
MTC 4525	NUT PLATE	2J14
MTC 4601	WASHER PLATE	2K05
MTC 4601	WASHER PLATE	2L05
MTC 4655	PAD-BONNET INSULATION	2I04
MTC 4657	BRACKET-BONNET INSULATION	2I04
MTC 4719	BADGE COUNTY	2K09
MTC 4720	TAPE	2K09
MTC 4824	BRACKET TAILGATE WIRE	2H13
MTC 4828	SEAL-CLAMPING STRIP	2G05
MTC 4829	SEAL-GRILLE PANEL	2G05
MTC 4844	CATCH-REAR PILLAR RH	2H13
MTC 4845	CATCH-REAR PILLAR LH	2H13
MTC 4846	PLATE	2H13
MTC 4876	TAPE	2K09
MTC 4888	PLATE	2H13
MTC 4942	BRACKET	2H14
MTC 4943	HOODSTICK	2L04
MTC 4944	HOODSTICK	2L04
MTC 4945	HOODSTICK	2L04
MTC 4946	LADDER RACK	2H14
MTC 4948	SEAL RETAINER RH	2G17
MTC 4949	SEAL RETAINER LH	2G17
MTC 5034	GLASS-REAR WINDOW	2H16
MTC 5038	REAR UPPER PILLAR RH	2H11
MTC 5039	REAR UPPER PILLAR LH	2H11
MTC 5171	BODY SIDE CAPPING	2H06
MTC 5172	CAPPING FOR BODY SIDE	2H06
MTC 5191	SEAL RETAINER-LH	2H17
MTC 5192	SEAL RETAINER-RH	2H17
MTC 5304	FIXED WINDOW	2G14
MTC 5305	SLIDING WINDOW	2G14
MTC 5306	FIXED WINDOW SUNDYM	2G14
MTC 5307	SLIDING WINDOW SUNDYM	2G14
MTC 5308	GLASS-REAR SIDE DOOR	2G17
MTC 5309	GLASS-REAR SIDE DOOR	2G17
MTC 5310	GLASS-FIXED SIDE SCREEN-REAR	2G17
MTC 5311	GLASS-SLIDING SIDE SCREEN-	2G17
MTC 5311	FILLER (LOWER)	2G17

PART NUMBER	DESCRIPTION	REF.NO.
MTC 5314	GLASS	2H16
MTC 5315	GLASS-SIDE WINDOW	2H16
MTC 5316	GLASS WINDSCREEN RH	2G10
MTC 5317	GLASS WINDSCREEN LH	2G10
MTC 5318	WINDSCREEN GLASS LAMINATED	2G10
MTC 5324	DOOR ASSEMBLY(109 V8)	2H18
MTC 5343	REAR BODY COMPLETE ASSEMBLY	2H04
MTC 5354	SIDE PANEL	2H07
MTC 5355	SIDE PANEL	2H07
MTC 5359	REAR BODY COMPLETE ASSY	2H07
MTC 5360	REAR BODY COMPLETE ASSY	2H02
MTC 5365	SIDE PANEL	2H02
MTC 5366	SIDE PANEL	2H02
MTC 5370	W/SCREEN COMPLETE TOUGHENED	2G10
MTC 5380	W/SCREEN COMPLETE LAMINATED	2G10
MTC 5382	FRONT DOOR SIDE SCREEN RH	2G14
MTC 5383	FRONT DOOR SIDE SCREEN LH	2G14
MTC 5384	SIDE SCREEN-RH-FRONT DOOR	2G14
MTC 5385	SIDE SCREEN-LH-FRONT DOOR	2G14
MTC 5386	REAR SIDE DOOR RH	2G17
MTC 5387	REAR SIDE DOOR LH	2G17
MTC 5388	DOOR RH-REAR SIDE	2G17
MTC 5389	DOOR LH-REAR SIDE	2G17
MTC 5394	CAPPING	2H15
MTC 5395	CAPPING	2H15
MTC 5422	SIDE PANEL ASSEMBLY-RH	2H15
MTC 5423	SIDE PANEL ASSEMBLY-LH	2H15
MTC 5447	WINDSCREEN COMPLETE	2G10
MTC 6014	LOCK RING	2K05
MTC 6014	LOCKING RING	2L05
MTC 6074	CAPPING TOP SIDE	2H08
MTC 6075	CAPPING TOP SIDE	2H08
MTC 6410	RETAINING PLATE	2H16
MTC 6410	RETAINING PLATE	2I02
MTC 6448	SEAT FRAME	2K07
MTC 6456	HANDLE	2J08
MTC 6466	HINGE	2K03
MTC 6466	HINGE	2K04
MTC 6467	HINGE	2K03
MTC 6467	HINGE	2K04
MTC 6754	SQUAB SUPPORT LINK RH	2K02
MTC 6754	SQUAB SUPPORT LINK RH	2K03
MTC 6755	SQUAB SUPPORT LINK LH	2K02
MTC 6755	SQUAB SUPPORT LINK LH	2K03
MTC 6792	LOCK SUPPORT BRACKET	2K04

PART NUMBER		DESCRIPTION	REF.NO.
MTC	6792	LOCK SUPPORT BRACKET	2K05
MTC	6801	SPRING	2K05
MTC	6802	ANCHOR PLATE	2K05
MTC	6902	FRAME AND PANEL ASSY	2H18
MTC	6959	SEAL DASH TO WINDSCREEN	2G10
MTC	6960	SEAL WINDSCREEN TO ROOF	2H17
MTC	7793	COVER-SPARE WHEEL 88"	2H16
MTC	7793	COVER SPARE WHEEL	2I02
MTC	7797	SEAT BELT (AUDIBLE WARNING) LH	2I15
MTC	8376	PAD	2H12
MTC	8984	SQUAB RETENTION COVER	2K05
MTC	8985	SQUAB RETENTION COVER	2K05
MTC	9424	SCREW	2K05
MTC	9908	CLINCHED DOOR ASSEMBLY	2H18
MTC	9917	CLINCHED DOOR ASSEMBLY	2H18
MTC	9956	LOCKING TRIM	2J14
MTC	9958	LOCKING TRIM	2J14
MTC	9959	LOCKING TRIM	2J14
MTC	9962	NAIL TRIM	2J14
MTC	9967	LOCKING TRIM	2J14
MUC	1324	NUT PLATE	2H15
MUC	1715	REFLECTOR	2F05
MUC	2364	'U' BOLT FOR SPARE WHEEL CARRIER	2H16
MUC	2364	'U' BOLT	2I02
MUC	2366	BOLT PLATE SPARE WHEEL CARRIER	2H16
MUC	2366	BOLT PLATE	2I02
MUC	2368	THREADED WASHER	2H16
MUC	2368	WASHER	2I02
MUC	2588	FRAME	2G17
MUC	2589	FRAME	2G17
MUC	2934	CLAMP PLATE	2H16
MUC	2934	CLAMP PLATE	2I02
NC	112041	L CASTLE NUT 12 MM	1K06
NC	112041	L NUT-CASTELLED	1K07
NC	112041	L NUT	1K08
ND	604041	L CASTLE NUT (0.25" UNF)	1D05
NH	104041	L NUT	2H03
NH	104041	L NUT	2H06
NH	105041	L NUT	1013
NH	105041	L NUT	1N10
NH	105041	L NUT	2D04
NH	105041	L NUT	2F05
NH	105041	L NUT	2H17
NH	105041	L NUT	2K07
NH	106041	L NUT	1013

PART NUMBER	DESCRIPTION	REF. NO.
NH 106041	L NUT	1F02
NH 106041	L NUT	1G03
NH 106041	L NUT	1G04
NH 106041	L NUT	1I03
NH 106041	L NUT	1I13
NH 106041	L NUT	1K04
NH 106041	L NUT	1L07
NH 106041	L NUT	1L09
NH 106041	L NUT	1L10
NH 106041	L NUT	1L11
NH 106041	L NUT	1L12
NH 106041	L NUT	1L13
NH 106041	L NUT	1L16
NH 106041	L NUT	1N09
NH 106041	L NUT	1N11
NH 106041	L NUT	1N12
NH 106041	L NUT	1N13
NH 106041	L NUT	1007
NH 106041	L NUT	1011
NH 106041	L NUT	1014
NH 106041	L NUT	2C03
NH 106041	L NUT	2C05
NH 106041	L NUT	2C08
NH 106041	L NUT	2C11
NH 106041	L NUT	2D02
NH 106041	L NUT	2D04
NH 106041	L NUT	2F09
NH 106041	L NUT	2F12
NH 106041	L NUT	2G02
NH 106041	L NUT	2G04
NH 106041	L NUT	2G04
NH 106041	L NUT	2G06
NH 106041	L NUT	2G07
NH 106041	L NUT	2G08
NH 106041	L NUT	2G10
NH 106041	L NUT	2G11
NH 106041	L NUT	2G12
NH 106041	L NUT	2G13
NH 106041	L NUT	2G15
NH 106041	L NUT	2H02
NH 106041	L NUT	2H03
NH 106041	L NUT	2H04
NH 106041	L NUT	2H05
NH 106041	L NUT	2H06
NH 106041	L NUT	2H07

PART NUMBER	DESCRIPTION	REF. NO.
NH 106041	L NUT	2H08
NH 106041	L NUT	2H11
NH 106041	L NUT	2H13
NH 106041	L NUT	2H14
NH 106041	L NUT	2H15
NH 106041	L NUT	2H17
NH 106041	L NUT	2I02
NH 106041	L NUT	2I04
NH 106041	L NUT	2I15
NH 106041	L NUT	2J09
NH 106041	L NUT	2J10
NH 106041	L NUT	2J11
NH 106041	L NUT	2J13
NH 106041	L NUT	2J14
NH 106041	L NUT	2J16
NH 106041	L NUT	2K04
NH 106041	L NUT	2K05
NH 106041	L NUT	2K06
NH 106041	L NUT	2K07
NH 106041	L NUT	2L04
NH 106041	L NUT	2L14
NH 106041	L NUT	2L15
NH 106041	L NUT	2L16
NH 106044	NUT	2K05
NH 106044	NUT	2K08
NH 106044	L NUT	2K07
NH 108041	L NUT	1C04
NH 108041	L NUT	1C07
NH 108041	L NUT	1C13
NH 108041	L NUT	1E05
NH 108041	L NUT	1E07
NH 108041	L NUT	1E08
NH 108041	L NUT	1E13
NH 108041	L NUT	1I03
NH 108041	L NUT	1I05
NH 108041	L NUT	1L16
NH 108041	L NUT	1N10
NH 108041	L NUT	1007
NH 108041	L NUT	1011
NH 108041	L NUT	2C03
NH 108041	L NUT	2C05
NH 108041	L NUT	2C06
NH 108041	L NUT	2C08
NH 108041	L NUT	2C11
NH 108041	L NUT	2E16

PART NUMBER		DESCRIPTION	REF.NO.
NH 108041	L	NUT	2G05
NH 108041	L	NUT	2G18
NH 108041	L	NUT	2H09
NH 108041	L	NUT	2H09
NH 108041	L	NUT	2H10
NH 108041	L	NUT	2H13
NH 108041	L	NUT	2I15
NH 108041	L	NUT	2J16
NH 108041	L	NUT 8 MM	2L13
NH 108044		NUT	2K03
NH 108044		NUT	2K04
NH 110041	L	NUT 10 MM	1C14
NH 110041	L	NUT	1D15
NH 110041	L	NUT	1E13
NH 110041	L	NUT	1H02
NH 110041	L	NUT	1L08
NH 110041	L	NUT	2E07
NH 110041	L	NUT	2E09
NH 110041	L	NUT	2L02
NH 110041	L	NUT	2L03
NH 112041	L	NUT	1I02
NH 112041	L	NUT 12MM	2H16
NH 112041	L	NUT	2I02
NH 116041	L	NUT	1I02
NH 116041	L	NUT	2L03
NH 406041		NUT	1L05
NH 406041		NUT	2G07
NH 406041	L	NUT	1C14
NH 406041	L	NUT	1D15
NH 406041	L	NUT	1H03
NH 406041	L	NUT	1H07
NH 406041	L	NUT	1H09
NH 406041	L	NUT	1H12
NH 406041	L	NUT (0.375" BSF)	2E08
NH 408041		NUT	2L02
NH 504041	L	NUT (0.500"UNC)	2E04
NH 504041	L	NUT	2E05
NH 600041	L	NUT	1L14
NH 600041	L	NUT	1L15
NH 604041	L	NUT	1C08
NH 604041	L	NUT	1D11
NH 604041	L	NUT	1D12
NH 604041	L	NUT	1L05
NH 604041	L	NUT	1L07
NH 604041	L	NUT	1L09

PART NUMBER	DESCRIPTION	REF. NO.
NH 604041	L NUT	1L12
NH 604041	L NUT	1M04
NH 604041	L NUT	1N07
NH 604041	L NUT	1N08
NH 604041	L NUT	1N09
NH 604041	L NUT	1N11
NH 604041	L NUT	1N12
NH 604041	L NUT	1N13
NH 604041	L NUT	1N13
NH 604041	L NUT	1007
NH 604041	L NUT	1008
NH 604041	L NUT	1009
NH 604041	L NUT	1010
NH 604041	L NUT	1011
NH 604041	L NUT	1012
NH 604041	L NUT	1014
NH 604041	L NUT	2C03
NH 604041	L NUT	2C04
NH 604041	L NUT	2C05
NH 604041	L NUT	2C07
NH 604041	L NUT	2C08
NH 604041	L NUT	2C09
NH 604041	L NUT	2C10
NH 604041	L NUT	2D02
NH 604041	L NUT	2F09
NH 604041	L NUT	2F12
NH 604041	L NUT	2G02
NH 604041	L NUT	2G04
NH 604041	L NUT	2G06
NH 604041	L NUT	2G07
NH 604041	L NUT	2G08
NH 604041	L NUT	2G10
NH 604041	L NUT	2G11
NH 604041	L NUT	2G12
NH 604041	L NUT	2G13
NH 604041	L NUT	2G15
NH 604041	L NUT	2G18
NH 604041	L NUT	2H02
NH 604041	L NUT	2H03
NH 604041	L NUT	2H04
NH 604041	L NUT	2H05
NH 604041	L NUT	2H06
NH 604041	L NUT	2H07
NH 604041	L NUT	2H08
NH 604041	L NUT	2H13

PART NUMBER		DESCRIPTION	REF. NO.
NH 604041	L	NUT	2H14
NH 604041	L	NUT	2H15
NH 604041	L	NUT	2H16
NH 604041	L	NUT	2H17
NH 604041	L	NUT	2H18
NH 604041	L	NUT	2I02
NH 604041	L	NUT	2I15
NH 604041	L	NUT	2J09
NH 604041	L	NUT	2J10
NH 604041	L	NUT	2J11
NH 604041	L	NUT	2J16
NH 604041	L	NUT	2K04
NH 604041	L	NUT	2K05
NH 604041	L	NUT	2K06
NH 604041	L	NUT-SELF-LOCKING	2L12
NH 604041	L	NUT	2L13
NH 604041	L	NUT(0.25"UNF) FIXING HOSE TO	2L17
NH 604061	L	NUT	1K04
NH 604061	L	NUT 0.250 UNF	1007
NH 604061	L	NUT	1009
NH 604061	L	NUT	1011
NH 605041	L	NUT	1013
NH 605041	L	NUT	1C04
NH 605041	L	NUT	1C07
NH 605041	L	NUT	1C13
NH 605041	L	NUT	1D08
NH 605041	L	NUT	1D13
NH 605041	L	NUT	1D14
NH 605041	L	NUT	1D15
NH 605041	L	NUT	1E05
NH 605041	L	NUT	1E07
NH 605041	L	NUT	1E08
NH 605041	L	NUT	1E13
NH 605041	L	NUT	1F03
NH 605041	L	NUT	1F04
NH 605041	L	NUT	1G03
NH 605041	L	NUT	1G04
NH 605041	L	NUT	1H13
NH 605041	L	NUT	1K04
NH 605041	L	NUT	1K05
NH 605041	L	SPECIAL NUT	1L02
NH 605041	L	NUT	1L03
NH 605041	L	NUT	1L04
NH 605041	L	NUT	1L07
NH 605041	L	NUT	1L07