


# PARTS DIAGRAM & LIST



Please visit our website [www.uniqueappliances.com](http://www.uniqueappliances.com) to view a PDF version of the schematics which will allow you to zoom in & out

# PARTS DIAGRAM & LIST

NO.	PART NUMBER	DESCRIPTION
1	UGP-BCD-230 S1	Screw ST4.2x16
2	UGP-BCD230-LH01-T	Top Cover Turquoise for UGP-230L Fridge
	UGP-BCD230-LH01-LG	Top Cover Light Green for UGP-230L Fridge
	UGP-BCD230-LH01-BP	Top Cover Bubblegum Pink for UGP-230L Fridge
	UGP-BCD230-LH01-W	Top Cover White for UGP-230L Fridge
	UGP-BCD230-LH01-B	Top Cover Black for UGP-230L Fridge
3	UGP-BCD230-02	Top Cover Holder for UGP-230L Fridge
4	UGP-BCD-T00-07	Flange screw M5x16
5	UGP-BCD230-01-00	Top Hinge for UGP-230L Fridge
6	N/A	
7	UGP-BCD-T00-05	Left Side Adjustable Foot for UGP_230L Fridge
8	UGP-BCD230-LH-00-02	Bottom Hinge for UGP-230L Fridge
9	UGP-BCD-T00-04	Right Side Adjustable Foot for UGP-230L Fridge
10	UGP-BCD-T00-04D	Hinge Mount Adjustable Foot for UGP-230L Fridge
11	UGP-BCD230-00-03	Glass Shelf with Ornament Strip(4 per unit) for UGP-230L Fridge
12	UGP-BCD230-00-05	Crisper Cover Glass with Ornament Strip for UGP-230L Fridge
13	N/A	
14	UGP-BCD230-130-03	Crisper for UGP-230L Fridge
15	UGP-BCD230-T00-17C	Wine Rack for UGP-230L Fridge
16	UGP-BCD230-19500-03	Freezer Door Stopper for UGP-230L Fridge
17	N/A	
18	UGP-BCD230-19500-02	Fixed Seat for UGP-230L Fridge
19	UGP-BCD230-1950001-03	Freezer Door Gasket for UGP-230L Fridge
20	UGP-BCD230-1950001-00	Freezer Door ASSY for UGP-230L Fridge
21	UGP-BCD230-1950001-04	Freezer Door Hole Cap for UGP-230L Fridge
22	UGP-BCD230-19500-01	Freezer Door Hinge for UGP-230L Fridge
23	UGP-BCD230-WD04-03A	Thermostat for UGP-230L Fridge
24	UGP-BCD230-WD00-09H	LED Lamp for UGP-230L Fridge
25	UGP-BCD230-T04-01C	Thermostat Shell for UGP-230L Fridge
26	UGP-BCD230-ST4220	Screw ST3.5x12
27	UGP-BCD230-T04-02	Thermostat Regulator Knob for UGP-230L Fridge
28	UGP-BCD230-T04-03	LED Lamp Cover for UGP-230L Fridge
29	UGP-BCD230-ST3X10	Screw ST3x10
30	UGP-BCD230-WD00-04A	Light Switch for UGP-230L Fridge
31	UGP-BCD230-T00-31	Drain Cleaning Tool for UGP-230L Fridge
32	UGP-BCD230-23506-05	Fridge Door Gasket for UGP-230L Fridge
33	N/A	
34	UGP-BCD230-10906-07	Egg Tray for UGP-230L Fridge
35	UGP-BCD230-06-06	Upper Balcony with Ornament Strip for UGP-230L Fridge
36	UGP-BCD230-06-07	Lower Balcony with Ornament Strip for UGP-230L Fridge
37	UGP-BCD230-213LH-03-05T	Top Hinge Cover Turquoise for UGP-230L Fridge
	UGP-BCD230-213LH-03-05LG	Top Hinge Cover Light Green for UGP-230L Fridge
	UGP-BCD230-213LH-03-05BP	Top Hinge Cover Bubblegum Pink for UGP-230L Fridge
	UGP-BCD230-213LH-03-05W	Top Hinge Cover White for UGP-230L Fridge
	UGP-BCD230-213LH-03-05B	Top Hinge Cover Black for UGP-230L Fridge

# PARTS DIAGRAM & LIST

NO.	PART NUMBER	DESCRIPTION
38	UGP-BCD230-Door LG	Fridge Door Light Green for UGP-230L Fridge
	UGP-BCD230-Door BP	Fridge Door Bubblegum Pink for UGP-230L Fridge
	UGP-BCD230-Door W	Fridge Door White for UGP-230L Fridge
	UGP-BCD230-Door B	Fridge Door Black for UGP-230L Fridge
39	UGP-BCD230-118LH03-08	Fixed Base for Handle for UGP-230L Fridge
40	UGP-BCD230-M5X8	Screw M5x8
41	UGP-BCD230-213LHC03-06	Door Handle for UGP-230L Fridge
42	UGP-BCD230-M5X6	Screw M5x6
43	UGP-BCD230-T06-06	Fridge Door Stopper for UGP-230L Fridge
44	UGP-BCD230-T00-01D	Drain Pipe for UGP-230L Fridge
45	UGP-BCD-UKV52YAX	Compressor UKV52YAX for UGP-230L Fridge
46	UGP-BCD-M5X10	Screw M5x10
47	UGP-BCD-230 S2	Screw M4x10
48	UGP-BCD230-WD01-02M	Power Cord with Plug for UGP-230L Fridge
49	N/A	
50	UGP-BCD230-24810-00	Compressor Base for UGP-230L Fridge
51	UGP-BCD230-WZ00-01	Drier Filter for UGP-230L Fridge
52	UGP-BCD230-T00-37D	Drip Tray for UGP-230L Fridge
53	UGP-BCD230-222K00-05	Plastic Back Cover Panel for UGP-230L Fridge
54	UGP-BCD230-T00-37	Ice Scraper
55	UGP-BCD230-T00-02B	Ice Tray for UGP-230L Fridge
	UGP-BCD230-PC Retainer	Power Cord Retainer for UGP-230L Fridge
	UGP-BCD230-M	Manual Kit for UGP-230L Fridge
	UGP-BCD230-Carton	Outer Carton for UGP-230L
	UGP-BCD230-package	Interior Packaging Materials Kit for UGP-230L