

OPERATING GUIDE

HEATED JACKET



Step 1

Connect battery to cable in small side pocket using either USB port

Button on front of jacket will flash 3 colours then turn off.



Step 2

Press and hold power button on front of jacket until button lights up

You need to do this within a few seconds or the battery will turn off and you will have to disconnect then reconnect the battery



Step 3

Place battery in pocket and zip it back up

IMPORTANT

The power button will pulse red. This is The fast-heat mode.

NOTE: The vest will cut out and power off within 5 minutes unless you select a heat mode (Step 4)



Step 4

To change heat setting single press the power button to cycle through the 3 heat modes



Low [longest run time]

Medium


High [shortest run time]



Step 5

To power off jacket, press and hold the power button until there is no light from button

If you need to power jacket on again you may need to disconnect the battery then reconnect and follow step 3



Wash Care

Ensure you remove battery before you wash your jacket

Most stains should be wiped off with a cloth and water. Make sure you wash separate with zippers closed



30°C



Do Not Tumble Dry



Drip Dry in Shade



Do Not Iron



Do Not Dry Clean

jackoli

www.jackoli.com