



BIO FIRES SMALL BURNER DIRECTIONS AND INSTRUCTIONS

Bio Fires should only be used indoors in a well ventilated but draught-free area, as fire depletes oxygen in the air.

Please read the following carefully:

The kit includes

Steel burner with a sliding steel lid, Extinguishing tool, Funnel

General Information

When placing the bio burner in your own fireplace, ensure there is sufficient air flow around it. Ensure there is sufficient space of approximately 50cm height clearance for the flame.

This product should only be placed in a fireproof surrounding far away from any flammable materials.

Directions For Use

1. Adjust the sliding lid to its widest opening.
2. Please ensure your pebbles or logs are not covering the opening in case of accidental spillage.
3. Ensure the funnel provided is securely held when pouring the bio fuel into the burner and watch carefully till you reach under the level marked 'MAX'. DO NOT overfill or spill. Please note if your fuel level is not high enough the fuel could splash while igniting. To avoid this always top up your fuel level before igniting.
4. Do not pour fuel directly from the bottle into the container; always use a funnel to avoid spillage.
5. Any spilled bio alcohol must be immediately removed with absorbent tissue and cleaned with water to prevent ignition outside the burner reservoir. Any ceramic pebbles or logs that the fuel might have been spilled on must be removed and allowed to fully dry before putting back into the fireplace.

Lighting

1. Use a long match or a long-end lighter to ignite.
2. When igniting, keep a safe distance at arm's length.
3. Please allow 10-15 minutes to reach the optimum temperature and flame height.
4. Avoid drafts for longer burning time.

Extinguishing The Fire

If you wish to extinguish the fire before the fuel has completely burned out, place the steel extinguishing tool securely into the round knob of the fuel container, and slide shut in a fast motion, completely covering the flame. When product is not in use, keep the container closed with the sliding lid to prevent excess evaporation of fuel.

For Your Safety

1. **Never pour fuel into burning flame.**
2. Allow the burner to cool down before refilling (for several minutes).
3. Do not attempt to cook anything over the flames.
4. **Do not blow the flame out** or blow on it to try to enhance the flame.
5. If you do burn any other bio fuel rather than our brand in your burner **it must not exceed more than 96% ethanol.**
6. Do not burn any other substances e.g. Pure® Gel Fuel.
7. Keep any combustible or flammable materials away from the flame.
8. Do not smoke while filling the container.
9. Make sure you can see the level of the fuel at all times while filling the container, use a torch if necessary.
10. It is not recommended to be used in a bedroom as you may fall asleep with the appliance still alight.
11. Never leave the lit product unattended.
12. Make sure children keep away from the flames.
13. Never attempt to clean the container when lit or still hot.
14. This fireplace is for decorative purposes, although giving off considerable heat, it cannot replace conventional heating.

Our product contains:

Ethanol solution 96% (Ethyl alcohol solution)

1. The bio fuel is easily soluble in water and is a biodegradable material.
2. When not in use, never leave the bio fuel in direct sunlight.
3. The fuel should be stored at room temperature as if it is cold it may be difficult to light.
4. If accidentally swallowed, seek immediate medical attention and show the label on the bottle
5. In the event of skin contact, wash with soap and cold water. If irritation develops then medical attention should be sought.
6. In the event of eye contact, remove contact lenses if applicable, immediately flush eyes with water or saline solution and seek medical attention.
7. Important - it can aggravate some respiratory disorders.
8. Store the fuel out of reach of children and pets.

DO NOT LIGHT FIREPLACE UNTIL ANY SPILLAGE IS FULLY DRY INCLUDING PEBBLES. NEVER BLOCK THE FLAME WITH ANY ACCESSORIES AS THIS WILL LEAD TO AN IMMEDIATE SOOT DEPOSIT AND WILL CREATE FUMES AND SOOT BY PRODUCTS

WARNING! WE DO NOT RECOMMEND THE USE OF 'CERAMIC SPONGE / WOOL' (said to increase the burning time) INSIDE THE BURNER. THIS CAN LEAVE CINDERS AT THE BASE OF THE BURNER CAUSING THE FLAME TO RE-IGNITE WHEN REFILLING.

Gel Fireplaces Ltd (incorporating Bio Fires)
Tel: +44 (0) 20 7724-1919
100 Crawford Street, London, W1H 2HW, UK
www.biofires.com / www.gelfireplaces.com
info@gelfireplaces.com