





# TABLE OF CONTENTS

Wands and Curling Irons	1
Flat Irons	5
The Tamanna 3-in-1	9
The 5-in-1	13
The Blowdryer	18
Troubleshooting	22
Warranty Information	24



How to Use

# WANDS AND CURLING IRONS



Temperature



Power

## How to Use **Wands and Curling Irons**

1



Plug in your tool. Once your tool is plugged in your display will say OFF. Some models may flash the OFF sign in blue.

2



To power on your tool hold down the ON/OFF button (middle button) for 2-4 seconds until the temperature is displayed.

3




You can now adjust the temperature with the up and down arrows on either side of the ON/OFF button.

## How to Use **Wands and Curling Irons**


4



5



6




Once your tool has reached the desired temperature your screen will turn green to indicate the tool is ready for use.

Style your hair as desired.

Once done, you can power off your tool by holding the on/off button down for 2-4 seconds. Your screen will display the OFF sign. You can now unplug your tool.

## How to Use **Wands and Curling Irons**

7




8



Let your tool completely cool before storing away.

Love your hair! Tag us  
[#BombayHair](#)



How to Use

# The Flat Iron



Temperature



Power




## How to Use The Flat Iron

1




Plug in your tool. Once your tool is plugged in your display will say OFF. Some models may flash blue.

2



To power on your tool hold down the ON/OFF button for 2-4 seconds until the temperature is displayed.


3



You can now adjust your temperature with the up and down arrows on either side of the ON/OFF button.


## How to Use The Flat Iron

4




Once your tool has reached the desired temperature your screen will turn green to indicate the tool is ready for use.

5



Style your hair as desired.


6



Once done, you can power off your tool by holding the on/off button down for 2-4 seconds. Your screen will display the OFF sign. You can now unplug your tool.

## How to Use **The Flat Iron**

7



Let your tool completely cool before storing away.


8



Love your hair! Tag us  
[#BombayHair](#)

How to Use

# The Tamanna 3-in-1




Temperature




Power

## How to Use **The 3-in-1**


1



2



3




Start by making sure your tool handle is in the unlock position.

Line up the inner prongs and insert your desired barrel. There should be no space left between your barrel and handle once it is inserted correctly. You may need to rotate the barrel.


Lock your tool into place by rotating the top lock indicator to LOCK.

## How to Use The 3-in-1


4



5



6




Plug in your tool. Once your tool is plugged in adjust your temperature with the up and down arrows on either side of the ON/OFF button.

While the tool is heating it will flash red. Once the light turns solid green, you have reached your desired temperature.

Style your hair as desired.


## How to Use The 3-in-1

7



Once done, you can power off your tool by moving the temperature gauge to OFF. You can now unplug your tool.


8



Let your tool completely cool before storing away or removing any barrels.

**WARNING:** Do not touch barrels after styling. Barrels must be completely cool before removing from handle.


9



To change your barrel once it is completely cool, move the lock indicator to UNLOCK and pull the barrel out gently.

How to Use

## The 5-in-1



pearl 25mm 19mm 13/35 tapered 32mm



Temperature




Power




## How to Use **The 5-in-1**


1



2



3




Start by making sure your tool handle is in the unlock position.

Line up the inner prongs and insert your desired barrel. There should be no space left between your barrel and handle once it is inserted correctly. You may need to rotate the barrel.

Lock your tool into place by rotating the top lock indicator to **LOCK**.


## How to Use The 5-in-1

4




Plug in your tool. Once your tool is plugged in your display will say OFF. Some models may flash blue. (If your tool says ERR your barrel may be inserted incorrectly, repeat steps 1-4)

5



To power on your tool hold down the ON/OFF button for 2-4 seconds until the temperature is displayed.


6



You can now adjust your temperature with the up and down arrows on either side of the ON/OFF button.


## How to Use The 5-in-1

7




Once your tool has reached the desired temperature your screen will turn green to indicate the tool is ready for use.

8



Style your hair as desired.


9



Once done, you can power off your tool by holding the ON/OFF button down for 2-4 seconds. Your screen will display the OFF sign. You can now unplug your tool.

## How to Use **The 5-in-1**


10



Let your tool completely cool before storing away or removing any barrels.

**WARNING:** Do not touch barrels after styling. Barrels must be completely cool before removing from handle.


11



To change your barrel once it is completely cool, move the lock indicator to UNLOCK and pull the barrel out gently.


How to Use

# The Blow Dryer




## How to Use The Blow Dryer

1




Start by making sure all switches are turned off.

2



Turn on your blow dryer by switching the ON/OFF button to on.


3



To increase or decrease the power of your blow dryer, use the black switch above the power ON/OFF


## How to Use The Blow Dryer

4




To increase or decrease the temperature of the blow dryer, use the red button

5



Begin to blow dry hair with a medium-sized round or flat brush using the positive ion (+) setting, as the positive setting helps to open the hair cuticle allowing for deeper penetration of heat; therefore, faster drying time.


6



Once your hair is 80% dry, then switch over to the negative ion setting. Negative ions (-), makes the heat much gentler on the hair during styling – therefore, allowing for a shinier and a less frizzy finish.


## How to Use The Blow Dryer

7



To cool blast your hair, hold down the button underneath the head of the blow dryer. You must hold down this button to continue blowing cold air.

8



Switch all settings to off before removing electrical plug and storing the unit away.



# TROUBLESHOOTING

## 1 My tool is flashing blue, and the screen says OFF

Some of our models have this as a safety default. Rest assured this is normal operation and will stop once the tool is disconnected from electricity.

## 2 My tool is displaying a stars and moon icon

The stars and moons represent auto shut-off. Seeing them on the display means this feature is turned on. If you would like to change the length of time for auto shut off or shut it off completely, hold down the ( - ) key on straighteners or ( < ) on wands/curling irons. Your display will turn red, and as default display 60. You can use the (+/-) or (</>) keys to change the duration. This time represents how long your tool is on before it automatically shuts off. Turning the time to 0, will turn off your auto shut off. We do not recommend turning off your auto shut off.

## 3 My tool is showing the temperature in celsius and I would like it in fahrenheit

In order to change the unit of temperature, hold down the ( + ) icon on straightener mode. For curling irons or wands, hold down the ( > ) arrow.

4

**My 5-in-1 or 3-in-1 is showing ERR when the barrel is inserted**

Your barrel is incorrectly inserted. Move the LOCK/UNLOCK indicator to UNLOCK and release the barrel. Then move the LOCK/UNLOCK indicator back and forth 5-10 times without a barrel inserted. Then reinsert your barrel, ensuring it is fully pushed in. Move the indicator to LOCK. You should see no space between the barrel and handle of the tool. If you still see ERR on your screen, try to repeat these steps with a different barrel.

If the issue persists, contact our support team at [www.bombayhair.com](http://www.bombayhair.com).

5

**My tool is plugged in but there is no display message or lights**

Please ensure that the outlet you are using is active and being supplied electricity. You can do this by plugging in another known working item.

If you have tested the electrical outlet and are still not able to turn the tool on, please visit us at [support@bombayhair.com](mailto:support@bombayhair.com) for further trouble shooting.

# WARRANTY INFORMATION

## Under 90 Days

All styling tools are covered by a 90 day replacement guarantee. If your tool is deemed faulty within 90 days of delivery, you will be issued a replacement at no cost.

This replacement guarantee does not cover:

1. Damage due to misuse or abuse, such as incorrect incorrect voltage supply, liquid damage, dropping, or failure to follow instructions enclosed in product packaging;
2. Tampering, such as repair or attempted repair.
3. Tools shipped outside of North America ordered from [www.bombayhair.com](http://www.bombayhair.com) and [www.bombayhair.ca](http://www.bombayhair.ca)

## Over 90 Days

All styling tools over the 90 day period, are then covered by a limited replacement product warranty if it is defective in workmanship or materials. Tools aged 91+days will be subject to a \$45.00 replacement fee.

The Tamanna Styling Set is covered by an additional warranty which waives the replacement fee for these tools if it is defective in workmanship or materials within a one (1) year period.

Please register your tool at [www.bombayhair.com](http://www.bombayhair.com)

This Warranty Does Not Cover:

1. Damage due to misuse or abuse, such as incorrect voltage supply, dropping, or failure to follow instructions enclosed in product packaging;
2. Tampering, such as repair or attempted repair.
3. Tools shipped outside of North America (Canada & USA).

THIS LIMITED WARRANTY IS ONLY VALID: (1) IF THE PRODUCT IS PURCHASED FROM AN AUTHORIZED SELLER OF BOMBAY HAIR GOODS AND (2) IF THE ORIGINAL HARDWARE ON THE PRODUCT HAS NOT BEEN REMOVED OR OTHERWISE TAMPERED WITH.

ANY IMPLIED WARRANTIES, OBLIGATIONS, OR LIABILITIES, INCLUDING BUT NOT LIMITED TO THE IMPLIED WARRANTY OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE, SHALL BE LIMITED IN DURATION TO THE (12) TWELVE MONTHS OF THIS WRITTEN LIMITED WARRANTY.

IN NO EVENT SHALL BOMBAY HAIR BE LIABLE FOR ANY SPECIAL, INCIDENTAL, OR CONSEQUENTIAL DAMAGES FOR BREACH OF THIS OR ANY OTHER WARRANTY, EXPRESS OR IMPLIED. THIS WARRANTY POLICY IS SUBJECT TO CHANGE.

