



Ghost 410			
Item #	Description	Qty	
1	3283 HALF STOCK	1	
2	3468 TRIGGER PIN	1	
3	4074 SCREWS	4	
4	B3469 WASHER	1	
5	3043A LOCK WASHER	1	
6	3658 SCREW	1	
7	3289 TRIGGER ASSEMBLY	1	
8	3285 TRACK	1	
9	3174 SCREWS	4	
10	2249B BOLT INSERT - NOSE	1	
11	2237 FRONT MOLDING	1	
12	2245 END CAP	1	
13	3402 TEFLON TAPE	1	
14	2247 ROUND BAR	1	
15	2410 TRACK INSERT - RIGHT	1	
16	2411 TRACK INSERT - LEFT	1	
17	4074 SCREW	1	
18	3171 SCREW	1	
19	B3671 7/8" SCOPE MOUNT	1	
20	3677 BRUSH	1	
21	3675 BRUSH HOLDER	1	
22	3441 SCREW	1	
23	1964 SAFE-FIRE STICKER	1	
24	1827 SCREW	1	
25	3332 TRIGGER HEX INSERT	2	
26	3627 TRIGGER HOOD GASKET	1	
27	1904 TRIGGER HOOD	1	
28	1965 FIRE-SAFE STICKER	1	
29	3644 SCREWS	2	
30	3646 SCREWS	2	
31	3656 SCREWS	2	
32	3657 SCREWS	2	
33	1533 SOFT TOUCH GRIP	1	
34	1017E CHEEK PIECE, RIGHT	1	
35	3353 SCREWS	8	
36	1017C CHEEK REST, RIGHT	1	
37	5195 CCD BUSHING	1	
38	1017F BUTT PLATE	1	
39	3650 SCREW	1	
40	3651 SCREW	1	
41	1017B CHEEK REST, LEFT	1	
42	1017D CHEEK PIECE, LEFT	1	
43	B6100 FINGER REMINDER, LEFT	1	
44	5051 SCREW	4	
45	6101 FINGER REMINDER, RIGHT	1	
46	S3283 BARNETT DOME LABEL	1	
47	2285 GHOST 415 DOME LABEL	1	
48	2491 PALM REST - LEFT	1	
49	3171 SCREWS	2	
50	3008 FIBER WASHER	1	
51	3167 SWIVEL STUD	1	
52	2492 PALM REST TOP	1	
53	3187 SCREW	1	
54	2490 PALM REST - RIGHT	1	

Cannot be sold to Consumers