




**FAUCET** 



## NOTICE

- 1.- Make sure the ware supply valve is shut off before installation.
- 2.- Make sure that you have access to all plumbing and drain fittings, door clearence and other obstructions

