


**gosun**<sup>®</sup>  
THERMO

# USER'S GUIDE



**SET IT + FORGET IT**

SMART BLUETOOTH THERMOMETER

# Parts & Features

Probe Socket



Power ON / OFF  
Pairing / Stop Alarm  
Backlight ON / OFF

Magnetic  
Stand

Battery  
Cover

Silicone  
Cable Wrap

Probe



# 1

## PAIR YOUR DEVICE

### A. Download the App

Search the keyword 'GoSunThermo' in App Store or Google Play. Download and install it for free.

Compatible Devices include:

- Apple Devices: iPhone 4S and newer, iPod Touch 5<sup>th</sup> generation and newer, iPad 3<sup>rd</sup> generations and newer
- Android: All devices running version 4.3 or later with bluetooth 4.0 module

### B. Turn on the Thermometer

Press and hold the **Power ON / OFF** button for more than three seconds to turn on. The LCD display will read 'ON'

**NOTE:** If the probe is not plugged into the Thermometer, it will power off automatically

### C. Pair with your mobile device


1. Enable the Bluetooth on your device.
2. Launch the app and follow step-by-step guide in the app to pair and activate the two devices.
3. Once you've paired the Thermometer to your mobile device, they will automatically find and pair to each other when both devices and Bluetooth are switched on.

# 2

## START COOKING

### Install the Probes

1. Release the Probe from the body of the Thermometer so that it is in the 'Extended Probe Configuration' (see figure below).
2. With your food in your GoSun Tray and the Thermometer switched on, insert the Probe into desired food. For an accurate temperature reading, position the Probe so that its point is as close to the center of your piece of food as possible.
3. Slide the GoSun Tray closed with the Thermometer inserted so that the cord sits in the notch cut out of the silicone gasket.



# 3


## INTERFACES

### On your GoSun Thermo LCD Display




### In the GoSunThermo App

1. With the Probe , push 'Set Preset' to adjust the food type. The target temperatures for each food type are editable within this menu.
2. Enjoy some sunshine while the GoSun works its magic!
3. Both the app and the Thermometer device will sound an alarm when the food reaches the target temperature.



# Specifications

**ATTENTION:** Temperature Probe diagrammed below for is for reference only and is subject to the actual Probes.





# CAUTION



## **Warning: Heat Resistance Varies**

The heat resistance varies in different components of the Probe.

DO NOT expose the Probe, Handle or Wire directly to open fire or flame.

DO NOT put the plastic body of the device into your GoSun product or other oven.

DO NOT submerge the Probe wire in water.

DO NOT get the plug leads or connectors wet.

The GoSun Thermo is NOT dishwasher safe.

## **Operation Applies to the following conditions:**

1. This device may not cause interference
2. This device must accept an interference, including interference that may cause undesired operation of this device.

App Store is a service mark of Apple Inc.  
Google Play is a service mark of Google Inc.



# WARRANTY

## PLEASE ACTIVATE YOUR WARRANTY!

- Keep your Thermometer protected for free
- Access to product resources & more
- Must register within 10 days of purchase

\*If ordered from gosun.co, you're already covered

## REGISTER TODAY:

[www.gosun.co/pages/register](http://www.gosun.co/pages/register)

Manual available in other languages on our website:

[www.gosun.co/pages/product-manuals](http://www.gosun.co/pages/product-manuals)

