



PACIFIC PLAY TENTS, INC.

“Giant Castle Combo”

Item #41616

“King’s Kingdom Combo”



Thank you for purchasing Pacific Play Tents, “King’s Kingdom Combo”. We at PPT are confident that our tents will provide you and your children with endless hours of creative fun and enjoyment year-round. We encourage you to read and understand each step of the set-up process prior to assembly. Invite your child to help. **Set-up is a fun and easy process.**

Made with flame resistant fabric which meets CPAI-84 specifications, it is **NOT FIRE PROOF**. The fabric will burn if left in continuous contact with any flame source. Content - Shell: 100% Polyester - Frame: Fiber glass pole.

Cette tente est fabriquée d’un tissu résistant au feu, mais qui n’est pas ininflammable. Ce tissu brûlera s’il est laissé en continu avec source d’inflammation. Contenu - Extérieur: 100% Polyester - Armature: Fibre de verre.

Let’s get started!

PLEASE READ ALL OF THE DIRECTIONS PRIOR TO ASSEMBLY. DO NOT APPLY EXCESS FORCE TO THE POLES DURING ASSEMBLY.

Step #1: Start with the King’s Kingdom tent on the ground, upside down (so The floor is on top) Note: There are two different groups of poles: 10 with metal connectors at one end, and 6 without any metal connectors. Begin by using the 10 poles with metal connectors. Insert the end of the pole without the metal connector through the opening on the bottom of the tent as shown in diagram 1. Continue this process by inserting the 2nd pole into the metal receptor of the first pole. Continue with the 3rd and 4th poles and then connect the end of the poles together, forming a circle.

Step #2: Turn the tent over so that the bottom is now on the ground. As in Step #1, begin inserting the first pole into the opening at the top of the tent. Continue as in step #1 until all 4 poles are inserted and their ends have been connected together as you did on the bottom. (See diagram # 1)

Step #3: Lay the tents on its side. Begin to insert on of the 6 poles provided (Without any metal connectors) into the sleeves at the side of the tent. Insert the end of the pole into the connector at the bottom and the top. (As shown in Diagram # 2.)




Diagram #1




Diagram #2




Diagram #3




Diagram #1-1




Diagram #2-2





Diagram #3-3



Step #4: Now place the tent upright to insure that all of the poles are properly connected together (On Top and Bottom) and that the vertical poles are all connected in their sleeves. (As shown in diagram # 3)

Step #1: – You are now ready to begin assembly of the “King’s Kingdom”. Lay the Tower out so that the bottom opening of the Tower is on the top. (Diagram #1-1) Note: There are two different sets of poles: 4 poles that are connected by an elastic shock cord, and 6 plastic poles (3 with metal connector ends and 3 without) We will begin by using the 6 plastic poles. Start by inserting a plastic pole WITH a metal connector end into the rim sleeve of the bottom of the Tower, using the end without the connector first. Then insert the pole without any connectors into the opposite side of the same sleeve. Connect the end of the second pole into the metal connector of the first pole and you will now have the semi-circular section that makes up the back of the tower.

Step #2: – Turn the Tower over so that the bottom is now on the ground. As in step 5, begin inserting the pole with the connector end into the top sleeve, plain end first, then insert the second pole into the opposite side of the sleeve and connect them in the middle, forming the top semi-circle.

Step #3: – Lay out the 4 shock corded poles so that the two sections of each pole fit together, making 4 longer poles. Lay the Tower on its side. Begin inserting a shock cord pole into the sleeve that runs from the bottom of the theater to the top. Insert the ends of the pole into the connector at the bottom and the top (as shown in diagram #2-2). Repeat this step for the remaining 3 shock cord poles.

Step #4: – Now that the Tower is up and self supported, insert the final two plastic poles into the center horizontal sleeve. Follow the process outlined in Steps 1 and 2.

Step #5: – Finally place the Tower upright and insure that all poles are securely connected together at the top and the bottom, and that the upright, shock cord poles are all connected in their sleeves (as shown in diagram #2-2).

Your “King’s Kingdom Combo” is now set up and ready to be enjoyed by the entire family. If you should have any questions, please contact Pacific Play Tents customer service department at (323) 269-0431. We hope you enjoy your new “King’s Kingdom Combo” and that you have many years of imaginative playtime with it. All of our products are constructed of the finest materials and craftsmanship. Pacific Play Tents is dedicated to providing you with creative high quality, value oriented, indoor/outdoor play products.