




USER MANUAL

ACEMILE® | THEATRE BOX™ | CBT612



www.acemile.net

ACEMILE

BRAND

THEATRE BOX™ is a leading wireless portable audio system that provides an immersive virtual 3D audio experience using innovative Q3D Holophony™ technology for hours of enjoyment. With THEATRE BOX™, no matter where the speaker is positioned, you're in the "sweet spot".

ACEMILE® has created a 4,1-channel audio system designed to easily move from room to room. With four 2-inch full-range drivers and one 3-inch bass driver controlled by dual-core audio processing circuitry, the THEATRE BOX™ delivers outstanding, high-fidelity music, movie or video game audio with clarity and power. It's designed to be used indoors in an area ranging from approximately 150 to 1,300 square feet (15' x 20 square meters) without any major obstacles. For optimal enjoyment, THEATRE BOX™ should be positioned 6 - 22 feet (2 - 7meters) from the listener.

CAUTION

- Before using the THEATRE BOX™, please carefully read the user manual. Users are urged to follow the steps instructed and heed all warnings below.
- Do not use the device near water. Only clean it with a soft, dry fabric. Avoid the use of abrasive cleaners.
- Do not use the device near any heat sources (portable heaters, radiators, stoves, etc.) or any other devices that generate heat.
- Only use accessories provided or specified by the manufacturer.
- Unplug the device during thunder/electrical storms or during extended periods of non-use
- Do not expose the device to dripping or splashing water. Do not place objects full of water near it.
- Do not place the device near hazardous chemicals or open flames, including candles.

FCC CAUTION

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This device complies with Part 15 of the FCC Rules.

Operation is subject to the following two conditions:

- (1) this device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation.

IC CAUTION

This device complies with Industry Canada licence-exempt RSS standard(s). Operation is subject to the following two conditions: (1) this device may not cause interference, and (2) this device must accept any interference, including interference that may cause undesired operation of the device.

Le présent appareil est conforme aux CNR d'Industrie Canada applicables aux appareils radio exempts de licence. L'exploitation est autorisée aux deux conditions suivantes : (1) l'appareil ne doit pas produire de brouillage, et (2) l'utilisateur de l'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.

SPECS

10.3 in. (260mm) 4.3 in. (110mm) 3.3 in. (85mm)

Four 2-inch full-range drivers; one 3-inch active bass driver

Q3D Holophony™ technology

Built-in 360° microphone

Frequency Range 20Hz-20KHz

Bluetooth V4.0 compliant, A2DP 1.2, HFP 1.6

Supports most music formats, along with transmission of Apt-X, SBC and AAC


3.5 mm stereo input (aux in)

Power output (peak): 125 W


Power supply Adaptor Input: 100~240V 50/60Hz 1.5A max

Output: 15V/3A DC


Build-in rechargeable Lithium ion battery: 28.86Wh



REAR PANEL




CONTROL PANEL





TURN ON/OFF

Press the power button to turn ON or turn OFF the unit.




NFC


If your device features NFC functionality, simply approach its NFC area with the  mark of the THEATRE BOX™.




TV AUDIO



PAIR


Note: If the Bluetooth connection is preoccupied, and you want to have a new device connected to the THEATRE BOX™, hold the  button until the LED flashes white and red indicating that it enters pairing mode.




CHARGE

Connect the THEATRE BOX™ to a power outlet using the power adaptor. The LED ring indicator will turn white when the device is fully charged. Full charging capacity is reached in about 4.5 hours. When using the device for the first time, it needs to be fully charged to become operational.



Normally, a fully-charged THEATRE BOX™ can be used for up to 20 hours of playback. When power is low, the LED ring indicator on the back of the unit will turn red.



AUX IN



CONFERENCE CALL



You have an incoming call.

DECLARATION OF CONFORMITY

Hereby, ACEMILE Inc declares that this device is in compliance with the essential requirements and other relevant provisions of Directive 1999/5/EC.

